

You are here: [MIP API](#) > [Commands](#) > [3DM \(0x0C\)](#) > Data Stream Control (0x0C,0x11)

## Data Stream Control (0x0C,0x11)

<b>Description</b>	<b>Enable/disable the selected data stream.</b>	
<b>Notes</b>	Each data stream (descriptor set) can be enabled or disabled. The default for the device is all streams enabled. For all functions except 0x01 (use new setting), the new enable flag value is ignored and can be omitted.	
<b>Parameter Name</b>	<b>Data Type</b>	<b>Description</b>
<i>Field Length</i>	<i>u8</i>	5
<i>Descriptor</i>	<i>u8</i>	0x11
Function Selector	u8	This command supports the following MIP function selectors: Write Read Save Load Default [WRS LD]
Desc Set [WRS LD]	<a href="#">u8</a>	The descriptor set of the stream to control. When function is SAVE, LOAD, or DEFAULT, can be ALL_STREAMS(0) to apply to all descriptor sets. On Generation 5 products, this must be one of the above legacy constants.
Enable [W]	<a href="#">bool</a>	True or false to enable or disable the stream.
<b>Ack/Nack Reply</b>	<a href="#">See standard MIP ack/nack reply format.</a>	
<b>Response Data</b>	<b>Data Type</b>	<b>Description</b>
<i>Response Length</i>	<i>u8</i>	4
<i>Response Descriptor</i>	<i>u8</i>	0x85
Desc Set	<a href="#">u8</a>	
Enabled	<a href="#">bool</a>	