



Figure 5-30 Nearest Airports Window on PFD

With the Nearest Airports Window displayed, pressing the **ENT** Key displays the PFD Airport Information Window for the highlighted airport. Pressing the **ENT** Key again returns to the Nearest Airports Window with the cursor on the next airport in the list. Continued presses of the **ENT** Key sequences through the information pages for all airports in the Nearest Airports list.



Figure 5-31 Airport Information Window on PFD

Viewing information for a nearest airport on the PFD:

- 1) Select the **Nearest** Softkey to display the 'Nearest Airports' Window.
- 2) Highlight the airport identifier with the **FMS** Knob and press the **ENT** Key to display the 'Airport Information' Window.
- 3) To return to the 'Nearest Airports' Window press the **ENT** Key (with the cursor on 'BACK') or press the **CLR** Key. The cursor is now on the next airport in the nearest airports list. (Repeatedly pressing the **ENT** Key moves through the airport list, alternating between the 'Nearest Airports' Window and the 'Airport Information' Window.)
- 4) Press the **CLR** Key or select the **Nearest** Softkey to close the PFD 'Nearest Airports' Window.