

I-Bus Button Codes

[Richard Naninck](#) has provided the following table of codes for button activity:

IMPORTANT: This information is provided for reference purposes only. Use this information at your own risk.

Reverse Play:	Press	F0 04 68 48 14 C0
	Release	F0 04 68 48 94 40
	Longer than 1 second	F0 04 68 48 54 80
Eject:	Press	F0 04 68 48 24 F0
	Release	F0 04 68 48 A4 70
	Longer than 1 second	F0 04 68 48 64 B0
Telephone:	Press	F0 04 FF 48 08 4B
	Release	F0 04 FF 48 88 CB
	Longer than 1 second	F0 04 FF 48 48 0B
Clock:	Press	F0 04 FF 48 07 44
	Release	None
	Longer than 1 second	None
Menu:	Press	F0 04 FF 48 34 77
	Release	F0 04 FF 48 B4 F7
	Longer than 1 second	F0 04 FF 48 74 37
Menu turnknob:	Press	F0 04 3B 48 05 82
	Release	F0 04 3B 48 85 02
	Longer than 1 second	F0 04 3B 48 45 C2
	Counterclockwise	F0 04 3B 49 01 87
	Clockwise	F0 04 3B 49 81 07
Radio Power:	Press	F0 04 68 48 06 D2
	Release	F0 04 68 48 86 52
	Longer than 1 second	F0 04 68 48 46 92
Rad/BM switch:	Press	F0 04 68 48 30 E4
	Release	F0 04 68 48 B0 64
	Longer than 1 second	F0 04 68 48 70 A4
Tone:	Press	???
	Release	???
	Longer than 1 second	F0 04 68 48 44 90
Select:	Press	F0 04 68 48 20 F4
	Release	F0 04 68 48 A0 74
	Longer than 1 second	F0 04 68 48 60 B4

Arrow Left:	Press	F0 04 68 48 10 C4
	Release	F0 04 68 48 90 44
	Longer than 1 second	F0 04 68 48 50 84
Arrow Right:	Press	F0 04 68 48 00 d4
	Release	F0 04 68 48 80 54
	Longer than 1 second	F0 04 68 48 40 94
Dolby: (small screen)	Press	F0 04 68 48 33 E7
	Release	F0 04 68 48 B3 67
	Longer than 1 second	F0 04 68 48 73 A7
Mode:	Press	F0 04 68 48 23 F7
	Release	F0 04 68 48 A3 77
	Longer than 1 second	F0 04 68 48 63 B7
AM:	Press	F0 04 68 48 21 F5
	Release	F0 04 68 48 A1 75
	Longer than 1 second	F0 04 68 48 61 B5
FM:	Press	F0 04 68 48 31 E5
	Release	F0 04 68 48 B1 65
	Longer than 1 second	F0 04 68 48 71 A5
RDS: (small screen)	Press	F0 04 68 48 22 F6
	Release	F0 04 68 48 A2 76
	Longer than 1 second	F0 04 68 48 62 B6
TP: (small screen)	Press	F0 04 68 48 2 E6
	Release	F0 04 68 48 B2 66
	Longer than 1 second	F0 04 68 48 72 A6
1:	Press	F0 04 68 48 11 C5
	Release	F0 04 68 48 91 45
	Longer than 1 second	F0 04 68 48 51 85
2:	Press	F0 04 68 48 01 D5
	Release	F0 04 68 48 81 55
	Longer than 1 second	F0 04 68 48 41 95
3:	Press	F0 04 68 48 12 C6
	Release	F0 04 68 48 92 46
	Longer than 1 second	F0 04 68 48 52 86
4:	Press	F0 04 68 48 02 D6
	Release	F0 04 68 48 82 56
	Longer than 1 second	F0 04 68 48 42 96
5:	Press	F0 04 68 48 13 C7

6:	Release	F0 04 68 48 93 47
	Longer than 1 second	F0 04 68 48 53 87
	<hr/>	
	Press	F0 04 68 48 03 D7
	Release	F0 04 68 48 83 57
	Longer than 1 second	F0 04 68 48 43 97