

### I-Bus Codes: E46 (3 Series 1999-2005)

IBUS Code	Windows
3F 05 00 0C 52 01 65	Driver Front Window: Open
3F 05 00 0C 53 01 CK	Driver Front Window: Close
3F 05 00 0C 41 01 76	Driver Rear Window: Open
3F 05 00 0C 42 01 CK	Driver Rear Window: Close
3F 05 00 0C 54 01 CK	Passenger Front Window: Open
3F 05 00 0C 55 01 CK	Passenger Front Window: Close
3F 05 00 0C 44 01 CK	Passenger Rear Window: Open
3F 05 00 0C 43 01 CK	Passenger Rear Window: Close
3F 05 00 0C 7E 01 CK	Sunroof: Open
3F 05 00 0C 7F 01 CK	Sunroof: Close
IBUS Code	Doors and Locks
3F 05 00 0C 47 01 CK	Driver Front Door: Lock
3F 05 00 0C 46 01 CK	Passenger Front Door: Lock
3F 05 00 0C 34 01 CK	All Doors: Toggle Lock/Unlock
3F 05 00 0C 02 01 CK	Trunk: Open
3F 05 00 0C 03 01 CK	Lock doors and fade out interior lights
IBUS Code	Radio
C0 06 68 31 00 00 0B 94	"Mode" Button: Press
C0 06 68 1 00 13 4B C7	"Mode" Button: Release
50 03 C8 01 9A	"R/T" Button: Press
68 03 18 01 72	Radio polling for CD changer. Expects response of 18 04 68 02 00 76.
18 04 68 02 00 76	CD changer responding to Radio to confirm existence.
50 04 68 32 10 1E	"Volume Down" Button: Press
50 04 68 32 11 1F	"Volume Up" Button: Press
IBUS Code	Lights
00 04 BF 76 00 CK	Turn all exterior lights off.
00 04 BF 76 02 CK	Flash warning lights on/off repeatedly.
00 04 BF 76 04 CK	Flash lowbeams on/off repeatedly.
00 04 BF 76 06 CK	Flash lowbeams and warning lights on/off repeatedly.
00 04 BF 76 08 CK	Flash highbeams on/off repeatedly.
00 04 BF 76 0A CK	Flash highbeams and warning lights on/off repeatedly.
00 04 BF 76 0C CK	Flash highbeams and lowbeams on/off repeatedly.

00 04 BF 76 0E CK	Flash highbeams, lowbeams and warning lights on/off repeatedly.
3F 05 BF 0C 01 01 CK	Cycle through exterior lighting patterns (high, low, fogs).
D0 07 BF 5B 60 00 04 00 CK	Flash dash blinkers (without flashing exterior blinkers)
D0 07 BF 5B 60 00 80 00 CK	Flash dash blinkers FAST/SLOW intermitent.
3F 05 00 0C 01 01 CK	Turn off interior lights.
3F 05 00 0C 4E 01 CK	Turn on clown nose for 3 seconds.
3F 05 00 0C 60 01 CK	Turn on interior lights for 3 seconds.
<b>IBUS Code</b>	<b>Seats</b>
3F 06 72 0C 01 01 00 CK	Driver Seat: Move Forward
3F 06 72 0C 01 02 00 CK	Driver Seat: Move Backward
3F 06 72 0C 01 04 00 CK	Driver Seat: Move Up
3F 06 72 0C 01 08 00 CK	Driver Seat: Move Down
3F 06 72 0C 01 40 00 CK	Driver Seat: Move Upper Portion Forward
3F 06 72 0C 01 80 00 CK	Driver Seat: Move Upper Portion Backward
<b>IBUS Code</b>	<b>Mirrors</b>
9B 04 51 6D 41 CK	Passenger Mirror: Move Out
9B 04 51 6D 42 CK	Passenger Mirror: Move In
9B 04 51 6D 44 CK	Passenger Mirror: Move Up
9B 04 51 6D 48 CK	Passenger Mirror: Move Down
9B 04 51 6D 40 CK	Passenger Mirror: Stop (motor won't stop until you tell it to)
<b>IBUS Code</b>	<b>Bluetooth</b>
3F 04 C8 1B 86 6E	Bluetooth Passkey Request to Phone
C8 08 3F A0 86 XX XX FF FF CK	Phone answer for Passkey Request, XX XX is the passkey.
3F 04 C8 1C 84 6B CK	Bluetooth Coupling Mode
3F 08 C8 1C 86 XX XX FF FF CK	Set Bluetooth Passkey.
3F 05 C8 1C 88 00 66	Turn Bluetooth On.
3F 05 C8 1C 88 01 67	Turn Bluetooth Off.
3F 04 C8 08 03 F8	Request for Bluetooth Name from phone.
C8 LL 3F A0 03 XX ... CK	Response from phone with Bluetooth Name.
<b>IBUS Code</b>	<b>Memory</b>
00 04 BF 72 20 E9	Car opened with remote/key 1
72 05 BF 78 05 00 B5	Save Memory: Position 1
3F 06 72 0C 02 01 00 CK	Driver Seat: Move to Memory Position 1

3F 06 72 0C 02 02 00 CK	Driver Seat: Move to Memory Position 2
3F 06 72 0C 02 04 00 CK	Driver Seat: Move to Memory Position 3

Letztes Update auf dieser Seite:  
16:09 11.05.2007

[zurück](#)