

# Lamp Status

From HackTheIBus

## Description

The status of the lamps. Is sent when some light changes occur. Also informs about the state of the light (cold and hot monitoring results)

## Format

<b>Message code</b>	0x5B
<b>Message length</b>	4 bytes
<b>Data size</b>	7 bytes
<b>Frequency</b>	all 3 seconds

## Example

```
00 07 BF 5B 20 00 04 00 17
```

LKM --> GLO : Lamp status: Indicator\_Left Indicator\_sync All\_OK

Retrieved from "[http://ibus.stuge.se/Lamp\\_Status](http://ibus.stuge.se/Lamp_Status)"

- 
- This page was last modified 21:00, 26 July 2008.
  - This page has been accessed 870 times.
  - Privacy policy
  - About HackTheIBus
  - Disclaimers