



NanoPower

P60 ACU 200

Manual

Software Documentation

Release 2.0.2

Product name: NanoPower P60 ACU 200

Document No.: 1018434

Revision: 2.0.2

Author: Gomspace

Approved by: Gomspace

Approval date: 2023

Confidentiality Notice

This document is submitted for a specific purpose as agreed in writing and contains information, which is confidential and proprietary. The recipient agrees by accepting this document, that this material will not be used, transferred, reproduced, modified, copied or disclosed in whole or in part, in any manner or to any third party, except own staff to meet the purpose for which it was submitted without prior written consent.

GomSpace © 2023

Table of Contents

1	Introduction	1
1.1	Unpacking and Handling Precautions	1
2	Overview	2
3	Command Interface	3
3.1	Global Settings	3
4	Operation	4
4.1	Board Parameters	4
4.2	Configuration Parameters	4
4.2.1	Charging Control	4
4.2.2	Hardware protection	5
4.3	Calibration Parameters	5
4.4	Telemetry Parameters	6
4.5	Configuration	6
4.6	Ground Watchdog	6
5	Client API	8
5.1	CSP Port Numbers	8
5.2	Get and Set Configuration Parameters	8
5.3	Retriving Housekeeping Parameters	9
5.4	Reset Ground Watchdog Timer	10
6	Parameter Tables	12
6.1	Table 0: Board Parameters	13
6.2	Table 1: Configuration Parameters	13
6.3	Table 2: Calibration Parameters	14
6.4	Table 4: Telemetry	14

1. Introduction

The GomSpace NanoPower P60 EPS is a flexible and modular system to rapidly implement power supply systems based on customer requirements. The P60 ACU-200 is part of the NanoPower P60 EPS modular power supply system.

This manual describes the P60 ACU-200 firmware version 2.0.2:

- Command Interface
- CSP Client API
- Parameter Tables

1.1 Unpacking and Handling Precautions



Warning The P60 ACU-200 is an ESD sensitive device. Proper precautions must be observed during the handling of the device.

Please use an ESD mat and a wrist strap as a minimum. Please wear gloves to avoid fingerprints on the anodized aluminum parts, as these are particularly difficult to rinse off. If any cleaning of the parts are required prior to flight, use only ESD safe cleaning methods and a neutral, non-reactive, IPA solvent.

2. Overview

The P60 ACU-200 can be operated through the Cubesat Space Protocol (CSP) over CAN, I²C or serial port. This integrates well with other GomSpace products, and GomSpace provides a client library for commanding the P60 ACU-200 from other systems running CSP. Refer to the *Client API* page for documentation of the client library API.

For integration and testing purposes, a command line interface is also available as explained in *Command Interface*. The command line interface uses the client API internally, so command names generally reflects the API function names.

The block diagram below shows the different P60 ACU-200 modules.




Fig. 2.1: P60 ACU-200 Block Diagram

3. Command Interface

For testing and debugging purposes, the P60 ACU-200 can be operated using the GomSpace Shell (GOSH) interface. The console interface is available in the FPC Debug connector. The serial connection is 8 databits, 1 stopbit, no parity at 500000 baud. On Linux, the serial connection can be opened using the `minicom` or `tio` tools (`tio` was formerly known as `gotty`).

You can now execute commands in the GOSH command interpreter. An example command is `cmp ident` which lists identification info of the current subsystem:

```
p60-acu # cmp ident
Hostname: p60-acu
Model:    NanoPower P60 ACU-200
Revision: v1.0
Date:     Jun 10 2016
Time:     09:53:08
```

A list of available commands can be shown by running the `help` command in GOSH. Pressing the `tab` key automatically completes commands and subcommands, and shows a usage string. Commands specific to the P60 ACU-200 are assembled under the `p60acu` command group. These commands are also available in `csp-term` for operating the P60 ACU-200 via CSP:

```
p60-acu # p60acu
node          Set P60 ACU node address
timeout       Set timeout in milliseconds
hk            Retrieve and list all housekeeping parameters
gndwdt_clear  Clear GND WDT
```

Note: All of the `p60acu` commands run over loopback CSP using GOSH command wrappers around the *Client API*

3.1 Global Settings

The P60 ACU-200 command line interface is written such that there are a few global variables that can be set first. The default values of the variables are:

- The P60 ACU-200 CSP address is set to 2.
- Timeout is set to 5000 ms.

These values can be set using the `p60acu node <node>` and `p60acu timeout <timeout>`. To show the current setting, run each command without an argument.

4. Operation

The P60 ACU-200 has three configuration parameter tables:

- Board parameters (table 0)
- Configuration parameters (table 1)
- Calibration parameters (table 2)

P60 ACU-200 telemetry parameters are available in parameter table 4.

See *Parameter Tables* for details on the individual parameter tables.

4.1 Board Parameters

The Board parameters will normally be configured from factory.

The P60 ACU-200 does not support RS422 USART and `rs422` should be set to 0.

CSP address is controlled by the parameter `csp_addr`. The default CSP address is 2 for the P60 ACU-200. If multiple P60 ACU-200 modules are included, they will need to use different CSP address.

4.2 Configuration Parameters

The P60 ACU-200 power point tracking can either be Fixed or Tracking mode. This is controlled by the parameter `mppt_mode`. To use Fixed mode, set `mppt_mode` to 2. To use Tracking mode, set `mppt_mode` to 1.

The P60 ACU-200 module has a total of 6 input channels.

For each input channel, the fixed power point voltage level used for charging the battery can be set by the parameter `vboost[]`.

In Fixed mode, the voltage is set to the value of parameter `vboost[]` and is not changed, except if battery charge is completed.

In Tracking mode, the voltage is initialized to the value of parameter `vboost[]`. By tracking the power, the input voltage is regulated to optimize the power generated by the input channels. It is possible to limit how much the voltage is changed from the initial `vboost` value. This is controlled by the parameter `max_dv`. E.g. if the `vboost[]` is set to 10000 mV and the `max_dv` is set to 5000 mV, the minimum voltage allowed will be 5000 mV and the maximum will be 15000 mV.

In both modes, the lower limit for `vboost[]` is 4300 mV and the upper limit is 27000 mV.

4.2.1 Charging Control

When the battery becomes fully charged or near to fully charged, the charging will be regulated to avoid over charging the battery. This is controlled by two parameters, `vbat_max_hi` and `vbat_max_lo`. When the battery voltage exceeds `vbat_max_lo`, the P60 ACU-200 will regulate the voltage down slowly to reduce the charging power. If the charging continues, even with reduced voltage, and the `vbat_max_hi` limit is reached, the charging will be reduced to a minimum. Charging will not be resumed until the battery voltage drops below `vbat_max_lo`. The following table lists the recommended values for `vbat_max_hi` and `vbat_max_lo` for 8, 16 and 32 V battery.

Table 4.1: Recommended settings for `vbat_max_hi` and `vbat_max_lo`

Battery Pack Voltage	8 V	16 V	32 V
<code>vbat_max_hi</code>	8300 mV	16600 mV	33200 mV
<code>vbat_max_lo</code>	8150 mV	16300 mV	32600 mV

The `ov_mode` defines the photovoltaic converter behavior of the P60 ACU-200 when the battery is fully charged, i.e. above the `vbat_max_hi` value.

When the battery voltage is above `vbat_max_hi`, the charging is minimised by setting the vboost voltage level to the maximum value (27000 mV) or the minimum value (4300 mV), depending on the parameter `ov_mode`. If `ov_mode` is 1, the vboost voltage level will be set to the minimum value (4300 mV). If `ov_mode` is 2, the vboost voltage level will be set to the maximum value (27000 mV).

The default `ov_mode` is 2, defining that the photovoltaic input is open circuited when the battery is fully charged. This mode is used on all spacecrafts with 8V, 16V and 32V battery pack, as long as each photovoltaic input open circuit voltage is guaranteed to be below the maximum operation voltage of the battery pack. E.g. a 8V battery pack requires an open circuit photovoltaic of no more than 8400 mV.

In special cases it may be desired to have a photovoltaic array with an open circuit input voltage slightly above the max. battery voltage. If such a case cannot be avoided the `ov_mode` must be set to 1. When `ov_mode` is 1, the photovoltaic input converter set point is as low as possible (4300 mV) when the maximum battery voltage is reached. Note that in this case, a one-string photovoltaic panel (500 mA) still produces about 2.2 W. It is recommended to have sufficient amount of subsystems powered ON in normal mode to avoid charging the battery further.

If the battery is charged further, the P60 Dock will disconnect the battery as a final protection method until the voltage is within safe operation again. Tripping the P60 Dock overvoltage battery protection may cause the spacecraft to be power cycled, as the available photovoltaic input power might be insufficient.

4.2.2 Hardware protection

Both the P60 ACU-200 and the P60 Dock has hardware protection circuits to protect the battery. The P60 ACU-200 takes this into account when controlling the charging of the battery. If the battery voltage exceeds the hardware protection high threshold, the charging will not resume until the battery voltage level has dropped below the hardware protection low threshold. For security reasons, the hardware protection low and high threshold are not configurable, but are listed here for reference:

Table 4.2: Hardware protection thresholds for battery voltage

Battery Pack Voltage	8 V	16 V	32 V
High threshold	8400 mV	16800 mV	33600 mV
Low threshold	7625 mV	15250 mV	30500 mV

4.3 Calibration Parameters

The P60 ACU-200 module has a set of calibration parameters for voltage and current measurements.

The calibrations parameters are configured from factory and normally don't need to be changed.

For voltages, there is a gain parameter. The gain is a floating-point number.

For currents, there is a gain and an offset parameter. The gain is a floating-point number. The offset is a signed 16-bit integer that controls the offset in mA.

The following table lists the default nominal values for each calibration parameter:

Table 4.3: P60 ACU-200 Calibration values

Name	Voltage gain	Current gain	Current offset
V IN channel 0	11.0	1.0	0
V IN channel 1	11.0	1.0	0
V IN channel 2	11.0	1.0	0
V IN channel 3	11.0	1.0	0
V IN channel 4	11.0	1.0	0
V IN channel 5	11.0	1.0	0
VBAT	25.0	n/a	n/a
VCC	3.2	n/a	n/a
DAC channel 0	11.0	n/a	n/a
DAC channel 1	11.0	n/a	n/a
DAC channel 2	11.0	n/a	n/a
DAC channel 3	11.0	n/a	n/a
DAC channel 4	11.0	n/a	n/a
DAC channel 5	11.0	n/a	n/a

4.4 Telemetry Parameters

The P60 ACU-200 module will provide the measured input voltage and current for each input channel in parameters `v_in[]` and `c_in[]` respectively. The calculated power is also available in parameter `power[]`. The charging voltage is provided in the parameter `vboost[]`.

P60 ACU-200 also measures VCC and VBAT, they available in parameters `vcc` and `vbat`. Temperature of the P60 ACU-200 is measured in three locations on the module and is available in parameter `temp[]`.

The up time measured in seconds is available in the `uptime` parameter and the number of boots is available in the `bootcnt` parameter (see also *Parameter Tables* for details on the telemetry parameters).

4.5 Configuration

The P60 ACU-200 module has two sets of configuration, the running configuration and the default configuration. The default configuration is a fallback configuration that will be restored automatically if the ground watchdog is triggered (see *Ground Watchdog*)

The P60 ACU-200 has a set of commands to manage the configuration:

```
p60-pdu # config
status          Show FRAM Lock status
lock            Lock FRAM upper tables 0x1000 to 0x1800
unlock          Unlock FRAM upper tables 0x1000 to 0x1800
gnd_wdt         Get or set gnd wdt timeout value
update_default  Update default factory settings in FRAM
verify_default  Verify default factory settings in FRAM
```

4.6 Ground Watchdog

The P60 ACU-200 module has a ground watchdog that needs to be activated at least every 48 hours if enabled. The purpose of the ground watchdog is to enable the P60 ACU-200 to revert to the default configuration if for some reason the running configuration prevents the P60 ACU-200 from operating.

If the ground watchdog is triggered, the P60 ACU-200 will restore to the default configuration and then do a reset of the P60 ACU-200.

To enable the ground watchdog and set the timeout value, run the following command from the GOSH terminal:

```
config gnd_wdt <timeout in seconds>
```

The minimum value is 172800 seconds (48 hours). The maximum value 31536000 seconds (365 days). To disable the ground watchdog, set the timeout to 0 seconds.

Note: The P60 ACU-200 will restore to the default configuration and then do a reset of the P60 ACU-200 if the ground watchdog is triggered.

5. Client API

The client API consists of a set of wrapper functions that simplify the CSP interface to the P60 ACU-200. These functions are implemented in the `p60acu_client.c` file and can be integrated in custom code by including the `p60acu.h` header file. The file `p60acu_cmd.c` implements the GOSH commands for the P60 ACU-200 and can be used as an additional reference for the use of the client API.

All the client functions specify a `timeout` argument that is used to specify the maximum number of milliseconds to wait for a reply. The client interface automatically performs endian conversion to network byte order on all arguments.

5.1 CSP Port Numbers

The P60 ACU-200 listens on the following CSP port numbers

Table 5.1: P60 ACU-200 CSP port numbers

Port	Name	Description
0	CSP_CMP	Control Port
1	CSP_PING	Returns a copy of the packet received
2	CSP_PS	Returns process list
3	CSP_MEMFREE	Returns memory free
4	CSP_REBOOT	Reboots subsystem
5	CSP_BUF_FREE	Returns number of free buffers
6	CSP_UPTIME	Returns subsystem uptime
7	P60_PORT_RPARAM	Controls P60 ACU with parameter system (see below)
9	P60_PORT_GNDWDT_RESET	Used for ground watchdog reset
10	P60_PORT_CMDCONTROL	Reserved for future use

For a description on how to use the CSP ports, please see `libcsp` manual. For a description on the parameter system, please see `libparam` manual.

5.2 Get and Set Configuration Parameters

Getting and setting configuration parameters is done by using the remote parameter system API provided by `libparam`.

Get a single configuration parameter from P60 ACU-200:

```
#include <p60acu.h>

uint16_t vboost;
int res = rparam_get_single(&vboost,          /* Pointer to variable */
                           P60ACU_MPPT_VBOOST(0), /* Logical address of parameter */
                           PARAM_UINT16,        /* Parameter type */
                           2,                   /* Parameter size */
                           P60ACU_PARAM,       /* Parameter table id */
                           p60acu_node,        /* P60 ACU csp node address */
                           P60_PORT_RPARAM,    /* CSP port number */
                           1000);              /* Timeout in milliseconds */

if (res > 0) {
    printf("Get vboost[0]: %u\n", vboost);
}
```

Set a single configuration parameter on P60 ACU-200:

```
#include <p60acu.h>

uint16_t vboost = 5200;
int res = rparam_set_single(&vboost,          /* Pointer to variable */
                           P60ACU_MPPT_VBOOST(0), /* Logical address of parameter */
                           PARAM_UINT16,        /* Parameter type */
                           2,                   /* Parameter size */
                           P60ACU_PARAM,        /* Parameter table id */
                           p60acu_node,         /* P60 ACU csp node address */
                           P60_PORT_RPARAM,     /* CSP port number */
                           1000);              /* Timeout in milliseconds */

if (res > 0) {
    printf("Set vboost[0]: %u\n", vboost);
}
```

5.3 Retriving Housekeeping Parameters

Retrieving Housekeeping Parameters from the P60 ACU-200 is provided by the `p60acu_get_hk` function.

```
int p60acu_get_hk(param_index_t * mem, uint8_t node, uint32_t timeout);
```

This function is used to retrieve housekeeping parameters from the P60 ACU-200. The housekeeping parameters are retrieved over CSP using the remote parameter system API provided by libparam. The function `p60acu_get_hk` is basically a wrapper around the remote parameter system API. The input parameter `mem` must be provided with a pointer to memory to hold the housekeeping parameters. The input parameter `node` must provide the CSP node address of the P60 ACU-200 and the `timeout` must provide the timeout in milliseconds. The following shows an example of this.

```
#include <p60acu.h>

uint8_t p60acu_node = 2;
uint8_t hk_mem[P60ACU_HK_SIZE];
param_index_t p60acu_hk = {0};
p60acu_hk.physaddr = hk_mem;
if (!p60acu_get_hk(&p60acu_hk, p60acu_node, 1000)) {
    printf("Error getting p60acu hk\n");
} else {
    param_list(&p60acu_hk, 1);
}
```

Housekeeping parameters can also be retrieved directly from P60 ACU-200 using the remote parameter system API provided by libparam:

```
#include <p60acu.h>

uint8_t p60acu_node = 2;
uint16_t v_in;
int res = rparam_get_single(&vboost,          /* Pointer to variable */
                           P60ACU_HK_V_IN(0), /* Logical address of parameter */
                           PARAM_UINT16,        /* Parameter type */
                           1,                   /* Parameter size */
                           P60ACU_HK,          /* Parameter table id */
                           p60acu_node,         /* P60 ACU csp node address */
                           P60_PORT_RPARAM,     /* CSP port number */
                           1000);              /* Timeout in milliseconds */

if (res > 0) {
    printf("Get v_in[0]: %u\n", v_in);
}
```

The previous example retrieves a single parameter. It is possible to retrieve all Housekeeping parameters by retrieving the entire table:

```
#include <p60acu.h>

uint8_t hk_mem[P60ACU_HK_SIZE];
param_index_t node_hk = {0};
uint8_t p60acu_node = 2;

node_hk.physaddr = hk_mem;
node_hk.table = p60acu_hk;
node_hk.mem_id = P60ACU_HK;
node_hk.count = P60ACU_HK_COUNT;
node_hk.size = P60ACU_HK_SIZE;
int result = rparam_get_full_table(&node_hk,
                                   p60acu_node,
                                   P60_PORT_RPARAM,
                                   node_hk.mem_id,
                                   1000);

if (result != 0) {
    printf("Error retrieving P60 ACU housekeeping\n");
} else {
    printf("Retrieved P60 ACU housekeeping\n");
    /* List all vboost[] values, using parameter name */
    const param_table_t * param = param_find_name(node_hk.table,
                                                  node_hk.count,
                                                  "vboost");

    if (param != NULL) {
        for (uint8_t index = 0; index < 6; index++) {
            /* Read parameter using name */
            uint16_t *vboost = param_read_addr(param->addr + param->size * index,
                                                &node_hk,
                                                param->size);

            printf("vboost[%d]: %u\n", index, *vboost);
        }
    }
    /* List all c_in[] values, using parameter address */
    param = param_find_addr(node_hk.table, node_hk.count, 0x0000);
    if (param != NULL) {
        for (uint8_t index = 0; index < 6; index++) {
            /* Read parameter using address */
            int16_t *c_in = param_read_addr(param->addr + param->size * index,
                                             &node_hk,
                                             param->size);

            printf("c_in[%d]: %d mA\n", index, *c_in);
        }
    }
}
```

5.4 Reset Ground Watchdog Timer

The Ground Watchdog Timer is reset by a dedicated command to the P60 ACU-200. This can for example be used as a ground communication watch dog, i.e. this command is issued to P60 ACU-200 on each connection with the ground station. If no communication has been received for a period of 48 hours P60 ACU-200 will switch off and do a reset back to default configuration.

The Ground Watchdog Timer on the P60 ACU-200 is reset by sending a single byte with the value 0x78 to CSP port P60_PORT_GNDWDT_RESET.

The following code will reset the Ground Watchdog Timer on the P60 ACU-200:

```
#include <p60acu.h>

int p60acu_gndwdt_clear(uint8_t node, uint32_t timeout) {
    uint8_t magic = 0x78;
    return csp_transaction(CSP_PRIO_HIGH,
                           node,
                           P60_PORT_GNDWDT_RESET,
                           timeout,
                           &magic,
                           1,
                           NULL,
                           0);
}
```

6. Parameter Tables

A number of parameters on the P60 ACU-200 can be adjusted through the GomSpace parameter system. The parameters are divided across four tables depending on the parameter types.

Table 0 is used for system level parameters that are expected to stay fixed for the entire mission. Table 1 is used for adjusting the operation and performance parameters. Table 2 is used for system level calibration parameters that are expected to stay fixed for the entire mission. Table 4 is used to store telemetry data.

Table 6.1: P60 ACU-200 Parameter tables

Table	File	Default	Description
0	0	4	Board Configuration
1	1	5	Module Configuration
2	2	6	Calibration parameters
4	-	-	Telemetry Data

Through GOSH it is possible to list all parameters in a table by running the `param list <table>` command. Here it shows the default configuration parameters:

```
p60-acu # param list 1
Parameter list 1:
0x0000 mppt_mode          U8  2
0x0001 mppt_d_mode        U8  1
0x0002 vboost             U16 5000 5000 5000 5000 5000 5000
0x0010 vbat_max_hi        U16 29000
0x0012 vbat_max_hi        U16 28000
0x0014 mppt_period        U32 100
0x0018 max_dv             U16 1000
0x001A ov_mode            U8  2
```

A parameter is modified by first switching to its table with `param mem <table>` and then running `param set <parameter> <value>`. E.g., to adjust the vboost value for channel 0 from 5000 mV to 5200 mV we run the commands:

```
p60-acu # param mem 1
p60-acu # param set vboost[0] 5200
p60-acu # param get vboost[0]
GET vboost[0] = 5200
```

The updated parameter values are only valid until next reboot. To store a parameter permanently, the parameter table must be stored to its matching file number (listed in the table above). To make our change to the vboost value permanent, we then need to run `param save <table> <file>`:

```
p60-acu # param save 1 1
Table CRC 56712
Data CRC 14953
```

The parameter system protects the stored table with two checksums: one to protect the data itself against corruption and one to ensure that the stored data matches the table structure.

System parameters in tables 0, 1 and 2 are saved in FRAM file numbers 0, 1 and 2 respectively.

The P60 ACU-200 also has a default factory setting version of table 0, 1 and 2. The default factory settings are stored in locked FRAM sectors and must be unlocked prior to saving the parameter table. This is done using the `config unlock` command. After e.g. the `param save 0 4` command has been executed, the FRAM sectors can be relocked by calling `config lock` or by rebooting the system.

There is a convenience function for saving the default configuration for each configuration table 0, 1 and 2 or for all of them at once:

```
config update_default 0 config update_default 1 config update_default 2 config update_default all
```

Note: As a safety measure, the `config` commands are only available through the GOSH interface and can not be executed via CSP. It is therefore not possible to unlock and modify the table 0 parameters remotely. This prevents accidental modification of e.g. the CSP address in orbit.

Telemetry data in table 4 is not saved to permanent storage and thus not backed by a file number or a default factory setting.

6.1 Table 0: Board Parameters

Table 0 holds system level configuration. Modification of these parameters require a reboot of the system, before they take effect.

Table 6.2: P60 ACU-200 Parameter table 0: Board parameters

Name	Address	Type	Index	Default Value	Unit	Comment
uid	0x0000	STR (16)		0123456789ABCD		Board UID
type	0x0010	U8		1		Board type
rev	0x0011	U8		0		Board revision
csp_addr	0x0012	U8		2		CSP address
i2c_addr	0x0013	U8		2		I ² C address
i2c_speed	0x0014	U16		400	kbps	I ² C bitrate in kbps
can_speed	0x0016	U16		1000	kbps	CAN bitrate in kbps
kiss_en	0x0018	U8		0		Enable KISS
rs422_mode	0x0019	U8		0		RS422 mode (not used)
rs422_speed	0x001C	U32		115200	kbps	RS422 bitrate in kbps (not used)
csp_rtable	0x0020	STR (96)		Empty		CSP routing table

6.2 Table 1: Configuration Parameters

Table 1 contains P60 ACU-200 runtime configuration parameters.

Table 6.3: P60 ACU-200 Parameter table 1: Configuration parameters

Name	Address	Type	Index	Default Value	Unit	Comment
mppt_mode	0x0000	U8		2		MPPT mode (1=Tracking, 2=Fixed)
mppt_d_mode	0x0001	U8		1		MPPT delta update mode (Tracking mode only)
vboost	0x0002	U16	[0..5]	4650 .. 4650	mV	Vboost value for input channels
vbat_max_hi	0x0010	U16		33600	mV	Maximum Battery value high value
vbat_max_lo	0x0012	U16		32000	mV	Maximum Battery value low value
mppt_period	0x0014	U32		50		MPPT period (not used)
max_dv	0x0018	U16		1000		MPPT max step size
ov_mode	0x001A	U8		2		Over voltage handling mode (1=lowest vboost, 2=highest vboost)

6.3 Table 2: Calibration Parameters

Table 2 contains P60 ACU-200 calibration parameters.

Table 6.4: P60 ACU-200 Parameter table 2: Calibration parameters

Name	Address	Type	Index	Default Value	Unit	Comment
vref	0x0000	U16		2500	mV	Reference voltage in mV
gain_vcc	0x0004	FLT		3.2		Gain for VCC measurement
gain_vbat	0x0008	FLT		25.0		Gain for VBAT measurement
gain_v_in	0x000C	FLT	[0..5]	11.0 .. 11.0		Gain for Vboost measurement
gain_c_in	0x0024	FLT	[0..5]	1.0 .. 1.0		Gain for input current meas.
offs_c_in	0x003C	I16	[0..5]	0 0 0 0 0 0	mA	Offset for input current meas.
gain_dac	0x0048	FLT	[0..5]	11.0 .. 11.0		Gain for DAC output control

6.4 Table 4: Telemetry

This table contains P60 ACU-200 telemetry data. The values are automatically updated once per second by the housekeeping task. Only the `bootcnt` parameter is stored to persistent memory.

Table 6.5: P60 ACU-200 Parameter table 4: Telemetry parameters

Name	Address	Type	Index	Default Value	Unit	Comment
c_in	0x0000	I16	[0..5]	0 0 0 0 0 0	mA	Measured input current in mA
v_in	0x000C	U16	[0..5]	0 0 0 0 0 0	mV	Measured input voltage in mV
vcc	0x001A	U16		3300	mV	Measured VCC in mV
vbatt	0x0018	U16		8000	mV	Measured VBAT in mV
temp	0x001C	I16	[0..2]	255 0 0	0.1 °C	Measured temperature in 0.1 °C
mppt_mode	0x0022	U8		2		MPPT mode
vboost	0x0024	U16	[0..5]	5000 .. 5000	mV	Measured Vboost voltage in mV
power	0x0030	U16	[0..5]	0 0 0 0 0 0	mW	Power in mW
dac_en	0x003C	U8	[0..2]	0 0 0		DAC enable status
dac_val	0x0040	U16	[0..5]	186 .. 186		DAC raw channel value
bootcause	0x0050	U32		0		Boot cause
bootcnt	0x0054	U32		0		Boot count
uptime	0x0058	U32		1	sec	Uptime in seconds
resetcause	0x005C	U16		0		Reset cause
mppt_time	0x005E	U16		15	msec	MPPT processing time
mppt_period	0x0060	U16		100	msec	MPPT loop time
device_type	0x0064	U8	[0..7]	0 .. 0		Device type (see below)
device_status	0x006C	U8	[0..7]	0 .. 0		Device status (0=None, 1=OK, 2=Error, 3=Not found)
wdt_cnt_gnd	0x0074	U32		0	sec	Ground WDT reboots
wdt_gnd_left	0x0078	U32		172800	sec	Ground WDT value (remaining seconds before reboot)

The following table shows the device types for the P60 ACU-200:

Table 6.6: P60 ACU-200 Device type overview

Index	Type	Description
0	7	FRAM
1	1	ADC
2	1	ADC
3	3	DAC
4	3	DAC
5	3	DAC
6	4	Temperature sensor
7	0	Reserved

Disclaimer

Information contained in this document is up-to-date and correct as at the date of issue. As GomSpace A/S cannot control or anticipate the conditions under which this information may be used, each user should review the information in specific context of the planned use. To the maximum extent permitted by law, GomSpace A/S will not be responsible for damages of any nature resulting from the use or reliance upon the information contained in this document. No express or implied warranties are given other than those implied mandatory by law.