

MEDIATEK

CONFIDENTIAL

MT7986 EDCCA Application note

CTD/SE2/CS6
BR Hsieh



How to use EDCCA Command

■ Set command

● *EDCCAEnable*

- iwpriv ra0 set EDCCAEnable=0/1 (**1** : **Auto mode**, **0** : **Force Disable**)
- Auto mode : EDCCA will detect energy and block TX when energy is over threshold.
- Force disable : EDCCA will ignore energy.

● *EDCCAThreshold*

- iwpriv ra0 set EDCCAThreshold=**BandwidthID** : **Threshold**

● *BandwidthID*

- **0**: BW20 , **1**: BW40 , **2**: BW80
- **127**: Reset
 - If EDCCACfgMode=1, It will reset to the value that you enter last time.
 - If EDCCACfgMode=0, It will reset to Profile setting or HW setting.

● *Threshold*

- xxdbm (Only Positive value, ex. If you want to set to -60dbm, you should enter 60)
- **127 is invalid value**, means not going to set
- Range : (**0** , **-126**) dbm

■ Show command

- iwpriv ra0 show EDCCAEnable
- iwpriv ra0 show EDCCAThreshold

How to use EDCCA profile

- EDCCAEnable=0/1
 - **0** : Disable
 - **1** : Enable
- EDCCAThreshold=**xx:yy:zz**
 - **xx** : Pri/Sec BW20 Threshold
 - **yy** : Sec BW40 Threshold
 - **zz** : Sec BW80 Threshold
- EDCCACfgMode=0/1
 - 0 : EDCCA reset value will follow profile/HW setting
 - 1 : EDCCA reset value will follow cmd setting