

		SNO+ Laser Procedures	
Document Number:		Revision Number: 01	
Document Owner: SNO+ Calibration Post-Doc			
Reviewer:			
Name:	Signature	Date	
Authorizer:			
Name:	Signature	Date	

## 1 Purpose

The SNO+ laser is used in conjunction with the laser ball source in the calibration of the detector. Operators must be familiar with safe operation of the laser under standard calibration conditions. The standard procedures associated with this operation are described in this document.

## 2 Definitions

- **N<sub>2</sub> laser:** The light source for the calibration which requires a constant flow of N<sub>2</sub> gas to operate.
- **Thyratron:** A flat head rectifier that produces the static discharge in nitrogen used that generates the light for the laser.
- **dye cell:** Curvettes containing the dyes used to generate specific optical wavelengths of light by optical pumping.
- **filter wheel:** Two wheels (**a** for course adjustments, **b** for fine adjustments) mounted on stepping motors to select various neutral density filters to adjust the output light intensity.
- **dye laser:** The extended optics to select a dye cell and guide the resulting light to the optical output aperture.

SNO+ Laser Procedures	Document No:
	Revision No: 01
	Effective Date: 2017-04-12
	Page 2

- **manip:** The program used to run the calibration hardware including the laser.

### 3 Commands

The following are common commands executed through the manip terminal during laser operation.

- **n2laser:** Print a list of n2laser commands to the screen.
- **n2laser monitor:** Displays status information on the n2laser.
- **n2laser poweron:** Turn on the low voltage control power.
- **n2laser poweroff:** Turn off the low voltage control power.
- **n2laser start:** Turn on the high voltage power to the laser.
- **n2laser stop:** Turn off the high voltage power to the laser.
- **dyelaser** Print a list of dye laser commands to the screen.
- **dyelaser init** Initialize the dye laser.
- **dyelaser findzero** Find the zero position of the dye laser mirror. The mirror travels down its track till it hits a stop. Must always be executed after **dyelaser init**.
- **dyelaser cell [0-5]** Select the dye laser cell between 0 and 5.
- **filterwheel(a|b)** Show commands for filter wheel a or b.
- **filterwheel(a|b) init** Initialize the filter wheel.
- **filterwheel(a|b) findtab** Find the calibration tab on filter wheels.

#### 3.1 Starting the Laser

1. Open MV1, the manual valve on the LN<sub>2</sub> dewar.
2. Open MV2, the pressure builder valve on the LN<sub>2</sub> dewar.



SNO+ Laser Procedures	Document No:
	Revision No: 01
	Effective Date: 2017-04-12
	Page 4

### 3.2 Calibrating the Filter Wheels

The control systems sometimes lose track of where the filter wheels are positioned. To fix this follow this procedure.

1. Reinitialize the filter wheel using the **filterwheela init** command.
2. Find the tab on the filter wheel using the **filterwheela findtab** command.
3. Select the desired filter wheel position using the **n2laser setnd** command.

Note that this example was for filter wheel a. Replace **filterwheela** with **filterwheelb** for the second filter wheel.

### 3.3 Calibrating the Dye Cell Mirror

1. Reinitialize the mirror **dyelaser init**.
2. Find the zero of the mirror **dyelaser findzero**.
3. Select the desired wavelength. Note that the 6 dyecell locations are shared between the 10 logical ones. **dyelaser cell < 0 – 9 >**

### 3.4 Shutting Down the Laser

1. Block the light by typing **n2laser block** in the manip terminal.
2. At the manip terminal type **n2laser stop**.
3. Type **n2laser poweroff**
4. Unplug the powercord to the laser.
5. Turn off the pressure builder (MV2) and then turn off the N<sub>2</sub> gas (MV1).
6. Close the manual gas valve on the laser (PRV8).

## 4 Operator Notes

Operation Date:

Operator Names:

<b>SNO+ Laser Procedures</b>	Document No:
	Revision No: 01
	Effective Date: 2017-04-12
	Page 5

Comments:

## 5 Revision History

Originating Date: 2017-04-12			
Revision No.	Effective Date (YYYY-MM-DD)	Author	Summary of Change
01	2017-04-12	Ryan Bayes	Drafted from SNO Calibration Operators Manual (Laser, Revision 2) with minor revisions and editable blocks added for user notes.