

Raspberry PI Community Projects

Raspberry PI Community Projects

How To – Configure Sound

To get sound out through HDMI the default settings for the connector is DVI so you will need to change the following:

edit config.txt

```
sudo nano /boot/config.txt
```

Uncomment `# hdmi_drive=2`

```
# Force the monitor to HDMI mode so that sound will be sent over HDMI cable  
hdmi_drive=2
```

Other Settings Are:

To get sound out the headphone jack type:

```
sudo modprobe snd_bcm2835  
sudo amixer cset numid=3 1
```

To get sound out the HDMI

```
sudo modprobe snd_bcm2835  
sudo amixer cset numid=3 0
```

Trouble with omxplayer

set the -o output for 3.5 audio jack

```
omxplayer -o local
```

set the -o output for hdmi

```
omxplayer -o hdmi
```

Raspberry PI Community Projects

 Proudly powered by WordPress.