

User Profile Questionnaire

S1001-BDHO-FO-025

Dealer Name: _____

Date Of Sale

Model Purchased

Main User Yes ☐ No ☐

- | | | | | |
|------------------------------------|-------------------------------------|---------------------------------------|---|--------------------------------------|
| <input type="checkbox"/> Activa 5G | <input type="checkbox"/> Activa 125 | <input type="checkbox"/> Dream Yuga | <input type="checkbox"/> CB Shine SP | <input type="checkbox"/> CBR 250R |
| <input type="checkbox"/> Dio | <input type="checkbox"/> GRAZIA | <input type="checkbox"/> Dream Neo | <input type="checkbox"/> CB Unicorn | <input type="checkbox"/> CBR 650F |
| <input type="checkbox"/> Aviator | <input type="checkbox"/> NAVI | <input type="checkbox"/> CD 110 Dream | <input type="checkbox"/> CB Unicorn 160 | <input type="checkbox"/> Africa Twin |
| <input type="checkbox"/> Activa I | | <input type="checkbox"/> Livo | <input type="checkbox"/> CB Hornet 160R | |
| <input type="checkbox"/> CLIQ | | <input type="checkbox"/> CB Shine | <input type="checkbox"/> X BLADE | |

Name: _____ Date of Birth: _____ Gender ☐ Male ☐ Female Marital Status ☐ Married ☐ Unmarried

City: _____ Phone No.: _____ Have Kids ☐ Yes ☐ No If Yes, How Many

01. Occupation

- ☐ 1 Student ☐ 2 Comp Employee ☐ 3 Own Business ☐ 4 Agriculture / Fishery ☐ 5 Housewife ☐ 6 Other

02. What is your Monthly Family Income (of combined household including yourself)?

- ☐ 1 ≤ 10,000 ☐ 2 10,001 to 20,000 ☐ 3 20,001 to 30,000 ☐ 4 30,001 to 50,000 ☐ 5 50,001 to 1,00,000 ☐ 6 >1,00,000

03. Please give details of the model you are presently using for yourself ?(If you have any)

Maker _____ Model _____ Yr of Purchase _____

Continue....

04. What are the major reasons for buying this model now?

- | | |
|---|--|
| <input type="checkbox"/> 1 Able to afford a 2 wheeler now | <input type="checkbox"/> 4 Current 2 wheeler is not convenient |
| <input type="checkbox"/> 2 People needing 2 wheeler in the family increased | <input type="checkbox"/> 5 Current 4 wheeler is not suitable for daily usage |
| <input type="checkbox"/> 3 Current 2 wheeler has become old | <input type="checkbox"/> 6 Other → <input type="text"/> |

05. Is there someone other than you, who will ride this model?

- ☐ Yes (If Yes) → ☐ Male ☐ Female
- ☐ No

06. Before buying this model, did you make comparison with any other models? **Mention cc**

- ☐ No comparison made
- ☐ Yes, please mention model (s) →

Model 1

Model 2

Model 3

Model 4

07. What are the reasons for your buying this model?

- | | | | | |
|--|--|--|---|---|
| <input type="checkbox"/> 1 Style | <input type="checkbox"/> 2 Brand | <input type="checkbox"/> 3 Mileage | <input type="checkbox"/> 4 Reasonable Price | <input type="checkbox"/> 5 Advance Technology |
| <input type="checkbox"/> 6 Power & Pick up | <input type="checkbox"/> 7 After Sales Service | <input type="checkbox"/> 8 Low Maintenance | <input type="checkbox"/> 9 Resale Value | <input type="checkbox"/> 10 Riding Comfort |
| <input type="checkbox"/> 11 Other | <input type="text"/> | | | |

WELCOME

The vehicle presents you a challenge to master the machine, a challenge to adventure. You ride through the wind, linked to the road by a vehicle that responds to your commands as no other does. Unlike an automobile, there is no metal cage around you. Like an air plane, a pre-ride inspection and regular maintenance are essential to your safety. Your reward is freedom.

To meet the challenges safely, and to enjoy the adventure fully, you should become thoroughly familiar with this owner's manual BEFORE YOU RIDE THE VEHICLE.

As you read this manual, you will find information that is preceded by a **NOTICE** symbol. This information is intended to help you avoid damage to your vehicle, other property, or the environment.

When service is required, remember that your Honda dealer knows your vehicle. If you have the required mechanical "know-how" and tools, your dealer can supply you an official Honda shop manual on paid basis to help you perform many maintenance and repair tasks.

Accessories shown in the illustration are not part of the standard equipment.

For any query or assistance, please call Customer Care No.:

1800 103 3434 (Toll free)

Pleasant riding, and thank you for choosing a Honda!

- The specifications may vary with each locale.

IMPORTANT INFORMATION

- **RIDER AND PILLION RIDER**

This vehicle is designed to carry the rider and one pillion rider. Never exceed the maximum weight capacity.

- **ON-ROAD USE**

This vehicle is designed to be used only on the road.

- **READ THIS OWNER'S MANUAL CAREFULLY**

Pay special attention to the safety messages that appear throughout the manual.

This manual should be considered as a permanent part of the vehicle and should remain with the vehicle when resold.

All information in this publication is based on the latest production information available at the time of approval for printing. Honda Motor Co., Ltd. reserves the right to make changes at any time without notice and without incurring any obligation.

No part of this publication may be reproduced without written permission.

TABLE OF CONTENTS

	Page		Page
CATALYTIC CONVERTER-----	1	Evaporative Emission Control System --	21
A FEW WORDS ABOUT SAFETY -----	2	Engine Oil -----	22
VEHICLE SAFETY-----	3	Tyres-----	23
Important Safety Information-----	3	ESSENTIAL INDIVIDUAL	
Protective Apparel -----	4	COMPONENTS -----	26
Load Limits and Guidelines-----	5	Ignition Switch -----	26
Anti-theft Tips-----	7	Right Handlebar Control -----	27
PARTS LOCATION -----	8	Left Handlebar Controls -----	27
Serial Numbers-----	10	FEATURES -----	28
Instrument and Indicators -----	10	(Not required for operation)	
MAJOR COMPONENTS -----	14	Steering Lock -----	28
(Important Information to operate this vehicle)		Seat-----	29
Suspension -----	14	Headlight Aim Vertical Adjustment -----	30
Brakes -----	15	Left Side Cover-----	30
Clutch-----	18	Document Bag -----	31
Fuel -----	19	Storage Compartment & First Aid Kit---	32

TABLE OF CONTENTS

	Page		Page
OPERATION -----	32	Air Cleaner -----	50
Pre-ride Inspection -----	32	Drive Chain-----	51
Starting the Engine -----	33	Drive Chain Slider-----	56
Running-in -----	35	Front and Rear Suspension-----	56
Riding-----	35	Side Stand -----	57
Braking -----	36	Wheel Removal-----	57
Parking -----	38	Brake Pad Wear -----	60
MAINTENANCE -----	39	Brake Shoe Wear (for Drum)-----	61
The Importance of Maintenance -----	39	Battery -----	61
Maintenance Safety-----	39	Fuse Replacement -----	63
Safety Precautions-----	40	Stoplight Switch Adjustment -----	64
Maintenance Schedule-----	41	Bulb Replacement-----	65
Tool Kit -----	44	CLEANING -----	68
Color Code -----	44	STORAGE GUIDE -----	69
Engine Oil -----	44	Storage-----	69
Crankcase Breather-----	46	Removal From Storage -----	70
Spark Plug-----	47	SPECIFICATIONS -----	71
Idle Speed-----	48	WARRANTY POLICY -----	73
Throttle Operation -----	49		

CATALYTIC CONVERTER

This Vehicle is equipped with a catalytic converter.

The catalytic converter contains precious metals that serve as catalysts. Promoting chemical reactions to convert the exhaust gasses without affecting the metals.

The catalytic converter acts on HC, CO, and NOx. A replacement unit must be an original Honda part or its equivalent.

The catalytic converter must operate at a high temperature for the chemical reactions to take place. It can set on fire any combustible materials that come near it. Mark your vehicle away from high grasses, dry leaves, or other flammables.

A defective catalytic converter contributes to air pollution, and can impair your engine's performance. Follow these guidelines to protect your vehicle's catalytic converter.

- Always use unleaded petrol. Even a small amount of leaded petrol can contaminate the catalyst metals, making the catalytic converter ineffective.
- Keep the engine tuned-up.
- Have your vehicle diagnosed and replaced if it is misfiring, backfiring stalling or otherwise not running properly.

A FEW WORDS ABOUT SAFETY

Your safety, and the safety of others, is very important. Operating this vehicle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all hazards associated with operating or maintaining a vehicle. You must use your own good judgment.

You will find important safety information in a variety of forms, including :

- **Safety labels** - on the vehicle.
- **Safety messages** - preceded by a safety alert symbol  and one of three signal words: **DANGER**, **WARNING**, or **CAUTION**.

These signal words mean:

 **DANGER** You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

 **WARNING** You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

 **CAUTION** You **CAN** be **HURT** if you don't follow instructions.

- **Safety Heading** - such as Important Safety Reminders or Important Safety Precautions.
- **Safety Section** - such as vehicle Safety.
- **Instructions** - how to use this vehicle correctly and safely.

This entire manual is filled with important safety information—please read it carefully.

VEHICLE SAFETY

IMPORTANT SAFETY INFORMATION

Your vehicle can provide many years of service and pleasure if you take responsibility for your own safety and understand the challenges that you can meet on the road.

There is much that you can do to protect yourself when you ride. You'll find many helpful recommendations throughout this manual. Following are few that we consider most important.

Always Wear a Helmet

It's a proven fact: helmets significantly reduce the number and severity of head injuries. So always wear an approved helmet and make sure your Pillion rider does the same. We also recommend that you wear eye protection, sturdy boots, gloves, and other protective apparel (page 4).

Make Yourself Easy to be Visible

Some riders do not see vehicles because they are not looking for them. To make yourself more visible, wear bright reflective clothing, position yourself so other drivers can see you, signal before turning or changing lanes, and use your horn when it will help others notice you.

Ride Within Your Limits

Pushing the limits is another major cause of vehicle accidents. Never ride beyond your personal abilities or faster than conditions warrant. Remember that alcohol, drugs, fatigue and inattention can significantly reduce your ability to make good judgements and ride safely.

Keep Your Vehicle in Safe Condition

For safe riding, it's important to inspect your vehicle before every ride and perform all recommended maintenance. Never exceed load limits, and only use accessories that have been approved by Honda for this vehicle. See page 6 for more details.

Don't Drink and Ride

Don't mix Alcohol and riding. Even one drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. So don't drink and ride, and don't let your friends drink and ride either.

PROTECTIVE APPAREL

For your safety, we strongly recommend that you always wear an approved helmet, eye protection, boots, gloves, long pants, and a long-sleeved shirt or jacket whenever you ride. Although complete protection is not possible, wearing proper gear can reduce the chance of injury when you ride.

Following are suggestions to help you choose proper gear.

WARNING

Not wearing a helmet increases the chance of serious injury or death in a crash.

Be sure you and your Pillion rider always wear a helmet, eye protection and other protective apparel when you ride.

Helmets and Eye Protection

Your helmet is your most important piece of riding gear because it offers the best protection against head injuries. A helmet should fit your head comfortably and securely. A bright-colored helmet can make you more noticeable in traffic, as can reflective strips. An open-face helmet offers some protection, but a full-face helmet offers more. Always wear a face shield or goggles to protect your eyes and help your vision.

Additional Riding Gear

In addition to a helmet and eye protection, we also recommend:

- Sturdy boots with non-slip soles to help protect your feet and ankles.
- Leather gloves to keep your hands warm and help prevent blisters, cuts, burns and bruises.
- A vehicle riding suit or jacket for comfort as well as protection. Bright colored and reflective clothing can help make you more noticeable in traffic. Be sure to avoid loose clothes that could get caught on any part of your vehicle.

LOAD LIMITS AND GUIDELINES

Your vehicle has been designed to carry you and one Pillion rider. When you carry a Pillion rider, you may feel some difference during acceleration and braking. But so long as you keep your vehicle well- maintained, with good tyres and brakes, you can safely carry loads within the given limits and guidelines.

However, exceeding the weight limit or carrying an unbalanced load can seriously affect your vehicle's handling, braking and stability. Non-Honda accessories, improper modifications, and poor maintenance can also reduce your safety margin.

The following pages give more specific information on loading, accessories and modifications.

Loading

How much weight you put on your vehicle, and how you load it, are important to your safety. Anytime you ride with a Pillion rider or cargo you should be aware of the following information.



WARNING

Overloading or improper loading can cause a crash and you can be seriously hurt or killed.

Follow all load limits and other loading guidelines in this manual.

Load Limits

Following are the load limits for your vehicle:

Maximum weight capacity:

170 kg (374.8 lbs)

Includes the weight of the rider, Pillion rider, all cargo and all accessories

Loading Guidelines

Your vehicle is primarily intended for transporting you and a Pillion rider. You may wish to secure a jacket or other small items to the seat when you are not riding with a Pillion rider. If you wish to carry more cargo, check with your Honda dealer for advice, and be sure to read the information regarding accessories on (page 6).

Improperly loading your vehicle can affect its stability and handling. Even if your vehicle is properly loaded, you should ride at reduced speeds whenever carrying cargo. Follow these guidelines whenever you carry a Pillion rider or cargo:

- Check that both tyres are properly inflated.
- If you change your normal load, you may need to adjust the rear suspension (page 14).
- To prevent loose items from creating a hazard, make sure that all cargo is securely tied down before you ride away.
- Place cargo weight as close to the center of the vehicle as possible.
- Balance cargo weight evenly on both sides.
- Do not attach large or heavy items (such as a sleeping bag or tent) to the handlebars, forks or fender.

Accessories and Modifications

Modifying your vehicle or using non-Honda accessories can make your vehicle unsafe. Before you consider making any modifications or adding an accessory, be sure to read the following information.

WARNING

Improper accessories or modifications can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Accessories

We strongly recommend that you use only Honda Genuine Accessories that have been specifically designed and tested for your vehicle. Because Honda cannot test all other accessories, you must be personally responsible for proper selection, installation and use of non-Honda accessories. Check with your dealer for assistance and always follow these guidelines:

- Make sure the accessory does not obscure any lights, reduce ground clearance and banking angle, limit suspension travel or steering travel, alter your riding position or interfere with operating any controls.

- Be sure not to use any non-genuine electrical equipment or equipment having capacity exceeding vehicle's electrical system capacity (page 72). A blown fuse can cause a loss of lights or engine power.
- Do not pull a trailer or sidecar with your vehicle. This vehicle is not designed for these attachments, and their use can seriously impair your vehicle's handling.

Modification

We strongly advise you not to remove any original equipment or modify your vehicle in any way that would change its design or operation. Such changes could seriously impair your vehicle's handling, stability and braking, making it unsafe to ride.

Removing or modifying your lights, mufflers, emission control system or other equipment can also make your vehicle illegal.

ANTI-THEFT TIPS


1. Always lock the steering.
2. Never leave the key in the ignition switch. This sounds simple but people do forget.
3. Be sure the registration information for your vehicle is accurate and current.
4. Put your vehicle in a locked garage whenever possible.
5. Use an additional anti-theft device of good quality.
6. Put your name, address, and phone number in this Owner's Manual and keep it on your vehicles at all times. Many times stolen vehicles are identified by information in the Owner's Manuals.

NAME: _____


ADDRESS: _____

PHONE NO: _____


PARTS LOCATION



Right Side View



Left Side View



(1) Oil Filler Cap/Dipstick	(10) Choke Knob
(2) Rear Brake Pedal	(11) Main Fuse
(3) Footpeg	(12) Seat Lock
(4) Pillion Rider Footpeg	(13) License Plate Lamp
(5) Storage Compartment	(14) Battery
(6) Air Cleaner	(15) Side Stand
(7) Kickstarter	(16) Center Stand
(8) Reflector	(17) Gearshift Pedal
(9) Fuel Valve	(18) Engine Oil Drain Plug

SERIAL NUMBERS


The frame and engine serial numbers are required when registering your vehicle. They may also be required by your dealer when ordering replacement parts.

The "Frame Number" (1) is stamped on the right side of the steering head. The "Engine Number" (2) is stamped on the left side of the crankcase.

Record the numbers here for your reference.

FRAME NO. _____

ENGINE NO. _____




(1) Frame Number

(2) Engine Number

INSTRUMENT AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.



(1) Tachometer

(2) Speedometer

(3) Digital Clock

(4) Odometer/Tripmeter

(5) Fuel Meter

(6) High Beam Indicator

(7) Turn Signal/Hazard Indicator

(8) Neutral Indicator

(9) Anti-lock Brake System (ABS) Indicator (for ABS)

(10) SEL Button


(11) SET Button

(Ref.No.) Description	Function
(1) Tachometer	Shows engine revolution per minute
(2) Speedometer	Shows riding speed.
(3) Digital Clock	Shows hour and minutes
(4) Odometer/Tripmeter	Odometer - Shows accumulated mileage. Tripmeter - Its shows distance travelled since the time it was last reset to zero.
(5) Fuel Meter	Shows approximate fuel supply available.
(6) High Beam Indicator (Blue)	Indicate when the headlight is glowing on high beam.
(7) Turn Signal/Hazard Indicator (Green)	Flashes when turn signal/hazard switch operates.
(8) Neutral Indicator (Green)	Indicate when the transmission is in neutral.
(9) Anti-lock Brake System (ABS) Indicator (for ABS)	This indicator normally comes on when the ignition switch is turned ON and goes off after you ride the vehicle at speed above 10 km/h (6 mph). If there is a problem with the Anti-lock Brake System, this indicator flashes and remains ON (page 14).
(10) SEL Button NOTICE <i>Operate SEL Button with hands only.(Do not use sharp/pointed objects to operate SEL Button)</i>	Use these button for the following purposes. <ul style="list-style-type: none"> • To reset tripmeter • To adjust time
(11) SET Button NOTICE <i>Operate SET Button with hands only.(Do not use sharp/pointed objects to operate SET Button)</i>	

Fuel Meter

When the "Fuel Meter" (1) indicator enters the "Last Band" (2), it shows the less fuel in the tank. Turn the fuel valve to the RES position and you should refill the tank as soon as possible. The amount of fuel left in the tank with the vehicle set upright is approximately.

1.5 L (0.39 US gal, 0.32 Imp gal)




(1) Fuel Meter

(2) Last Band

Tripmeter

To reset the Tripmeter A or B proceed as follows:

Press the SEL button to select Tripmeter A or B.



(1) SEL Button

(2) SET Button

To reset the tripmeter, press and hold the SET button for more than 3 seconds when the display is in the "Trip".




Digital Clock

The digital clock will show hours and minutes up to 11:59.

To adjust the time, proceed as follows:

1. Turn the ignition switch ON.
2. Press and hold the both buttons "SEL" (1) and "SET" (2) for more than 3 seconds simultaneously. The clock will be set in the adjust mode with the hour flashing.



(1) SEL button

(2) SET button



3. To set the hour, press the SET button until the desired hour is displayed.

- Quick setting - press and hold the SET button until the desired hour appears.
4. Press the SEL button when the display reaches the desired hour.

The minute display will be flashing.



5. To set the minute, press the SET button until the desired minute appears.
- Quick setting - press and hold the SET button until the desired minute appears.
6. Press the SEL button when the display reaches the desired minute.

The display will stop flashing.

If the ignition switch is turned OFF or no operation is performed for 30 seconds during the time adjustment mode, the clock will be reset.

The clock will be reset to 1:00 if the battery is disconnected.

ABS (Anti-lock Brake System) indicator

It comes ON when the ignition switch is turned to the ON position and goes OFF when your speed reaches approximately 10 km/h.

If the indicator behave in one of the following ways, you may have a serious problem with the ABS. Reduce your speed and visit your Honda dealer as soon as possible.

- Indicator comes ON or starts flashing while riding.
- Indicator does not come ON when the ignition switch is in the ON position.
- Indicator does not go OFF at speeds above 10 km/h.
- If Battery is not connected properly, ABS wouldn't be actuated and speedometer display will turn OFF.

NOTICE

If the ABS indicator stays on, your vehicle brakes will continue to work as a conventional system, but without the anti-locking function.

MAJOR COMPONENTS

(Important Information to operate this vehicle)

SUSPENSION


The "Shock Absorber" (1) has 3 adjustment positions for different load or riding conditions.

Position 2 to 3 increases spring preload for a stiffer rear suspension, and can be used when the vehicle is heavily loaded.

NOTICE

For rear shock absorber adjustment visit to your nearest Honda dealer.

Standard position: 2



(1) Shock Absorber

BRAKES

Front Brake

This vehicle has a hydraulic front brake. As the brake pads wear, brake fluid level drops.


There are no adjustments to perform, but fluid level and pad wear must be inspected periodically. The system must be inspected frequently to ensure there are no fluid leaks.

If the brake lever free travel becomes excessive and the brake pads are not worn beyond the recommended limit (page 60), there is probably air in the brake system and it must be bled. Visit your Honda dealer for this service.

Front Brake Fluid Level:

With the vehicle in an upright position, check the fluid level. It should be above the "Lower Level Mark" (1). If the level is at or below the lower level mark, check the brake pads for wear (page 60).

Worn pads should be replaced. If the pads are not worn, have your brake system inspected for leaks.



(1) Lower Level Mark

The recommended brake fluid is Honda DOT 3 or 4 brake fluid from a sealed container, or an equivalent.

Other Checks:

Make sure there are no fluid leaks. Check for deterioration or cracks in the hoses and fittings.


Rear Brake

Adjustment: (for Drum brake)

1. Place the vehicle on its center stand.
2. Measure the distance the "Rear Brake Pedal" (1) moves before the brake starts to take hold.

Free play should be:


20 -30 mm (0.8 -1.2 in)



(1) Rear Brake Pedal

3. If adjustment is necessary, turn the "Rear Brake Adjusting Nut" (2).

Make sure the cut-out on the adjusting nut is seated on the "Brake Arm Joint" (3) after making final free play adjustment.



(2) Rear Brake Adjusting Nut

(3) Brake Arm Joint

(A) Decrease Free Play


(B) Increase Free Play

4. Apply the brake several times and check for free wheel rotation after the brake pedal is released.

If proper adjustment cannot be obtained by this method, visit your Honda dealer.

After adjustment, push the brake arm to confirm that there is a gap between the rear brake adjusting nut and the brake arm pin.

After adjustment, confirm the free play of the brake pedal.



Cut out
correctly seated



Cut out not
seated




Other Checks:

Make sure the brake arm, spring and fasteners are in good condition.

Rear Brake Fluid Level: (for Disc brake)

With the vehicle in a side right position, check the fluid level. It should be above the "LOWER Level Mark" (1). If the level is at or below the LOWER level mark, check the brake pads for wear (page 61).



(1) LOWER Level Mark

Worn pads should be replaced. If the pads are not worn, have your brake system inspected for leaks.

The recommended brake fluid is Honda DOT 3 or 4 brake fluid from a sealed container, or an equivalent.


Other Checks:

Make sure there are no fluid leaks. Check for deterioration or cracks in the hoses and fittings.

CLUTCH

Clutch adjustment may be required if the vehicle stalls when shifting into gear or tends to creep; or if the clutch slips, causing acceleration to lag behind engine speed. Normal clutch lever free play is:


10 -20 mm(0.4 -0.8 in)



(1) Clutch lever

1. Loosen the "Lock Nut" (2) at the lower end of the cable. Turn the "Adjusting Nut" (3) to obtain the specified free play. Tighten the lock nut and check the adjustment.

2. Start the engine, pull in the clutch lever and shift into gear. Make sure the engine does not stall and the vehicle does not creep. Gradually release the clutch lever and open the throttle. The vehicle should begin to move smoothly and accelerate gradually.



(2) Lock Nut

(3) Adjusting Nut

(A) Increase Free Play

(B) Decrease Free Play

If proper adjustment cannot be obtained or the clutch does not work correctly, visit your Honda dealer.

Other Checks:

Check the clutch cable for kinks or signs of wear that could cause sticking or failure. Lubricate the clutch cable with a commercially available cable lubricant to prevent premature wear and corrosion.

FUEL

Fuel Valve

The three way "Fuel Valve" (1) is on the left side below the fuel tank.

ON

With the fuel valve in the ON position, fuel will flow from the main fuel supply to the carburetor.

OFF

With the fuel valve in the OFF position, fuel cannot flow from the tank to the carburetor. Turn the valve to OFF position whenever the vehicle is not in use.


RES

With the fuel valve in this RES position, fuel will flow from the reserve fuel supply to the carburetor. Use the reserve fuel only when

the main supply is gone. Refill the tank as soon as possible after switching to RES.

The reserve fuel supply is:

1.5 L (0.39 US gal, 0.32 Imp gal)



(1) Fuel Valve


Remember to check that the fuel valve is in the ON position each time you refuel. If the valve is left in the RES position, you may run out of fuel with no reserve.

Fuel Tank

The fuel tank capacity including the reserve supply is:

12 Ltr. (3.17 US gal , 2.63 Imp gal)

To open the "Fuel Fill Cap" (1), insert the "Ignition Key" (2) and turn it clockwise. The fuel fill cap will pop up and can be lifted off. Do not overfill the tank. There should be no fuel in the "Filler Neck" (3).



- (1) Fuel Fill Cap
- (2) Ignition Key
- (3) Filler Neck

After re-fueling, to close the fuel fill cap, align the latch in the cap with the slot in the filler neck. Push the fuel fill cap into the filler neck until it snaps closed and locks. Remove the key.

WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Refuel only outdoors.
- Wipe up spills immediately.

Use unleaded petrol with a research octane number of 90 or higher.

The use of leaded petrol will cause premature damage to the catalytic converter.

NOTICE

If "spark knock" or "pinking" occurs at a steady engine speed under normal load, change brands of petrol. If spark knock or pinking persists, consult your Honda dealer. Failure to do so is considered misuse, and damage caused by misuse is not covered by Honda's Limited Warranty.

Petrol Containing Alcohol

If you decide to use a petrol containing alcohol (gasohol), be sure it's octane rating is at least as high as that recommended by Honda.

- When certain types of petrol containing alcohol are used, problems such as hard starting, poor performance, etc. may occur.
- If you notice any undesirable operating symptoms while using a petrol that contains alcohol, or one that you think contains alcohol, try another station or switch to another brand of petrol.
- When a problem resulting from the use of petrol containing alcohol occurs, contact your Honda dealer.


WARNING

Adulterated fuel not to be used. It causes damage to the engine parts and considered as misuse, damage caused by misuse is not covered under Honda warranty.

EVAPORATIVE EMISSION CONTROL SYSTEM

This vehicle is equipped with evaporative emission (EVAP) canister, which is designed to keep gasoline from evaporating into the atmosphere. Rather than venting a gas tank to the atmosphere.

If the problem occurs, contact your Honda dealer.




ENGINE OIL

Engine Oil Level Check

Check the engine oil level each day before riding the vehicle.

The level must be maintained between the "Upper" (1) and "Lower" (2) level marks on the "Oil Filler Cap/Dipstick" (3).



- (1) Upper Level Mark
- (2) Lower Level Mark
- (3) Oil Filler Cap/Dipstick

1. Start the engine and let it idle for 3-5 minutes.
2. Stop the engine and put the vehicle on its center stand on level ground.
3. After 2-3 minutes, remove the oil filler cap/dipstick, wipe it clean, and reinsert the oil filler cap/dipstick without screwing it in. Remove the oil filler cap/ dipstick. The oil level should be between the upper and lower marks on the oil filler cap/dipstick.
4. If required, add the specified oil (see page 44) up to the upper level mark. Do not overfill.
5. Reinstall the oil filler cap/dipstick. Check for oil leaks.

NOTICE

Running the engine with insufficient oil quantity may cause serious engine damage.

TYRES

To safely operate your vehicle, your tyres must be of proper type and size, in good condition with adequate tread, and correctly inflated for the load you are carrying. The following pages give more detailed information on how and when to check your air pressure, how to inspect your tyres for damage, and what to do when your tyres need to be repaired or replaced.

WARNING

Using tyres that are excessively worn or improperly inflated can cause an accident in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tyre inflation and maintenance.

Air Pressure

Keeping your tyres properly inflated provides the best combination of handling, tread life and riding comfort. Generally,

under inflated tyres wear unevenly, adversely affect handling, and are more likely to fail from being overheated.

Over inflated tyres make your vehicle ride more harsh, are more prone to damage from road hazards, and wear unevenly.

We recommend that you visually check your tyres before every ride and use a gauge to measure air pressure at least once a month or any time you think the tyres might be low.

Always check air pressure when your tyres are "cold" when the vehicle has been parked for at least three hours. If you check air pressure when your tyres are "warm" when the vehicle has been ridden for even a few miles the readings will be higher than if the tyres were "cold". This is normal, so do not let air out of the tyres to match the recommended cold air pressures given below. If you do, the tyres will be under inflated.

The recommended “cold” tyre pressures are:

kPa (kgf/cm , psi)		
Driver Only	Front	175 (1.75 , 25)
	Rear	175 (1.75 , 25)
Driver and one pillion rider	Front	175 (1.75 , 25)
	Rear	200 (2.00 , 29)

This vehicle is fitted with tubeless tyre in both wheels. Compared with ordinary tube tyre, the tubeless tyre releases slow air leak when punctured by a nail or other similar object. For this reason, even though they remain fully inflated, it is important to regularly check the tyre for embedded objects.

Inspection

Whenever you check the tyre pressures, you should also examine the tyre treads and side walls for wear, damage, and foreign objects:

Look for:

- Bumps or bulges on the side of the tyre tread. Replace the tyre if you find any bumps or bulges.


- Cuts, splits or cracks in the tyre. Replace the tyre if you can see fabric or cord.
- Excessive tread wear.

Also, if you hit a pothole or hard object, pull to the side of the road as soon as you safely can and carefully inspect the tyres for damage.

Tread Wear

Replace tyres before tread depth at the center of the tyre reaches the following limit:

Minimum tread depth	
Front:	1.5 mm (0.06 in)
Rear	2.0 mm (0.08 in)



- (1) Wear Indicator
(2) Wear Indicator Location Mark

Tyre Repair

If a tubeless tyre is punctured or damaged, Please visit nearest tyre manufacture dealer and follow his recommendation for repair or replacement.

CAUTION

Repair/Replacement of tubeless tyre by unauthorized person may render the tyre useless or tyre can fail while driving.

Tyre Replacement

The tyres that came on your vehicle were designed to match the performance capabilities of your vehicle and provide the best combination of handling, braking, durability and comfort.

WARNING

Using tyres that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed. Follow all instructions in this owner's manual regarding tyre inflation and maintenance.

The recommended tyres for your vehicle are:

Front: 100/80-17M/C 52S


Rear: 140/70-17M/C 66S

Whenever you replace a tyre, use one that is equivalent to the original and be sure the wheel is balanced after the new tyre is installed.

ESSENTIAL INDIVIDUAL COMPONENTS

IGNITION SWITCH

The "Ignition Switch" (1) is below the speedometer.



(1) Ignition Switch

Key Position	Function	Key Removal
LOCK (steering lock)	Steering is Locked. Engine and lights cannot be operated.	Key can be removed
OFF	Engine and lights cannot be operated.	Key can be removed
ON	Engine can be operated Turn signal, passing light control switch, horn and hazard switch can be operated. Position light, meter light and tail light will glow. Headlight glow only when the engine is running	Key cannot be removed

RIGHT HANDLEBAR CONTROL

Starter Button


The "Starter Button" (1) is next to the throttle grip.

When the starter button is pressed the starter motor cranks the engine. See page 34 for the starting procedure.

Hazard Switch

The "Hazard Switch" (2) is above the starter button.

- The hazard switch will activate all turn signals at the same time.
- The hazard lights indicate to other drivers around you that you are in trouble or having problems with your vehicle.



(1) Starter Button

(2) Hazard Switch

LEFT HANDLEBAR CONTROLS



NOTICE

Automatic Headlamp ON (AHO Compliance):-

This means that the Headlamp will get ON as soon as the engine is started.

There is no switch to turn OFF the Headlamp while riding. "Automatic Headlamp ON" feature of your vehicle helps other to recognize your vehicle position in foggy/dusty environment condition.

Headlight Dimmer Switch (1)

Push the dimmer switch to  (HI) to select high beam or to  (LO) to select low beam.

Passing Light Switch (2)


When this switch is pressed, the headlight flashes on to signal approaching vehicles or when passing.

Turn Signal Switch (3)

Move to  (L) to signal a left turn,  (R) to signal a right turn. Press to turn signal OFF.

Horn Button (4)

Press the button to sound the horn.



- (1) Headlight Dimmer Switch
- (2) Passing Light Switch
- (3) Turn Signal Switch
- (4) Horn Button


FEATURES

(Not required for operation)

STEERING LOCK

To lock the steering, turn the handlebar all the way to the left or right, turn the "Ignition Key" (1) to LOCK while pushing in. Remove the key. To unlock the steering, turn the key to OFF.

Do not turn the key to LOCK while riding the vehicle, this may result in loss of vehicle control.



- (1) Ignition Key
- (A) Push in
- (B) Turn to LOCK
- (C) Turn to OFF

SEAT

The "Seat" (1) must be removed for air cleaner inspection, to remove the right & left side cover or to access the tool kit, first aid kit and owner's manual.


Removal:

1. Insert the "Ignition Key" (2) into the "Seat Lock" (3) and turn it clockwise.

Installation:

1. Align the "Front Prongs" (4) under the front of the seat with the "Recess" (5) under the frame cross member, and locating the "Rear Prongs" (6) on the bottom of the seat with the "Hooks" (7) on the frame.
2. Slide the seat into position and push down on the rear of the seat.

Be sure the seat is locked securely in position after installation.




- (1) Seat
- (2) Ignition Key
- (3) Seat Lock
- (4) Front Prongs
- (5) Recess
- (6) Rear Prongs
- (7) Hooks

HEADLIGHT AIM VERTICAL ADJUSTMENT

"Headlight Aim Adjuster" (1) is provided at back side of headlight. Vertical adjustment can be made by rotating it clockwise or anticlockwise as necessary with the help of "Screwdriver" (2). Visit your Honda dealer for aim adjustment.

(Obey local laws and regulations.)



(1) Headlight Aim Adjuster

(2) Screwdriver

(A) Clockwise

(B) Anticlockwise

LEFT SIDE COVER


The left side cover must be removed for battery & fuse maintenance.

Removal:

1. Remove the left side cover "Pan Screw" (1) and "Trim Clips" (2).
2. Remove 3 side cover "Bosses" (3) from the "Grommets" (4).
3. Slide "Left Side Cover" (5) backward and remove it carefully from "Slots" (6).

Installation:

- Installation can be done in the reverse order of removal.




- (1) Pan Screw
- (2) Trim Clips
- (3) Bosses
- (4) Grommets
- (5) Left Side Cover
- (6) Slots

DOCUMENT BAG

The "Documents Bag" (1) is in the "Document Compartment" (2) on the reverse side of the "Seat" (3).

The owner's manual and other documents should be stored in the document bag.

When washing your vehicle, be careful not to flood this area with water.



- (1) Document Bag
- (2) Document Compartment
- (3) Seat


STORAGE COMPARTMENT & FIRST AID KIT

The "Storage Compartment" (1) is located under the seat (page 29) . This compartment is for light weight items.

This vehicle comes with a "First Aid Kit" (2) which should be stored in this compartment.

A special marking is also given on the rear fender for the "First Aid Kit".

When washing your vehicle, be careful not to flood this area with water.



- (1) Storage Compartment
(2) First Aid Kit

OPERATION

PRE-RIDE INSPECTION

For your safety, it is very important to take a few moments before each ride to walk around your vehicle and check its condition. If you detect any problem, be sure you take care of it, or have it corrected by your Honda dealer.

WARNING

Improperly maintaining this vehicle or failing to correct a problem before riding can cause a crash in which you can be seriously hurt or killed.

Always perform a pre-ride inspection before every ride and correct any problems.

1. Engine oil level - add engine oil if required (page 22). Check for leaks.
2. Fuel level - fill fuel tank when necessary (page 19). Check for leaks.
3. Front and Rear brakes - check operation; Front: make sure there is no brake fluid leakage (pages 15).

Rear (Drum): adjust free play if necessary (pages 16).

Rear (Disc): make sure there is no brake fluid leakage (pages 17).

4. Tyres - check condition and pressure (pages 23-25).
5. Drive chain - check condition and slack (page 51). Adjust and lubricate if necessary.
6. Throttle - check for smooth opening and full closing in all steering positions.
7. Clutch - check operation, and adjust if necessary (pages 18-19).
8. Lights and horn - check that turn signals, indicators and horn function properly.

STARTING THE ENGINE

Always follow the proper starting procedure described below.

This vehicle can be started with the transmission in gear by disengaging the clutch before operating the electric starter.

Fold the front right side footrest before operating kickstarter.

To protect the catalytic converter in your vehicle's exhaust system, avoid extending idling and the use of leaded petrol.

Your vehicle's exhaust contains poisonous carbon monoxide gas. High levels of carbon monoxide can collect rapidly in enclosed areas such as a garage. Do not run the engine with the garage door closed. Even with the door open, run the engine only long enough to move your vehicle out of the garage.

Do not operate the kickstarter pedal while the engine is running as engine damage could result. Do not apply excessive force on the kickstarter pedal.

Fold up the kickstarter pedal after the kickstarter is returned to the pedal stop and unfold footrest.

Do not use the electric starter for more than 5 second at a time. Release the starter button for approximately 10 seconds before pressing it again.

Preparation

Before starting, insert the key, turn the ignition switch ON and confirm the following:

- The transmission is in NEUTRAL (neutral indicator light ON).
- The fuel valve is ON.
- The ABS indicator is ON. (for ABS).

The ABS indicator should go off after you ride the vehicle at a speed above 10 km/h (6 mph).


Starting Procedure

To restart a warm engine follow the procedure for High Air Temperature.

Normal Air Temperature (10°C to 35°C):

1. Pull the "Choke Knob" (1) out all the way to "Fully ON" (A).
2. **a <Using the electric starter>**
With the throttle closed, press the starter button.
- b <Using the kickstarter pedal>**
Fold the front footrest and lightly depress the kickstarter until resistance is felt. Then let the kickstarter return to the top of its stroke.
With the throttle closed, operate the kickstarter.
Kick from the top of the stroke through to the bottom with a rapid, continuous motion
3. Immediately after the engine starts operate the choke knob to keep fast idle.

4. About 15 seconds after the engine starts push the choke knob in all the way to "Fully OFF" (B). If idling is unstable, Open the throttle slightly.



- (1) Choke Knob
(A) Fully ON
(B) Fully OFF

High Air Temperature (35°C or Above):

1. Do not use the choke.
2. **a <Using the electric starter>**
With the throttle slightly open press the starter button.
- b <Using the kickstarter pedal>**
Fold the front footrest and lightly depress the kickstarter until resistance is felt. Then let the kickstarter return to the top of its stroke.
With the throttle closed, operate the kickstarter.
Kick from the top of the stroke through to the bottom with a rapid, continuous motion

Low Air Temperature (10°C or below):

1. Follow **Step 1 & 2** from "Normal Air Temperature" starting procedure.
2. When engine speed begins to pickup operate the choke knob to keep fast idle.
3. Continue warming up the engine until it runs smoothly and responds to the throttle when the choke knob is at fully OFF (B).

Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel.

(Use the start button)

To clear a flooded engine, turn the ignition switch to ON, and move the choke knob to fully OFF (B). Open the throttle fully and crank the engine for 5 seconds. If the engine starts, quickly close the throttle, then open it slightly if idling is unstable. If the engine does not start, Wait for 10 seconds, then follow the starting procedure.

(Use the kickstarter)

To clear a flooded engine, turn OFF the ignition switch and move the choke knob

to fully OFF (B). Open the throttle fully and crank the engine several times with the kickstarter. Turn the ignition switch to ON and open the throttle slightly; start the engine using the kickstarter.

RUNNING-IN

Help assure your vehicle's future reliability and performance by paying extra attention to how you ride during the first 500 km (300 miles).

During this period, avoid full-throttle starts and rapid acceleration.


RIDING

Review Vehicle Safety (page 3-7) before you ride.

Make sure the side stand is fully retracted before riding the vehicle. If the stand is extended, it may interfere with control during a left turn.

1. After the engine has been warmed up, the vehicle is ready for riding.
2. While the engine is idling, pull in the clutch lever and depress the gearshift pedal to shift into 1st (low) gear.

3. Slowly release the clutch lever and at the same time gradually increase engine speed by opening the throttle. Coordination of the throttle and clutch lever will assure a smooth positive start.
4. When the vehicle attains a moderate speed, close the throttle, pull in the clutch lever and shift to 2nd gear by raising the gearshift pedal.
5. Coordinate the throttle and brakes for smooth deceleration.
6. Both front and rear brakes should be used at the same time and should not be applied strongly enough to lock the wheel, or braking effectiveness will be reduced and control of the vehicle be difficult.



BRAKING

Your vehicle is equipped with a hydraulically activated disc brake in front and mechanically/hydraulically operated rear brakes. Operating the brake lever applies the front brake. Depressing the brake pedal applies the rear brake.

For normal braking, apply both the brake pedal and lever while down-shifting to match your road speed. For maximum braking, close the throttle and firmly apply the pedal and lever; pull in the clutch lever before coming to a complete stop to prevent stalling the engine.

(For CBS)

Both brakes can be applied with the help of rear brake pedal only. However, for more effective braking, it is advised to apply both front and rear brake simultaneously

Anti-Lock Brake System (ABS)



This vehicle is equipped with 1 Channel ABS. For full braking effectiveness, use brake lever and pedal simultaneously.

Anti-lock Brake System (ABS) designed to prevent the front brake from locking up during hard braking.

- **There is no ABS function to the rear wheel.**
- ABS does not reduce braking distance. In certain circumstances, ABS may result in a longer stopping distance.
- ABS does not function at speeds below 10 km/h (6 mph).
- The front brake lever may recoil slightly when applying the brakes. This is normal.
- Always use the recommended front/rear tyres and sprockets to ensure correct ABS operation.

Important Safety Reminders:

- Independent operation of only the brake lever or brake pedal reduces stopping performance.
- Extreme application of the brake controls may cause wheel lock, reducing control of the vehicle.
- When possible, reduce speed or brake before entering a turn; closing the throttle or braking in mid-turn may cause wheel slip. Wheel slip will reduce control of the vehicle.
- When riding in wet or rainy conditions, or on loose surfaces, the ability to manoeuvre and stop will be reduced. All of your actions should be smooth under these conditions. Rapid acceleration, braking or turning may cause loss of control. For your safety, exercise extreme caution when braking, accelerating or turning.

- When descending a long, steep grade, use engine compression braking by downshifting, with intermittent use of both brakes.
- Continuous brake application can overheat the brakes and reduce their effectiveness.
- Riding with your foot resting on the brake pedal or your hand on the brake lever may actuate the brakelight, giving a false indication to other drivers. It may also overheat the brakes, reducing effectiveness.

PARKING

1. After stopping the vehicle, shift the gear into neutral, turn the fuel valve OFF, turn the handlebar fully to the left/right, turn the ignition switch OFF, LOCK the handlebar and remove the key.
2. Use the center stand to support the vehicle while parked..

Park the vehicle on firm, level ground to prevent it from falling over. If you must park on a slight incline, aim the front of the vehicle uphill to reduce the possibility of rolling off the center stand or overturning.

3. Lock the steering (page 28) to help prevent theft.

Make sure flammable materials such as dry grass or leaves do not come in contact with the exhaust system when parking your vehicle.

MAINTENANCE

THE IMPORTANCE OF MAINTENANCE

A well-maintained vehicle is essential for safe, economical and trouble-free riding. It will also help reduce air pollution.

To help you properly care for your vehicle, the following pages include a Maintenance Schedule and a maintenance Record for regularly scheduled maintenance.

These instructions are based on the assumption that the vehicle will be used exclusively for its designed purpose. Sustained high speed operation or operation in unusually wet or dusty conditions will require more frequent service than specified in the Maintenance Schedule. Consult your Honda dealer for recommendations applicable to your individual needs and use. If your vehicle overturns or becomes involved in a crash, be sure your Honda dealer inspects all major parts, even if you are able to make some repairs.

WARNING

Improperly maintaining this vehicle or failing to correct a problem before you ride can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

MAINTENANCE SAFETY

This section includes instructions on some important maintenance tasks. You can perform some of these tasks with the tools provided- if you have basic mechanical skills.

Other tasks that are more difficult and require special tools are best performed by professionals. Wheel removal should normally be handled only by a Honda technician or other qualified mechanic; instructions are included in this manual only to assist in emergency service.

Some of the most important safety precautions follow. However, we cannot

warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

SAFETY PRECAUTIONS

Make sure the engine is OFF before you begin any maintenance or repairs. This will help eliminate several potential hazards:

*** Carbon monoxide poisoning from engine exhaust.**

Be sure there is adequate ventilation whenever you operate the engine.

*** Burns from hot parts.**

Let the engine and exhaust system cool before touching.

*** Injury from moving parts.**

Do not run the engine unless instructed to do so.

- Read the instructions before you begin, and make sure you have the tools and skills required.
- To help prevent the vehicle from falling over, park it on a firm, level surface, using the center stand or a maintenance stand to provide support.
- To reduce the possibility of a fire or explosion, be careful when working around petrol or batteries. Use only nonflammable solvent, not petrol, to clean parts. Keep cigarettes, sparks and flames away from the battery and all fuel-related parts.

Remember that your Honda dealer knows your vehicle best and is fully equipped to maintain and repair it.

To ensure the best quality and reliability, use only new genuine Honda parts or their equivalents for repair and replacement.

MAINTENANCE SCHEDULE

Perform the pre-ride Inspection (Ref. page 32) at each scheduled maintenance period.

I: INSPECT, CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE.

The following Maintenance Schedule specifies all maintenance required to keep your vehicle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Honda by properly trained and equipped technicians. Your Honda dealer meets all of these requirements.

- * Should be serviced by your Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the Official Honda Shop Manual.
- ** In the interest of safety, we recommend these items be serviced only by your Honda dealer.

Honda recommends that your Honda dealer should road test your vehicle after each periodic maintenance is carried out.

- NOTES:
- (1) At higher odometer reading, repeat at the frequency interval established here.
 - (2) Service more frequently when riding in unusually wet or dusty areas.
 - (3) Service more frequently when riding in rain or at full throttle.
 - (4) Replacement requires mechanical skill.

FREQUENCY ITEM		NOTE	PRE-RIDE CHECK	ODOMETER READING (NOTE 1)												ANNUAL CHECK	REGULAR REPLACE	REFER TO PAGE
				X1000KM	1	6	12	18	24	30	36							
				X1000MI	0.6	4	8	12	16	20	24							
				MONTHS	1	6	12	18	24	30	36							
*	FUEL LINE					I	I	I	I	I	I	I			-			
	FUEL LEVEL		I												-			
*	FUEL STRAINER SCREEN					C	C	C	C	C	C				-			
*	THROTTLE OPERATION		I			I	I	I	I	I	I	I			49			
*	CHOKE OPERATION					I	I	I	I	I	I	I			34			
*	AIR CLEANER	NOTE (2)						R			R				50			
	CRANKCASE BREATHER	NOTE (3)				C	C	C	C	C	C				46			
	SPARK PLUG					I	R	I	R	I	R				47			
*	VALVE CLEARANCE					I	I	I	I	I	I				-			
	ENGINE OIL		I			R	R	R	R	R	R	R			44			
**	ENGINE OIL STRAINER SCREEN					C		C		C		C			-			
**	ENGINE OIL CENTRIFUGAL FILTER							C		C		C			-			
*	ENGINE IDLE SPEED					I	I	I	I	I	I	I			48			
*	SECONDARY AIR SUPPLY SYSTEM							I			I				-			
*	EVAPORATIVE EMISSION CONTROL							I			I				-			
	DRIVE CHAIN		I	EVERY 1000 km (600 mil)I, L												51		

The vehicle must be serviced at every 6000 kms or within 6 months whichever is earlier from the date of previous service. For NOTES refer page 41.

FREQUENCY ITEM		NOTE	PRE-RIDE CHECK	ODOMETER READING (NOTE 1)										
				X1000KM	1	6	12	18	24	30	36	ANNUAL CHECK	REGULAR REPLACE	REFER TO PAGE
				X1000MI	0.6	4	8	12	16	20	24			
				MONTHS	1	6	12	18	24	30	36			
*	BATTERY VOLTAGE		I		I	I	I	I	I	I	I			-
	BRAKE FLUID	NOTE (4)	I		I	I	I	I	I	I	I	2YEARS	15,17	
	BRAKE PADS WEAR (for Disc)		I		I	I	I	I	I	I	I		60-61	
	BRAKE SHOES/PADS WEAR (for Drum)		I		I	I	I	I	I	I	I		-	
	BRAKE SYSTEM (for Disc)			I	I	I	I	I	I	I	I		15-18	
	BRAKE SYSTEM (for Drum)		I	I	I	I	I	I	I	I	I		15-18	
	BRAKE LIGHT SWITCH				I	I	I	I	I	I	I		-	
	HEAD LIGHT AIM				I	I	I	I	I	I	I		30	
	LIGHTS/HORN		I		I	I	I	I	I	I	I		-	
	CLUTCH SYSTEM		I	I	I	I	I	I	I	I	I		18	
	SIDE STAND				I	I	I	I	I	I	I		57	
*	SUSPENSION				I	I	I	I	I	I	I		56	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	I		-	
**	WHEELS/TYRES		I		I	I	I	I	I	I	I		-	
**	STEERING HEAD BEARINGS					I		I		I	I		-	


The vehicle must be serviced at every 6000 kms or within 6 months whichever is earlier from the date of previous service. For NOTES refer page 41.

TOOL KIT

The "Tool Kit" (1) is in the storage compartment under the seat.

Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- Tool Bag
- Spanner 14x17
- Wrench spark plug
- Driver screw (No. 2 +/-)
- Wrench Hex 5 mm



(1) Tool Kit

COLOR CODE

The color table is attached below.
It is useful during ordering the replacement parts.

S.No.	Color	Color code
1.	Mat Axis Gray Metallic	NH-303M
2.	Sports Red	R-321
3.	Athletic Blue Metallic	PB-396M
4.	Dazzle Yellow Metallic	Y-230M


The above color code table helps in providing the correct color part as per your vehicle color.

ENGINE OIL

Refer to the Safety Precautions on page 40.
Good engine oil has many desirable qualities. Use only high detergent, quality motor oil certified on the container to meet or exceed requirements for API Service Classification MA

Viscosity:

Viscosity grade of engine oil should be based on average atmospheric temperature in your riding area. The following provides a guide to the selection of the proper grade or viscosity of oil to be used at various atmospheric temperatures.



Engine Oil

Engine oil quality is the chief factor affecting engine service life. Change the engine oil as specified in the maintenance schedule (page 42).

When running in very dusty conditions, oil changes should be performed more frequently than specified in the maintenance schedule.

Please dispose of used engine oil in a manner that is compatible with the environment. We suggest you take

it in a sealed container to your local recycling center or service station for reclamation. Do not throw it in the trash or pour it on the ground or down a drain.

Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

If a torque wrench is not used for this installation, visit your Honda dealer as soon as possible to verify proper torquing.

Change the engine oil with the engine at normal operating temperature and the vehicle on its center stand to assure complete and rapid draining.

1. To drain the oil, remove the oil filler cap/dipstick and "Oil Drain Bolt" (1) and "Sealing Washer" (2).
2. Operate the kickstarter several times to aid in complete draining of the remaining oil.
3. Check that the sealing washer on the drain bolt is in good condition and install the bolt. Replace the sealing washer


every other time the oil is changed, or each time if necessary.

Oil Drain Bolt Torque:

30 N·m (3.1 kgf·m , 22 lbf·ft)

4. Fill the crankcase with the recommended grade oil; approximately:

1.0 L (1.0 US qt , 0.9 Imp qt)



- (1) Oil Drain Bolt
(2) Sealing Washer


5. Install the oil filler cap/dipstick.
6. Start the engine and let it idle for 3-5 minutes.
7. 2-3 minutes after stopping the engine, check that the oil level is at the upper level mark on the oil filler cap/dipstick

with the vehicle upright on firm, level ground. Make sure there are no oil leaks.

CRANKCASE BREATHER

Refer to the Safety Precautions on page 40.

1. Remove the left side cover (page 30).
2. Remove the "Crankcase Breather Tube Plug" (1) from the tube and drain deposits into a suitable container.



- (1) Crankcase Breather Tube Plug

3. Reinstall the crankcase breather tube plug.

Service more frequently when riding in rain or at full throttle.

SPARK PLUG

Refer to the Safety Precautions on page 40.

Recommended plug:

Standard:

CPR8EA - 9 (NGK)


NOTICE

Never use a spark plug with an improper heat range. Severe engine damage could result.

1. Disconnect the "Spark Plug Cap" (1) from the spark plug.
2. Clean any dirt from around the spark plug base.

Remove the spark plug using the "Spark Plug Wrench" (2) furnished in the tool kit.

3. Inspect the electrodes and center porcelain for deposits, erosion or carbon fouling. If the erosion or deposit is heavy, replace the plug. Clean a wetfouled plug with a plug cleaner, otherwise use a wire brush.




- (1) Spark Plug Cap
(2) Spark Plug Wrench

4. Check the "Spark Plug Gap" (3) using a wire-type feeler gauge. If adjustment is necessary, bend the "Side Electrode" (4) carefully.

The gap should be:

0.8-0.9 mm(0.03-0.04 in)

5. With the plug washer attached, the spark plug in by hand to prevent cross-threading.



- (3) Spark Plug Gap
(4) Side Electrode

6. Tighten the spark plug as follows:
- Install the old plug if it is in good condition and tighten it $1/8$ turn after it seats.
 - If installing a new plug, tighten it twice to prevent loosening:
 - a) Tighten the plug $1/2$ turn after it seats.
 - b) Loosen the plug.
 - c) Tighten the plug again $1/8$ turn after it seats.

NOTICE

Improperly tightened spark plug can damage the engine. If a plug is too loose, a piston may be damaged. If a plug is too tight, the threads may be damaged.

7. Reinstall the spark plug cap.

IDLE SPEED

Refer to the Safety Precautions on page 40.

The engine must be at normal operating temperature for accurate idle speed adjustment. 10 minutes of stop-and-go riding is sufficient.


Do not attempt to compensate for faults in other systems by adjusting idle speed. Visit your Honda dealer for regularly scheduled carburetor adjustments.

1. Warm up the engine, and shift to neutral, and place the vehicle on its center stand.

2. Adjust idle speed with the "Throttle Stop Screw" (1).

Idle speed (In neutral):

1,400 \pm 100 min⁻¹ (rpm)



(1) Throttle Stop Screw

(A) Increase

(B) Decrease

THROTTLE OPERATION


Refer to the Safety Precautions on page 40.

1. Check for smooth rotation of the throttle grip from the fully open to the fully closed position at both full steering positions.
2. Measure the throttle grip free play at the throttle grip flange.

The standard free play should be approximately:

2-6 mm (0.08-0.24 in)

To adjust the freeplay, loosen the "Lock Nut" (1) and turn the "Adjuster" (2).



(1) Lock Nut



(2) Adjuster

AIR CLEANER

Refer to the Safety Precautions on page 40.

The air cleaner element should be replaced at regular intervals (Ref. page 42). Replace more frequently when riding in unusually wet or dusty areas.

1. Remove the seat (page 29).
2. Remove the "Screws" (1) and "Air Cleaner Cover" (2).
3. Take out the "Air Cleaner Element" (3) and replace.
4. Viscous type air filters should be replaced. Do not reuse it by cleaning.
5. If the filter element is cleaned using pressured air or any solvent, viscous oil will be lost and as the base element is coarse paper, dust may enter along with air which will damage the engine.




- (1) Screws
(2) Air Cleaner Cover
(3) Air Cleaner Element

6. Replace the air cleaner element if it is excessively dirty, torn or damaged. Use Honda genuine air cleaner element specified for your model. Using the wrong Honda air cleaner element or a non-Honda air cleaner element which is not of equivalent quality may cause premature engine wear or performance problem.
7. Install the removed parts in the reverse order of removal.

CAUTION

Do not use air, oil, water for cleaning of air cleaner element. Replacement should be done at regular intervals.



DRIVE CHAIN

Refer to the Safety Precautions on page 40.

This vehicle is equipped with seal type chain. The service life of the drive chain is dependent upon proper lubrication and adjustment. Poor maintenance can cause premature wear or damage to the drive chain and sprockets.


The drive chain should be checked and lubricated as part of the Pre-ride Inspection (page 32). Under severe usage, or when the vehicle is ridden in unusually dusty or muddy areas, more frequent maintenance will be necessary.

Inspection:

1. Turn the engine OFF, place the vehicle on its center stand, and shift the transmission into neutral.

2. Move the "Drive Chain" (1) up and down with your finger. Drive chain slack should be adjusted approximately to allow the following vertical movement by hand:

25-35 mm (0.98-1.38 in)




(1) Drive Chain

3. Rotate the rear wheel slightly and then stop to check the drive chain slackness again. Repeat this procedure several times at different positions. Drive chain slack should remain constant. If the chain is slack only in certain sections, some links are kinked and binding, kinking can be eliminated by lubrication.

4. Inspect the sprocket teeth for possible wear or damage. Replace if necessary.

Damaged sprocket
Teeth
Replace



Normal sprocket Teeth
Good

If the drive chain or sprockets are excessively worn or damaged, they should be replaced. Never use a new chain with worn sprockets; rapid chain wear will result.


Adjustment:

Drive chain slack should be checked and adjusted if necessary at every 1,000 km (600 miles). When operated at sustained high speeds or under conditions of frequent rapid acceleration, the chain may require more frequent adjustment.

If the drive chain requires adjustment, the procedure is as follows:

1. Place the vehicle on its center stand with the transmission in neutral and the ignition switch OFF.
2. Loosen the "Rear Axle Nut" (1)
3. Loosen the "Drive Chain Lock Nuts" (2).
4. Turn both "Drive Chain Adjusting Nuts" (3) an equal number of turns until the correct drive chain slack is obtained. Turn the adjusting nuts clockwise to tighten the chain, or counterclockwise to provide more slack.

Align the chain adjuster "Index Marks" (4) with the "Rear Edge of Adjusting Slots" (5) on both sides of the swingarm.



In case of Drum

In case of Disc

- (1) Rear Axle Nut
- (2) Drive Chain Lock Nuts
- (3) Drive Chain Adjusting Nuts
- (4) Index Marks
- (5) Rear Edge Of Adjusting Slot

If the drive chain slack is excessive when the rear axle is moved to the furthest limit of adjustment, the drive chain is worn and must be replaced.

5. Tighten the rear axle nut to:
88 N·m (8.9 kgf·m , 65 lbf·ft)
- If a torque wrench is not used for this installation, visit your Honda dealer as soon as possible to verify proper torquing.
6. Tighten the adjusting nuts lightly, then tighten the lock nuts by holding the adjusting nuts with a spanner.
 7. Recheck drive chain slack.
 8. Rear brake pedal free play (for Drum) is affected when repositioning the rear wheel to adjust drive chain slack. Check rear brake pedal free play and adjust as necessary (page 16.).

Cleaning and Lubrication:

This vehicle is equipped with seal type chain hence proper care needs to be taken during its cleaning and lubrication.

When the drive chain becomes dirty, it should be cleaned prior to lubrication as follows.

1. Turn the ignition switch OFF.
2. For drive chain cleaning use Honda recommended chain cleaner.

CAUTION

Do not use a steam cleaner, high pressure cleaner, wire brush, volatile solvent such as **gasoline (petrol)**, benzene and abrasive cleaner or a chain cleaner NOT designed specially for seal (O-ring) chains to clean the drive chain.


3. Adjust the drive chain (page 53) and rear brake pedal free play (for Drum). (page 16)

Lubricate every 1,000 km (600 miles) or sooner if chain appears dry.

Use any one of the following methods for lubricating drive chain:

- SAE 80 or 90 gear oil.
- Honda recommended drive chain cleaner and chain lube sprays.

Saturate each chain link joint so that the lubricant penetrates between the link plates, pins, bushings, seals and rollers.



Drive Chain Wear

Check the "Drive Chain Wear Indicator Label" (1) attached on the left swingarm.

If the "Index Marks" (2) of the "Drive Chain Adjuster" (3) reaches "Red Zone" (4) of the indicator label, replace the drive chain with a new one.


Drive chain must be replaced with new sprocket set.

Replacement chain:

L.G.B. R428NOR-132LE

NOTICE

For chain replacement visit your nearest Honda dealer.



- (1) Drive Chain Wear Indicator Label
- (2) Index Mark
- (3) Drive Chain Adjuster
- (4) Red Zone


DRIVE CHAIN SLIDER

Refer to the Safety Precautions on page 40.

Remove the left side cover (page 30)

Check the "Chain Slider" (1) for wear.

The chain slider must be replaced if it is worn to the "Wear Limit Cutout" (2). For replacement, visit your Honda dealer.



(1) Chain Slider

(2) Wear Limit Cutout

FRONT AND REAR SUSPENSION

INSPECTION

Refer to the Safety Precautions on page 40.


1. Check the front fork assembly by locking the front brake and pumping the fork up and down vigorously. Suspension action should be smooth and there must be no oil leakage.
2. Swingarm bearings should be checked by pushing hard against the side of the rear wheel while the vehicle is on the center stand. Free play indicates worn bearings.
3. Carefully inspect all front and rear suspension fasteners for tightness.

SIDE STAND

Refer to the Safety Precautions on page 40.

Check the "Side Stand Spring" (1) for damage and loss of tension, and the side stand assembly for freedom of movement.

If the side stand is squeaky or stiff, clean the pivot area and lubricate the pivot bolt with clean engine oil.



(1) Side Stand Spring

WHEEL REMOVAL


Refer to the Safety Precautions on page 40.

(For ABS only)

When removing and installing the wheel, be careful not to damage the wheel speed sensor and pulser ring.

Front Wheel Removal

1. Place the vehicle on its center stand.
2. Raise the front wheel off the ground by placing a support block under the engine.
3. Remove the "Front Axle Nut" (1).
4. Loosen the "Axle Pinch Bolt" (2)
5. Remove the "Front Axle Shaft" (3) and the wheel.



- (1) Front Axle Nut
- (2) Axle Pinch Bolt
- (3) Front Axle Shaft

Do not depress the brake lever when the wheel is off the vehicle. The caliper piston will be forced out of the cylinder with subsequent loss of brake fluid. If this occurs, servicing of the brake system will be necessary. Visit your Honda dealer for this service.

Installation Notes:

- Position the wheel between the fork legs and insert the front axle from right side, through the right fork leg and wheel hub.
- Tighten the front axle nut to the specified torque.

Front axle nut torque:

59 N·m (6.0 kgf·m , 43 lbf·ft)

- Tighten the axle pinch bolt on the left fork leg to the specified torque.

Axle pinch bolt torque:

22 N·m (2.2 kgf·m , 16 lbf·ft)

- After installing the wheel, apply the brake several times and then check if the wheel rotates freely. Recheck the wheel if the brake drags or if the wheel does not rotate freely.

If a torque wrench was not used for installation, visit your Honda dealer as soon as possible to verify proper torquing.


Improper torque may lead to loss of braking capacity.

Rear Wheel Removal

1. Place the vehicle on its center stand.

(for Disc)


- (i). Loosen the "Rear Axle Nut" (1).
- (ii). Remove the "Drive Chain Lock Nut" (2) and "Drive Chain Adjusting Nut" (3).
- (iii). Push the rear wheel forward and make the drive chain slack fully.



- (1) Rear Axle Nut
- (2) Drive Chain Lock Nut
- (3) Drive Chain Adjusting Nut


(for Drum)

- (i). Loosen the "Rear Axle Nut" (1).
- (ii). Remove the "Rear Brake Adjusting Nut" (2).
Disconnect the "Brake Rod" (3) from the "Brake Arm" (4).
- (iii). Loosen the "Drive Chain Lock Nut" (5) and "Drive Chain Adjusting Nut" (6).



- (1) Rear Axle Nut
- (2) Rear Brake Adjusting Nut
- (3) Brake Rod
- (4) Brake Arm
- (5) Drive Chain Lock Nut
- (6) Drive Chain Adjusting Nut

2. Remove the rear axle nut.
3. Remove the "Drive Chain" (1) from the driven sprocket by pushing the rear wheel forward.
4. Remove the "Rear Axle Shaft" (2), side collar and rear wheel from the swingarm.



- (1) Drive Chain
- (2) Rear Axle Shaft

Installation Notes:

To install the rear wheel, reverse the removal procedure.

Make sure that the slot on the swingarm is located in the lug in the brake caliper.

Tighten the rear axle nut to be specified torque:

Rear axle nut torque:

88 N·m (8.9 kgf·m , 65 lbf·ft)

When installing the wheel carefully fit the brake disc (for Disc) between the brake pads to avoid damaging the pads. Adjust the brake (for Drum).

After installing the wheel, apply the brake several times and then check if the wheel rotates freely. Recheck the wheel if the brake drags or if the wheel does not rotate freely.

If a torque wrench was not used for installation, visit your Honda dealer as soon as possible to verify proper torquing. Improper torque may lead to loss of braking capacity.

BRAKE PAD WEAR

Refer to the Safety Precautions on page 40.


Brake pad wear depends upon the severity of usage, the type of riding, and road conditions. (Generally, the pads will wear faster on wet and dirty roads.)

Inspect the pads at each regular maintenance interval (page 43).

Front Brake

Check the "Wear Indicator Grooves" (1) in each pad.

If either pad is worn to the bottom of the wear indicator grooves, replace both pads as a set. Visit your Honda dealer for this service.




(1) Wear Indicator Grooves

Rear Brake (for Disc)

Check the "Wear Indicator Grooves" (1) in each pad.

If either pad is worn to the wear indicator grooves, replace both pads as a set. Visit your Honda dealer for this service.




(1) Wear Indicator Grooves

BRAKE SHOE WEAR (for Drum)

Refer to the Safety Precautions on page 40. The rear brake is equipped with a brake wear indicator.

When the brake is applied, an "Arrow Mark" (1) attached to the "Brake Arm" (2) moves toward a "Reference Mark" (3) on the "Brake Panel" (4). If the arrow aligns with

the reference mark on full application of the brake, the brake shoes must be replaced. Visit your Honda dealer for this service.



- (1) Arrow Mark
- (2) Brake Arm
- (3) Reference Mark
- (4) Brake Panel

BATTERY

Refer to the safety precautions on page 40. It is not necessary to check the battery electrolyte level or add distilled water as the battery is a maintenance-free (sealed) type. If your battery seems weak and/or is leaking electrolyte (causing hard starting or other electrical troubles), contact your Honda dealer or battery manufacturer.

NOTICE

Your battery is maintenance-free type and can be permanently damaged if the cap strip is removed.



This symbol on the battery means that this product must not be treated as household waste.

NOTICE

Battery contains lead, which is a hazardous material and if improperly disposed, can be harmful to the environment and human health.

Always return the used maintenance-free battery to the Honda dealer.

⚠ WARNING

The battery gives off explosive hydrogen gas during normal operation.


A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.

Wear protective clothing and a face shield or have a skilled mechanic do the battery maintenance.

Keep children away from the battery.

Removal

1. Make sure the ignition switch is OFF.
2. Remove the left side cover (page 30).
3. Remove the "Bolt" (1) and open the "Battery Holder" (2).
4. Disconnect the "Negative (-) Terminal Lead" (3) from the battery, first.
5. Disconnect the "Positive (+) Terminal Lead" (4).
6. Pull out the "Battery" (5) from the battery box.



- (1) Bolt
(2) Battery Holder
(3) Negative (-) Terminal Lead
(4) Positive (+) Terminal Lead
(5) Battery

Installation


1. Reinstall in the reverse order of removal. Be sure to connect the positive (+) terminal first, then the negative (-) terminal.
2. Check all bolts and fasteners are secure.
3. Apply petroleum jelly on both terminals after connecting.

FUSE REPLACEMENT

Refer to the Safety Precautions on page 40. When frequent fuse failure occurs, it usually indicates a short circuit or an overload in the electrical system. Visit your Honda dealer for repair.

NOTICE

Never use a fuse with a different rating from that specified. Serious damage to the electrical system or a fire may result, causing a dangerous loss of lights or engine power.




Fuse Box:

The "Fuse Box" (1) is located behind the left side cover.

The specified fuse is: 15A & 10A

1. Remove the seat (page 29).
2. Remove the left side cover (page 30).
3. Open "Fuse Box Cover" (2).
4. Pull out the old fuse and install a new fuse. The "Spare Fuse" (3) is located near the tool kit.
5. Close the fuse box cover and install the left side cover & seat.




MAIN FUSE:

The "Main Fuse" (1) is located behind the left side cover.

The specified fuse is : 20A

1. Remove the left side cover (page 30).
2. Disconnect the "Wire Connector" (2) of the "Starter Magnetic Switch" (3).
3. Pull out the fuse. If fuse is blown, install a new fuse. "Spare Main Fuse" (4) is attached below the starter magnetic switch.
4. Install the left side cover and the seat.




- (1) Main Fuse
(2) Wire Connector
(3) Starter Magnetic Switch
(4) Spare Main Fuse

STOPLIGHT SWITCH ADJUSTMENT

Refer to the Safety Precautions on page 40.

Check the operation of the "Stoplight Switch" (1) at the right side behind the engine from time to time.

Adjustment is done by turning the "Adjusting Nut" (2). Turn the nut in the "Direction" (A) if the switch operates too late and in "Direction" (B) if the switch operates too soon.



- (1) Stoplight switch
(2) Adjusting nut

BULB REPLACEMENT

Refer to the Safety Precautions on page 40.

The light bulb becomes very hot while the light is ON, and remains hot for a while after it is turned OFF. Be sure to let it cool down before servicing.


Wear clean gloves while replacing the bulb.

If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol to prevent its early failure.

- Be sure to turn the ignition switch OFF when replacing the bulb.
- Do not use bulbs other than those specified.
- After installing a new bulb, check that the light operates properly.

LED Headlight



This vehicle is equipped with LED Headlight. If there is LED which is not turned ON, visit your nearest Honda dealer.



(1) Position Light (C)


(2) High Beam (B)

(3) Low Beam (A)


Switch Position	Light	Glow
Ignition ON	Position Light	C
	High Beam 	A, B & C
	Low Beam 	A & C

Headlight Characteristics

If dimmer switch is operated from "High" to "Low" within 3 seconds from ignition switch OFF, Low-beam will instantly flashes only one time.




If ignition switch is turned "ON" within 3 seconds after ignition switch "OFF" with dimmer switch is "High" position, Hi-beam indicator will instantly flashes one time.



Stop/Tail Light LED


1. "Stop/Tail Light" (1) is LED unit. If there is LED which is not turned ON, visit your Honda dealer for this service.



(1) Stop/Tail Light

Licence Plate Light Bulb


1. Remove the "Licence Plate Light Cover" (1) by removing the "Screws" (2).
2. Remove the "Bulb" (3) without turning.
3. Install a new bulb in the reverse order of removal.



- (1) Licence Plate Light Cover
(2) Screws
(3) Bulb

Front/Rear Turn Signal Bulb

1. Remove the "Turn Signal Lens" (1) by removing the "Screw" (2).
2. Slightly press the "Bulb" (3) and turn it counterclockwise.
3. Install a new bulb in the reverse order of removal.



- (1) Turn Signal Lens
(2) Screw
(3) Bulb

CLEANING

Clean your vehicle regularly to protect the surface finishes and inspect for damage, wear, and oil or brake fluid leakage.

Avoid cleaning products that are not specifically designed for vehicle or automobile surfaces.

They may contain harsh detergents or chemical solvents that could damage the metal, paint, and plastic on your vehicle.

If your vehicle is still warm from recent operation, give the engine and exhaust system time to cool off.

We recommend avoiding the use of high pressure water spray (typical in coin operated car washes).

NOTICE

High pressure water (or air) can damage certain parts of the vehicle.

Washing the Vehicle

1. Rinse the vehicle thoroughly with cool water to remove loose dirt.
2. Clean the vehicle with a sponge or soft cloth using cool water.

Avoid directing water to muffler outlets and electrical parts.

3. Clean the plastic parts using a cloth or sponge dampened with a solution of mild detergent and water. Rub the soiled area gently rinsing it frequently with fresh water.

Take care to keep brake fluid or chemical solvents off the vehicle.

They will damage the plastic and painted surfaces.

The inside of the headlight lens may be clouded immediately after washing the vehicle. Moisture condensation inside the headlight lens will disappear gradually by lighting the headlight in high beam. Run the engine while keeping the headlight on.

4. After cleaning, rinse the vehicle thoroughly with plenty of clean water. Strong detergent residue can corrode alloy parts.
5. Dry the vehicle, start the engine, and let it run for several minutes.
6. Test the brakes before riding the vehicle. Several applications may be necessary to restore normal braking performance.
7. Lubricate the drive chain immediately after washing and drying the vehicle.

Braking efficiency may be temporarily impaired immediately after washing the vehicle. Anticipate longer stopping distance to avoid a possible accident.

Finishing Touches

After washing your vehicle, consider using a commercially-available spray cleaner/polish or quality liquid or paste wax to finish the job. Use only a non abrasive polish or wax made specifically for vehicles or automobiles. Apply the polish or wax according to the instructions on the container.

If a surface on your vehicle is chipped or scratched, your Honda dealer has touch up paint to match your vehicle's color. Be sure to use your vehicle's color code (page 44) when you buy touch-up paint.

Removing Road Salt

The salt contained in the road surface freezing prevention medicine which a road was sprayed with in winter, and the seawater becomes the cause which rust occurs in.

Wash your vehicle by the following point after it runs through such a place.

1. Clean the vehicle using cool water (page 68).

Do not use warm water.

This worsens the effect of the salt.

2. Dry the vehicle and the surface of the metal is protected with the wax.

STORAGE GUIDE

Extended storage, such as for winter, requires that you take certain steps to reduce the effects of deterioration from non-use of the vehicle. In addition, necessary repairs should be made before storing the vehicle; otherwise, these repairs may be forgotten by the time the vehicle is removed from storage.

STORAGE

1. Change the engine oil.
2. Empty the fuel tank into an approved petrol container using a commercially available hand siphon or an equivalent method. Spray the inside of the tank with an aerosol rust-inhibiting oil.

Reinstall the fuel fill cap on the tank.

If storage will last more than one month, carburetor draining is very important, to assure proper performance after storage.

WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
 - Refuel only outdoors.
 - Wipe up spills immediately.
3. To prevent rusting in the cylinder, perform the following:
- Remove the spark plug cap from the spark plug. Using tape or string, secure the cap to any convenient plastic body part so that it is positioned away from the spark plug.
 - Remove the spark plug from the engine and store it in a safe place. Do not connect the spark plug to the spark plug cap.
 - Pour a table spoon (15-20 cm³) of clean engine oil into the cylinder and cover the spark plug hole with a piece of cloth.
 - Crank the engine several times to distribute the oil.
 - Reinstall the spark plug and spark plug cap.

4. Remove the battery. Store in an area protected from freezing temperatures and direct sunlight.
5. Wash and dry the vehicle. Wax all painted surfaces. Coat chrome with rust inhibiting oil.
6. Lubricate the drive chain (page 54).
7. Inflate the tyres to their recommended pressures. Place the vehicle on blocks to raise both tyres off the ground.
8. Cover the vehicle (don't use plastic or other coated materials) and store in an unheated area, free of dampness with a minimum of daily temperature variation. Do not store the vehicle in direct sunlight.

REMOVAL FROM STORAGE

1. Uncover and clean the vehicle.
2. Change engine oil if more than 4 months have passed since the start of storage.
3. Check the battery voltage and charge the battery as required. Install the battery.
4. Drain any excess aerosol rust-inhibiting oil from the fuel tank. Fill the fuel tank with fresh petrol.
5. Perform all Pre-ride Inspection (page 32). Test ride the vehicle at low speeds in a safe riding area away from traffic.

SPECIFICATIONS

DIMENSIONS

Overall length -----	2041 mm (80.4 in)
Overall width -----	783 mm (30.8 in)
Overall height -----	1,091 mm (43.0 in)
Wheel base -----	1,346 mm (53.0 in)

WEIGHT

Dry weight	Non ABS & CBS Model-- 129 kg (284.4 lbs)
	ABS & CBS Model----- 131 kg (288.8 lbs)

CAPACITIES

Engine oil	After draining ----- 1.0 L (1.0 US qt, 0.9 Imp qt)
	After disassembly ----- 1.2 L (1.3 US qt, 1.1 Imp qt)
Fuel tank -----	12.0 L (3.17 US gal, 2.63 Imp gal)
Fuel tank reserve -----	1.5 L (0.39 US gal, 0.32 Imp gal)
Passenger capacity -----	Operator and one pillion rider
Maximum weight capacity -----	170 Kg (374.8 lbs)

ENGINE

Bore and stroke -----	57.30 x 63.096 mm (2.26x2.48 in)
Compression ratio -----	10:1
Displacement-----	162.71 cm ³ (9.93 cu-in)
Spark plug-----	Standard ----- CPR8EA-9 (NGK)
Spark plug gap-----	0.8-0.9 mm (0.03-0.04 in)
Idle speed -----	1,400 ± 100 min ⁻¹ (rpm)
Valve clearance (Cold)	Intake ----- 0.08 mm (0.003 in)
	Exhaust ----- 0.24 mm (0.009 in)

CHASSIS AND SUSPENSION

Caster angle-----	25°30'
Trail length -----	100 mm (3.9 in)
Tyre size, front -----	100/80-17M/C 52S
Tyre size, rear-----	140/70-17 M/C 66S

POWER TRANSMISSION

Primary reduction-----	3.136
Gear ratio, 1st-----	3.076
2nd -----	1.789
3rd-----	1.300
4th-----	1.066
5th-----	0.916
Final reduction -----	3.133

ELECTRICAL

Battery -----	12V-4Ah
Generator -----	0.14 kW/5,000 min ⁻¹ (rpm)

LIGHTS

Head light -----	LED
Position light -----	LED
Stop/tail light -----	LED
License plate lamp -----	12V-5W
Turn signal light-----	12V-10W x 4
Instrument lights -----	LED
Neutral, Turn signal & High beam indicator --	LED

FUSE

Main fuse -----	20A
Sub fuse-----	15A & 10A

Warranty Policy

Honda Motorcycle & Scooter India (Pvt.) Ltd. (HMSI) gives the following warranty in respect of vehicle **"CB Hornet 160R"** manufactured by them.

Proper care and precaution has been taken to ensure the best quality in respect of the material and workmanship in manufacturing **"CB Hornet 160R"**.

HMSI would repair or replace at its discretion, those part(s) found to have manufacturing defects during examination. This repair or replacement of part(s) would be done free of charge at their authorised workshop, within a warranty period of 24 months from the date of sale or until the vehicle has covered 32000 kms, whichever comes first.

Warranty claims in respect of proprietary parts like tyres and battery are warranted by their respective manufacturers and should be claimed on them directly by customer.

NOTE: Battery Warranty is applicable from 21 months from Date Of Charging at manufacturer or 18 Months from the Date Of Sale or 20000 Kms whichever is earlier.

In all such cases the decision of the respective manufacturer will be final and binding.

HMSI shall not be liable in any manner to replace them though their dealers will give full assistance in preferring such claims on their manufacturers.

HMSI undertake no liability in the matter of consequential loss or damage caused due to the failure of the parts. Delay, if any, at the repairing workshop in carrying out repair to vehicle shall not be a ground for extending the warranty period nor shall it give any right to the customer for claiming any compensation for damages.

HMSI reserves the right either to repair or replace the defective part.

Where a defective part can be replaced by part/s of alternative brand/s, which are normally used by HMSI in the course of manufacturing, HMSI reserves the right to carry out the replacement by a part or parts of any such alternative brands.

Valid in India only

This warranty and any claim arising there from is subject to Gurgaon jurisdiction only.

No claim for exchange or repair can be consider unless the customer:

- a. Ensures that immediately upon discovery of the defect, he approaches any nearest authorised dealer of HMSI with the concerned vehicle and enables him to remove and dispatch the part/parts attributing to manufacturing defect to the company.
 - b. Produces Owner's Manual in original, to enable that dealer to verify the details. It must be expressly understood that claims forwarded directly to us by the Owner/customer will not be entertained at all and such defective part/parts thus forwarded by them will lie at our factory at their own risk, and this warranty shall not be enforceable.
- case of misalignment and bent), Bushes, Fasteners, Shims, Washers and Electrical Items like Bulbs(LEDs are covered under warranty), Rubber and Plastic Components like Grommets, O-Rings, Bellows as well as Packings, Gaskets, Oil Seals and Consumable like Fuel Filter, Air Cleaner Element, Engine Oil, Grease, Suspension Oil and other items as specified by HMSI.
 4. Fasteners and clips which needs replacement during maintenance/service will not be covered under warranty.
 5. If there is any damage to the painted surface due to industrial pollution or other extraneous factors.

Further this warranty is not applicable to:

1. Any **"CB Hornet 160R"** on which any free and paid services has not been carried out, as per schedule given in Owner's Manual.
2. Normal maintenance operations like valve adjustment, cleaning of fuel system, engine tune-up or such other adjustments.
3. HMSI does not warrant normal wear and tear items like brake pad, brake shoes, Clutch Disc, Chain, Chain Sprocket, Wheel Rim (in
6. Any damage resulting from unavoidable natural disaster i.e fire collision, earthquake, flood etc.
7. Any damage caused by exposure of the product to soot and smoke, chemical agents, bird-droppings, sea water, sea breeze, or other environmental phenomenon.
8. If there is any damage caused due to usage of improper oil/grease, non genuine parts.

9. For two-wheelers, which have been used for any commercial purposes as taxi etc.
10. For maintenance repairs required due to misuse while driving or due to adulteration of oil, petrol or due to bad road conditions.
11. Recommended fuel quality not used.
12. Parts of the vehicle that have been subjected to misuse, accident, negligent treatment or which have been used in conjunction with parts and an equipment not manufactured or recommended for use by HMSI if in the sole judgment of HMSI, such use prematurely affects the performance and reliability of the vehicle.
13. Parts of the vehicle that have been altered or modified or replaced in unauthorised manner, and which in the sole judgment of HMSI affect its performance and reliability.
14. The vehicle that has not been serviced by HMSI authorised dealer as per the service schedule or which have not been operated or maintained in accordance with instructions mentioned in the Owner's Manual.
15. The vehicles used for any competition or race and/or for attempting to set up any kind of record HMSI reserves the right to make any

changes in design or to add any improvement on the vehicle at any time without incurring any obligations to install the same on a vehicle previously supplied and sold. Also the conditions of this warranty are subject to alteration without any notice.

This warranty is entirely written warranty given by HMSI for "**CB Hornet 160R**" and no other person, including the dealer or its or his agent or employee is authorised to extend or enlarge this warranty.

This warranty is given in lieu of and excludes every condition or warranty whether statutory or otherwise not herein expressly set out.

EMISSION WARRANTY

Subject to other terms of the warranty policy and other conditions and obligations laid down hereunder, the manufacturer certifies that the components liable to affect the emission of the gaseous pollutants in the vehicle in normal use despite the use to which it may be subjected, comply with provisions of rule 115(2) of the Central Motor Vehicle Rules, 1989 and further warrants that if on examination by a service center duly authorized by the manufacturer, the vehicle is discovered to be failing to meet the

Valid in India only

emission standard as specified in the said rule, the authorized service center shall take such corrective measures as may be necessary and shall at its sole discretion replace free of charge such components of emission control system as are specified in schedule.

A. Conditions

1. This warranty will be in addition to and run parallel to the product warranty given by the manufacturer and will apply to components as mentioned later. This warranty is applicable in Delhi, Mumbai, Kolkata and Chennai with effective from 1st July 2001. Other places when included will be covered under warranty accordingly.
2. The period of the vehicle's emission warranty will be determined starting from the date of the vehicle sale. The period of time and kilometers that are covered under the provisions of warranty may vary but should not be less than the minimum warranty period based on the vehicle category.

For a two-wheeler the emission warranty period is 30,000 kms or 3 years whichever is earlier.

3. Warranty claim for the components under Emission warranty will be admitted, for a prima facie examination, in the event of failure of the vehicle to meet the emission standard as specified in sub-rule (2) of Rule No 115 of the Central Motor vehicle Rules.
4. The warranty claim will be accepted only after the examinations carried out by Authorized Service Centers leads to a firm conclusion that none of the original settings have been tampered with and that the components has/ have a manufacturing defect, and/or, that the vehicle is unable to meet the in-use emission standard, in spite of the vehicle being maintained and used in accordance with the instructions in the owner's manual.
5. The methods of examination to determine the warrantable condition of the components will be at the sole discretion of manufacturers and or their Authorized service centers and results of such examination will be final and binding. If, on examination, a warrantable condition is not established, the manufacturers will have to charge all, or part, of the cost of such examination.

6. In case of a vehicle in which the components covered under Emission warranty, the manufacturer will replace, at Authorized centers free of charge, the components which are covered, but the consumables as mentioned in Owner's Manual shall be charged as per actuals.
7. In case of a vehicle in which the components covered under Emission warranty or the associated parts are not independently replaceable on account of their being integral parts of a complete assembly, the manufacturer will have the sole discretion to replace either the entire assembly or by using some of the parts of the system through suitable repairs or modifications.
8. Any consequential repairs or replacement of parts which may be found necessary to establish compliance to in-use emission standards, in addition to replacement of the parts covered under emission warranty, will not be made free of cost unless such parts are also found to be in a warrantable condition within the scope and limit of the product warranty. The consumables shall be charged as per actuals during such repairs or replacement of parts.
9. All the parts removed for replacement under warranty will be the property of the manufacturer.
10. The manufacturer will not be responsible for the cost of transportation of the vehicle to the nearest Authorized Service center or any loss due to non-availability of the vehicle during the period of lodging of a warranty claim and examination by the manufacturer and repairs.
11. The manufacturer will not be responsible for any penalties that may be charged by statutory authorities on account of failure to comply with the in use emission standards.
12. Emission warranty will be applicable irrespective of the change of ownership of the vehicle provided all the conditions as laid down in this document are met from the date of original sale of the vehicle.
13. The emission warranty will be applicable only if:
 - a. Observes all important instructions and any other precautions listed in the Owner's Manual for use of the vehicle.
 - b. Under all circumstances uses lubricants and fuel as recommended by manufacturer.

- c. Regularly obtains and carries out maintenance in accordance with the manufacturers guidelines and enters the details in the Logbook.
- d. Immediately approaches the nearest authorized service center upon discovery of failure to comply with the in use emission standards in spite of having maintained and used the vehicle in accordance with the instructions in the Owner's Manual and having carried out such repairs and adjustments as may be required with a view to establish such compliance.
- e. Produces the 'Pollution Under Control' certificate valid for the period immediately preceding the test during which the failure is discovered, the test having been carried out either for obtaining a new certificate, or pursuant upon being directed by an officer as referred to in sub-rule(2) of Rule 116 of the Central Motor Vehicle Rules.
- f. Produces the Owner's Manual and Log book for verification details.

- g. Produces receipts covering maintenance of the vehicle as specified in the Owner's Manual from the date of original purchase of the vehicle.
- h. Produces valid certificate of insurance and RTO registration.

14. Conditions under which warranty is not applicable:

A valid 'Pollution Under Control' certificate as described in customer obligation D(6) above is not produced.

A vehicle which is not serviced by Authorized service center as per the service schedule described in the maintenance chart given in the Owner's Manual.

A vehicle, which has been subjected to abnormal use, abuse, neglect and improper maintenance or has met with an accident. Use of replacement parts not specified and approved by the manufacturer.

A vehicle, or parts thereof, which has been altered, tampered with or modified or replaced in an unauthorized manner.

A vehicle on which the odometer is not functioning or the odometer has been changed/tampered with so that the actual mileage cannot be readily determined.

A vehicle which has been used for competitions, races, rallies or for the purpose of establishing records

Examination by the manufacturers or his Authorized Service Centers of the vehicle shows that any of the conditions stipulated in the Owner's Manual with regard to use and maintenance have been violated.

A vehicle, which has been run on, adulterated fuel, leaded fuel or lubricant or fuel/lubricants other than those specified by the manufacturer in the Owner's Manual with regard to use and maintenance have been violated.

SCOPE AND LIMITS

1. This emission warranty is in addition to product warranty and shall run parallel to the product warranty for the vehicle as per the scope and limit described in the Owner's Manual and all conditions described there in will apply in addition to those exclusively stipulated in this warranty.

2. The emission warranty covers only compliance with the emission standard as specified in the sub rule (2) of rule 115 of CMVR. It does not cover any other performance of these parts or routine test and consequent maintenance or adjustments to establish compliance to the in use emission standard as applicable to the state, in which the vehicle is registered and is in use.

The parts, which are covered under emission warranty, are carburetor and internal parts, intake manifold, distributor and internal parts, ignition coil, muffler etc.

NOTE: The emission warranty is applicable only when a customer enters into emission warranty contract.