

TAG DESCRIPTION
FOR FRONT PANEL


3 STATIONS

DATA LOGGER 1 BANK 1 & 2						BANK 3 & 4					
34902	DESCRIPTION	34902	DESCRIPTION	34902	DESCRIPTION	34902	DESCRIPTION	34902	DESCRIPTION	34902	DESCRIPTION
101	STATION 1 CUR.	201	STATION 17	301	STATION 1-3 240V	101	STATION 33	201	STATION 49	301	STATION 48-50 208V
102	STATION 2 CUR.	202	STATION 18	302	STATION 1-3 120V	102	STATION 34	202	STATION 50	302	STATION 48 208V SELECTED
103	STATION 3 CUR.	203	STATION 19	303	STATION 4-6 240V	103	STATION 35	203	STATION 51	303	STATION 51-53 240V
104	STATION 4	204	STATION 20	304	STATION 4-6 120V	104	STATION 36	204	STATION 52	304	STATION 51-53 208V
105	STATION 5	205	STATION 21	305	STATION 7-9 240V	105	STATION 37	205	STATION 53	305	STATION 51 208V SELECTED
106	STATION 6	206	STATION 22	306	STATION 7-9 120V	106	STATION 38	206	STATION 54	306	STATION 54-56 240V
107	STATION 7	207	STATION 23	307	STATION 10-12 240V	107	STATION 39	207	STATION 55	307	
108	STATION 8	208	STATION 24	308	STATION 10-12 120V	108	STATION 40	208	STATION 56	308	
109	STATION 9	209	STATION 25	309	STATION 13-14 240V	109	STATION 41	209	STATION 33-35 240V	309	
110	STATION 10	210	STATION 26	310	STATION 13-14 120V	110	STATION 42	210	STATION 36-38 240V	310	
111	STATION 11	211	STATION 27	311	STATION 15-17 240V	111	STATION 43	211	STATION 39-40 240V	311	
112	STATION 12	212	STATION 28	312	STATION 15-17 120V	112	STATION 44	212	STATION 42-44 240V	312	
113	STATION 13	213	STATION 29	313	STATION 18-20 240V	113	STATION 45	213	STATION 45-47 240V	313	
114	STATION 14	214	STATION 30	314	STATION 18-20 120V	114	STATION 46	214	STATION 45-47 208V	314	
115	STATION 15	215	STATION 31	315	STATION 21-23 240V	115	STATION 47	215	STATION 45 208V SELECTED	315	
116	STATION 16	216	STATION 32	316	STATION 24-26 240V	116	STATION 48	216	STATION 48-50 240V	316	

AGILENT 34972A - 7					
34902	DESCRIPTION	34902	DESCRIPTION	34902	DESCRIPTION
101	STATION 21 START	201	STATION 41 START	301	
102	STATION 22 START	202	STATION 42 START	302	
103	STATION 23 START	203	STATION 43 START	303	
104	STATION 24 START	204	STATION 44 START	304	
105	STATION 25 START	205	STATION 45 START	305	
106	STATION 26 START	206	STATION 46 START	306	
107	STATION 27 START	207	STATION 47 START	307	
108	STATION 28 START	208	STATION 48 START	308	
109	STATION 29 START	209	STATION 49 START	309	
110	STATION 30 START	210	STATION 50 START	310	
111	STATION 31 START	211	STATION 51 START	311	
112	STATION 32 START	212	STATION 52 START	312	
113	STATION 33 START	213	STATION 53 START	313	
114	STATION 34 START	214	STATION 54 START	314	
115	STATION 35 START	215	STATION 55 START	315	
116	STATION 36 START	216	STATION 56 START	316	
117	STATION 37 START	217		317	
118	STATION 38 START	218		318	
119	STATION 39 START	219		319	
120	STATION 40 START	220		320	

START AND STOP DRYER WITH AGILENT

AGILENT 34972A TERMINALS



SOLDER WIRES ACROSS START BUTTON
(DRYER SIDE)