


Generic Fanuc TT

Contents

Chapter 1: Working with .machine files	1
A: Installing your .machine file	2
B: Customizing your .machine file	3
Customizing operation defaults and tool libraries	5
Editing .machine file settings and defaults	7
Configuring the Code Expert editor.....	8
Configuring tool table output.....	10
Setting the toolpath directory and stream names	11
C: Working with machine licenses	14
Chapter 2: Working with tools and spindles	19
A: Setting up tools.....	20
B: Spindle control functions	25
C-axis clamp (M89/M189).....	26
Selecting the spindle winding range (M61, M62).....	28
Activating the M86 torque skip function	29
Using the spindle sync function (M128).....	31
Chapter 3: Working with toolpaths	33
A: Toolpath reference positions	34
Setting the start point and end point for an operation.....	35
Creating custom reference positions.....	39
Reference positions and reference points.....	42
B: Generic Fanuc TT machining modes	43
Polar (G12.1) and cylindrical (G7.1) interpolation.....	44
Balanced turning operations.....	47
Using coolant.....	51
Output expanded Mcode comments.....	53

revision date: April 15, 2016



Mill-Turn Application Guide—Generic Fanuc TT

Copyright © 2016 CNC Software, Inc.—All rights reserved

Terms of Use—Use of this document is subject to the Mastercam End User License Agreement.

A copy of the Mastercam End User License Agreement is included with the Mastercam product package.

The Mastercam End User License Agreement can also be found at: <http://www.mastercam.com/en-us/Company-Info/Legal/LicenseAgreement/>

Chapter I: Working with .machine files

The **.machine** file drives your entire Mill-Turn experience. A Mill-Turn **.machine** file is very different from the machine and control definition files that you might be familiar with from legacy Mastercam. This chapter gives you some basic information about working with **.machine** files. It includes the following topics:


- ❖ **Installing your .machine file**
- ❖ **Customizing operation defaults and tool libraries**
- ❖ **Editing .machine file settings and defaults**
- ❖ **Configuring the Code Expert editor**
- ❖ **Configuring tool table output**
- ❖ **Setting the toolpath directory and stream names**
- ❖ **Working with machine licenses**

This guide is designed to support Mastercam version X9 and 2017. There are no differences in the **.machine** file between the two versions that affect the content in this guide.

About this machine—The Generic Fanuc TT **.machine** file and post are designed to replicate a typical Fanuc control on a twin-turret mill-turn machine. It is intended to be used for:

- training purposes
- demonstrations
- working through the exercises in the *Getting Started with Mill-Turn* application guide.

IMPORTANT: This **.machine** file and post are designed to produce sample NC code only! Do **not** attempt to run ANY part program produced by this **.machine** file and post on an actual machine.



A: Installing your .machine file

Your **.machine** file is packaged in a .zip file. Simply unzip it to your desired location.

The default location for **.machine** files is the


\\shared Mcamx2017\\Mill Turn\\MACHINES

folder. However, you can place it anywhere you wish.


Unlike legacy Mastercam, the single **.machine** file includes all the resources that you need to support your Fanuc TT application. You do not need to worry about linking the **.machine** file to other files, like posts.

Running Mill-Turn from a network location—To work with your **.machine** file from a network location, simply copy it to the desired location on your network. Since the **.machine** file does not point to any other files, there is no difference between a network location or a local drive.

Note, however, that Mastercam will look for the **.machine** file every time you load a part that uses it, so it does need to be in a location that your workstation is regularly connected to.



Adding the .machine file to the menu—To make your **.machine** file available on the machine list in Mastercam, select **Machine > Mill-Turn > Manage list**. Then navigate to the folder with your **.machine** file and select it.



B: Customizing your .machine file

Whenever you load your **.machine** file in Mastercam to begin working on a Fanuc TT part, Mastercam also starts up the Code Expert and loads your **.machine** file in there as well. You can see the Code Expert icon appear on your task bar, right next to Mastercam.




When you switch to Code Expert and click on the Machine Explorer, you can see all the different components of your **.machine** file.

- The **Control Layers** section lists the resources used by the post. Most of these resources are hidden from you by the post/machine developer. However, the **Consumer** layer is designed specifically for machine defaults and other settings that you are allowed to edit. You will do this often in the other procedures in this book.
- The **Mastercam Files** section lists the support files that are encapsulated inside the your **.machine** file. Users of other Mastercam products are familiar with these files being stored in many locations throughout your Mastercam installation. In Mill-Turn, they are all brought together inside the **.machine** file.


They are grayed out because you cannot edit them in Code Expert. However, you can edit common files like your operation defaults, operation libraries, and tool libraries inside Mastercam. You just need to follow a slightly different workflow than you are used to. Follow the guidelines in the next section.

- Beginning in Mastercam 2017, you can access this application guide directly from Code Expert: just double-click the **.pdf** file under **Application Guide**.



Opening the Machine Explorer—Before you can work with the .machine file, the Machine Explorer needs to be visible.

Simply go to the **View** menu inside Code Expert and click the **Machine Explorer** button.



Customizing operation defaults and tool libraries




Load the .machine file in Mastercam to edit its component libraries.

In legacy Mastercam you are used to working with tool libraries and .defaults files by simply loading them from your hard disk. The workflow is a little different in Mill-Turn because in Mill-Turn, these files are stored inside the .machine file. Follow this general outline.


1. Start up Mastercam.
2. Load the desired .machine file or a part that uses the .machine file.
3. Use Mastercam's regular tools for editing these libraries:

- You can use the **Edit** buttons on the **Machine Group Properties > Files** tab.

- You can also use the controls in the **Toolpath parameters** page for any operation.



4. Save the changes in the locations that Mastercam prompts you with.
5. When you finish making changes, go back to Code Expert and look at the Machine Explorer. Any files that you changed should be marked “dirty” with an asterisk.
6. Press **[Ctrl+S]** in Code Expert to save the **.machine** file with your changes.



Editing .machine file settings and defaults

The .machine file includes a number of configurable settings and defaults, similar to the control definition in legacy Mastercam.

Although typically your .machine file will be supplied to you ready-to-use by your Reseller, it includes many settings that you can configure yourself according to your preferences and specific application needs. These include sequence and sync numbering, tool offset numbering, use of spaces in your NC file, job/shop info for your NC header, and so on.

Reach these settings by opening your .machine file in Code Expert and double-clicking the **Consumer** icon in the Machine Explorer.

Most of the settings are grouped into two categories:



- **Control Definition**
- **Output Settings**

Click the + signs to see the individual options. Some of these options (for example, sequence number settings) are very common or generic to most controls; others are very specific to individual machines. These settings serve a wide variety of functions:

- Mimicking the control definition settings in legacy Mastercam.
- Configuring toolpath modes and cycles.
- Setting default values for Sync Manager and toolpath options.

Most of these settings are self-explanatory and you can easily configure them to meet your needs by simply browsing the interface. The settings that are specific to this .machine file are described fully in this manual.


After making any changes, press **[Ctrl+S]** to save your .machine file.



Configuring the Code Expert editor


Several settings in your .machine file help configure the Code Expert editor.

There are several settings in the .machine file that you can use to configure the Code Expert editor. Access these options by opening the **Consumer** layer.




Opening in multi-stream view—You can use the Code Expert editor in either single-stream or multi-stream mode. Since the Fanuc TT NC output is typically divided into two streams, you may wish to open files in multi-stream view by default.

1. Go to the **Output Settings** category.
2. Open the **NC Output** group.
3. Select the **Open post output in Multi Stream view** option.



Configuring the Find Extents feature—The **Find Extents** feature in Code Expert scans your NC file and displays the minimum and maximum values for each letter address. By default, this is set to scan **X, Y, Z, C, S** and **F**. If you wish, you can edit the set of addresses that are scanned.

1. Go to the **NC Configuration** category.
2. Open the **Program** group.
3. Enter the desired letter addresses in the list, separated by semi-colons (;).




Start Page Control X

Category: NC Configuration

☒ **Program**

A semicolon separated string to specify address characters for "Find Extents" X;Y;Z;C;S;F;

For example, you can choose to add **I;J;K;** to the list. The next time you post, you will see them in the **Find Extents** table.



Text	Minimum	Maximum
S	200	5000
F	.005	20.
I	-.0405	.125
J	0.	.125
K	-.0324	.0156





Configuring tool table output

Use pre-defined strategies to get the tool table output you want.

As a user, you can configure your tool table output yourself without needing to do any programming or edits to your post. Your **.machine** file includes 12 different tool table strategies; simply select the desired one. Follow these steps.


1. Double-click the **Consumer** layer.
2. Go to the **Output Settings** category.
3. Open the **Tool table** group.
4. Select the desired strategy. Hover over each one to see a description.
5. Press **Ctrl+S** before posting to save your setting.



Setting the toolpath directory and stream names


Several common posting options from regular Mastercam are replaced by machine options in Mill-Turn.

If you are familiar with Mastercam, you are probably familiar with the **Toolpath directory** setting in the **Machine Group Properties**.




In Mill-Turn, this setting is not used. Instead, it is a property of the **.machine** file. To set it, follow these steps:

1. Open the **.machine** file in CodeExpert.
2. Make sure that the **Properties** window is displayed.





3. Click the machine name in the **Machine Explorer**.





4. Select the desired **NC Output Folder**. Mastercam will write your NC files for this machine to this folder.
5. You can also choose whether Mastercam will automatically overwrite NC files with the same name, or prompt you to enter a different name. Select the desired **Overwrite Mode** to control this.

This **Overwrite Mode** setting replaces the following setting from the **Posting** dialog box in regular Mastercam:



6. Mastercam Mill-Turn also lets you configure the names of the upper and lower streams. These will be automatically added to the NC file names for each stream. You can edit these names if you wish.



7. Save the .machine file when you are done.




C: Working with machine licenses

Before you can use this Mill-Turn machine, Mastercam requires that you have a license for it.

- If you are familiar with other Mastercam products, you are probably familiar with HASPs—a small device that plugs into your USB port that Mastercam uses to make sure that you are an authorized user.
- Licenses for Mill-Turn machines are different. Mastercam uses a product called CodeMeter to administer these licenses.

You can access CodeMeter from your System Tray to inspect or manage your Mill-Turn licenses.




Verifying that you have the proper license

Beginning with X8, a specific license is required for each machine.


Follow these steps to see what licenses are available on your workstation and verify their status.

1. Start CodeMeter by clicking on it from the System Tray.
 - When CodeMeter opens, you should see a single item in the **Licenses** tab. This is a *container* that stores all the Mill-Turn licenses installed on your system.
 - The **Status** should tell you that they are **activated**.
2. Click the **WebAdmin** button to inspect the individual licenses.




3. When the **WebAdmin** console starts up, go to the **Licenses** tab to see exactly what licenses are installed.

This example shows two installed licenses: your Mill-Turn license as a **Consumer** user (every Mill-Turn user must have this), and one license for a machine. If you had licenses for more machines, they would be listed here.



If you try to access a machine for which you do not have a license—or open a part file that uses such a machine—Mastercam displays the following error message:



Follow the steps in the next section or call your Reseller for assistance.



Reactivating disabled licenses

If you lose the connection to your HASP, your machine license might be disabled.

If you feel that you have gotten the **Failed to open as machine file** message in error and you are sure the license has been installed on your system, the license may have become disabled.

To run properly, the CodeMeter application needs to maintain a constant connection with your HASP. If this connection is broken, your CodeMeter licenses cannot be activated and you will not be able to run Mill-Turn.


Some common reasons why this might happen include:

- You unplug your HASP before shutting down your workstation.
- You run on a NetHASP and the network connection is broken.
- Your computer has gone into a “sleep” or hibernation mode and CodeMeter can no longer detect the HASP.


If your CodeMeter licenses are not valid for any reason, the icon in the System Tray changes color, from blue-green to red.

However, when this happens, you can easily repair the license with CodeMeter. Follow these steps:

1. Make sure that your workstation is properly connected to the HASP.
2. Start CodeMeter by clicking its icon in the System Tray.




Blue-green icon = status OK



Red icon = disabled



3. When CodeMeter starts, make sure your Mastercam license container is visible.
CodeMeter should tell you that the license is invalid.
4. Click the **Repair License** button.



5. Click the **WebAdmin** button.
6. Click **Update**.

You should be able to run Mill-Turn normally at this point. Please contact your Reseller if you still have problems.



Chapter 2: Working with tools and spindles

Proper tool use is controlled by:


- ❖ **Initial tool setup**
- ❖ **Setting up for the left or right spindle**

This chapter explains how these different settings work together to produce the proper tool call output for your Fanuc TT machine.

See also “Setting up tools for pinch turn operations” on page 48 in the next chapter.

Your Fanuc TT **.machine** file also supports a number of spindle control commands, such as spindle syncing, clamping, and more.

- ❖ **C-axis clamp (M89/M189)**
- ❖ **Selecting the spindle winding range (M61, M62)**
- ❖ **Activating the M86 torque skip function**
- ❖ **Using the spindle sync function (M128)**




A: Setting up tools

Tool output is influenced by the tool definition and your toolpath settings.

The following sections show you which specific Mastercam settings your post is expecting so that it can output tool calls in the proper format.

- ❖ **Initial tool setup**
- ❖ **Setting up for the left or right spindle**




Initial tool setup


The tool definition should show the intended spindle.

Tools for both upper and lower turrets should be defined so that they are oriented proper for the intended spindle. They should be defined in the proper vertical or horizontal orientation.

Consider the toolpath shown at right. It uses a vertical, left-hand, insert-down tool.



The tool definition settings for the tool as pictured above would look like this in Mastercam.






Then when you select the tool in Mastercam, the picture in the tool selection window should look like this.

The picture that you see in Mastercam should show the proper orientation for:

- vertical/horizontal mounting
- left-hand/right-hand holder
- insert up/insert down

To review or edit these settings, follow these steps:

1. Right-click the picture of the tool.
2. Choose **Edit tool**.
3. Click **Setup Tool** and edit the settings as desired. See “Insert up/down and LH/RH holders” on page 23 to learn more.
4. Decide whether you want to keep the changes for all parts, or just the current part file.
 - Click **Save To Library** if you want the changes to apply to all future parts.
 - Click the **OK** button only if you just want the changes to apply to the current job.



Insert up/down and LH/RH holders

Tools that are mounted for a given spindle can still be in any of four different orientations, depending on whether it is mounted insert up or insert down, and whether you are using a left-hand or right-hand holder. Any of these is acceptable with Mill-Turn; the proper choice depends on how you will need the tool oriented when it is in its eventual cutting position.

The tool preview window in Mastercam shows you how the tool is oriented. Notice that the insert color changes to show up (yellow) or down (orange).



*left-hand holder;
insert up*



*left-hand holder;
insert down*




*right-hand holder;
insert up*




*right-hand holder;
insert down*

To switch between left- and right-hand holders or insert up/down (while maintaining the spindle orientation), follow these steps:

1. Right-click on a tool and select **Edit tool** to go to the **Tool Definition** dialog box.
2. Select the **Holders** tab.
The holders are arranged in left/right pairs.
3. Select the desired left- or right-hand holder.



4. Click **Setup**.
5. Change the **Spindle Rotation** direction.




Setting up for the left or right spindle


Axis combinations tell Mastercam on which spindle an operation will occur.

Once the tools have been defined properly, use the axis combination to tell Mastercam which spindle you are using. Follow these steps:

1. Click the **Axis Combination** button. Typically it is better to select this before selecting a tool.



2. Select the desired turret/spindle combination from the **Axis Combination** window. This picture shows the axis combination for using the lower turret on the left spindle.
3. If necessary, select the proper setup from the **Spindle Origin** list. (This is not common.)



4. Select the desired tool after selecting the axis combination. Make sure the picture in Mastercam shows it oriented for the selected spindle.



B: Spindle control functions

Your **.machine** file supports a number of spindle control functions that affect how your spindle/chuck operations are output.

- ❖ **C-axis clamp (M89/M189)**
- ❖ **Selecting the spindle winding range (M61, M62)**
- ❖ **Activating the M86 torque skip function**
- ❖ **Using the spindle sync function (M128)**

For all of these options, you can both edit the default settings and configure how they are implemented for specific individual operations.



C-axis clamp (M89/M189)

Separate controls let you clamp either the B or C axis.

The C-axis high-pressure clamp mode is available for Mill toolpaths. This is an M89 code for C1 (left spindle) and M189 for C2 (right spindle).

Set this option in the Sync Manager. Click the small triangle next to the toolpath name and select the desired **C-axis Clamp/Brake** mode:



- **Automatic**—Mastercam will automatically decide whether to clamp the C-axis based on the application and toolpath type.
- **FullClamp**—Force M89/M189 output.
- **Off**—Suppress M89/M189 output for the selected operation.

Default settings for M89/M189


You can choose which M89 mode will be the default

Follow these steps:

1. Open the Fanuc TT **.machine** file in the Code Expert.
2. Double-click the **Consumer** layer.
3. Select **Category: Output Settings**.



4. Go to the **Rotary Clamping** section.
5. Select the desired **C-axis Clamp/Brake** mode:
 - **Automatic**—Mastercam will automatically decide whether to clamp the C-axis based on the application and toolpath type.
 - **FullClamp**—Force M89/M189 output.
 - **Off**—Suppress M89/M189 output for the selected operation.
6. Save the **.machine** file.




Selecting the spindle winding range (M61, M62)

Select spindle winding range for either spindle to desired torque.

Your Fanuc TT **.machine** file lets you select the spindle winding range (Low or High) for each spindle.

- Low/High range for left spindle = M61/M62
- Low/High range for right spindle = M161/M162

Do this by selecting the **Hi/Lo Spindle Range Selection** option in the Sync Manager. Select **Low** for greater torque.



Activating the M86 torque skip function

The Fanuc TT .machine file supports M86 torque skip mode.




Your Fanuc TT .machine file supports M86/M87 to enable/disable the A-axis torque skip function.

Setting the default mode

Choose whether the default for torque skip mode is turned on or off.

Follow these steps:


1. Open the Fanuc TT .machine file in the Code Expert.
2. Double-click the **Consumer** layer.
3. Select the **Output Settings** category.
4. Go to the **Part Handling** section.
5. Select **Activate Torque Skip Mode...** to enable M86 torque skip as the default mode.



Enabling/disabling torque skip for each part

Mastercam lets you override the default M86 setting for each part. Do this in the Sync Manager before you post the part.

1. In the Sync Manager, click the little triangle next to the machine group name.
2. Select the desired **Activate Torque Skip Mode...** option.
3. Save the IOF file before posting.



Using the spindle sync function (M128)


Synchronize your C1 and C2 axes so that the master spindle drives the slave spindle.

Your Fanuc TT **.machine** file supports the M128 spindle sync command. Use this to lock the subspindle to the main spindle so that spindle rotation is synchronized.

Do this by selecting the **Sync control between C1 and C2** option in the Sync Manager. It is available for all Mill and multiaxis operations.

Typically this is selected in an **Upper Stream** operation, so that the left spindle (C1) is the master spindle and the right spindle (C2) is the slave.

An M129 is automatically output at the end of the operation if you turn this mode on.






Chapter 3: Working with toolpaths

Your Fanuc TT **.machine** file includes a number of settings that let you apply Fanuc TT-specific features to the operations that you create in Mastercam.

This chapter includes the following sections:

- ❖ **Toolpath reference positions**
 - ♦ Setting the start point and end point for an operation
 - ♦ Creating custom reference positions
 - ♦ Reference positions and reference points
- ❖ **Generic Fanuc TT machining modes**
 - ♦ Polar (G12.1) and cylindrical (G7.1) interpolation
 - ♦ Balanced turning operations
 - ♦ Using coolant
 - ♦ Output expanded Mcode comments



A: Toolpath reference positions

Use Sync Manager controls to determine the start and end points of each operation. Mastercam uses a Sync Manager option called *reference positions* that lets you choose this. You can also create new, custom reference positions for specific parts or part setups.

- ❖ **Setting the start point and end point for an operation**
 - **Setting the start point for an operation**
 - **Setting the end point**
 - **Selecting a reference position of None**
 - **Reference positions and null tool changes**
- ❖ **Creating custom reference positions**
- ❖ **Reference positions and reference points**



Setting the start point and end point for an operation


Use Sync Manager options to determine where each operation begins and ends.

Your **.machine** file includes a set of reference positions that have been defined specifically for your individual machine. Use these to tell Mastercam where you want to start and end each operation. For example, you might—or might not—want to move all the way to the home position between operations. Sync Manager reference positions let you determine exactly where you want each turret to go between operations.

- Select specific positions for the start and end of each operation in the Sync Manager.
- You can also define additional, new reference positions. Do this in the Job Setup inside Mastercam. Do this if your particular part setup requires different reference locations than are already defined in your **.machine** file—for example, to accommodate special fixturing, an unusual part shape, etc.

Setting the start point for an operation

To set the start point for an operation, select the desired **Reference position** in the Sync Manager. Click the small triangle next to the operation name in the Sync Manager, and select the location from the list.



The selected reference position is typically output before the tool change. For example, the highlighted code shows the **Upper Reference Return** reference position from the previous picture

```


18 N5
19 (OPERATION # 1)
20 G28 U0.
21 G28 W0.
22 (T01001 | ROUGH FACE LEFT - 80 DEG
23 M34
24 G54
25 T01001 ( ROUGH FACE LEFT - 80 DEG. )
26 M262
27 G97 S395 M04 P11

```

Setting the end point

To set the end point for an operation, select the desired **Reference position** from the operation's **Retract** branch. You can choose to make the end position of one operation the same location as the start point of the next operation by choosing the same reference position.

The example shown here displays a user-defined reference position. You can create such positions if, for example, you don't want to retract all the way to the home position between operations. (See **Creating custom reference positions** on next page.)



The highlighted lines in this code sample show how this might appear in your NC program. You can see that instead of a G28 move to the home position, there is a move to the user-defined reference position.

```

118 G00 Z.25
119 G369
120 G53 U14. V0.
121 G53 W6.
122 G28 B0.
123 T03000
124 M05 P12
125 M01

```




Selecting a reference position of None

Selecting **None** for a reference position means that there will simply be no output where the reference position is typically output. For example, the code at right shows what happens if **None** is selected as the reference position for operation #2.

Note that you cannot select **None** for the start point of the first toolpath.



```
81 T02000
82 M05 P11
83 M01
84
85 N2
86 (OPERATION # 3)
87 (T03 | 3/16 FLAT ENDMILL | DIA. - 0.
88 M35
89 G54
90 M06 T03003 ( 3/16 FLAT ENDMILL )
91 T04000
92 G00 G28 W0.
93 G28 B0.
94 M101
95
```



Reference positions and null tool changes

If you have consecutive operations in the same stream that use the same tool and tool orientation, Mastercam will typically not output a tool change between the operations. When this happens, Mastercam will not display the reference position option for the **Retract** of the first operation, or for the start of the second operation. You can see in this picture that the **Reference position** option is not available for the start of this operation.

In these instances, you can force the **Reference position** option to be available by selecting the **Force tool change** option inside Mastercam. This might be useful if you have defined custom reference positions that you want to use as clearance positions between such operation.




Creating custom reference positions

Create reference positions for specific parts or jobs inside Mastercam.

There will be times when you need reference positions that have not been defined in your **.machine** file. These might be necessary to accommodate special part fixturing or tooling, or a part with unusual dimensions. In these cases, you can define your own custom reference positions. These are saved with your part, not in the **.machine** file, and therefore are only available to the current part.


Follow these steps to create a new reference position.


1. Click the  button on the Toolpath Manager toolbar.

Mastercam displays the **Machine Reference Positions Manager**, which lists all of the reference positions that have been defined for the current machine. Most of them will be grayed out, meaning that you are not allowed to edit them.

2. Right-click in the list and select **New reference position** or **Duplicate selected reference position** to create a new one.

3. Enter a **Name** and edit the other properties.
 - You can see in the list that there are several different types of reference positions; however, you can only create new ones of type **Reference**. You can duplicate a different reference position, but the **Type** will be set to **Reference**.






- Each reference position is associated with a specific axis combination. Mastercam uses this to filter the reference points by spindle, turret, and/or stream. For example, when you select reference points in the Sync Manager for a lower stream operation, only reference points valid in that stream will be displayed.
 - For each reference position, enter the desired axis motion and coordinate. You can choose to move any or all axes. Mastercam only displays axes that are included in the selected axis combination.
4. Click **OK** when you are done.
 5. Click **G1** to post the operations.
 6. Go to the Sync Manager. The new reference




position should be available. Make sure you look in the proper stream.



Reference positions and reference points

Reference positions in the Sync Manager are in addition to reference points in your toolpath settings.

Mastercam toolpaths still include the **Reference Point** feature. This is available in the toolpath parameter pages for each Mill and Lathe toolpath. In Mill-Turn, this defines an intermediate position between the toolpath and the reference position that is selected in the Sync Manager. For example, if you are turning an ID operation, you might create toolpath reference points to make sure the tool fully and properly retracts from the ID before moving to the reference position. Do not make the mistake of confusing reference *points* and reference *positions*.




B: Generic Fanuc TT machining modes

Your Fanuc TT .machine file supports several different machining modes for mill operations

Your Fanuc TT .machine file supports the following milling cycles:

- G7.1 (polar interpolation)
- G12.1 (cylindrical interpolation)

The cycles are automatically keyed to the milling setup types on the **Setup** page for mill operations. Just select the proper application icon when programming the toolpath in Mastercam, and the appropriate cycle will be activated in your post



This section also contains information about how the Fanuc TT .machine file supports the following features:

- balanced turning (or pinch turning)
- coolant

The following sections describe how to set defaults for each mode and how to enable or suppress them for individual operations.

- ❖ **Polar (G12.1) and cylindrical (G7.1) interpolation**
- ❖ **Balanced turning operations**



Polar (G12.1) and cylindrical (G7.1) interpolation

Configure the type of output you want for polar and cylindrical interpolation cycles.

Your Fanuc TT **.machine** file supports both polar (G12.1) and cylindrical (G7.1) interpolation cycles. This topic explains how to:

- configure default settings for these operations.
- select the cycle for each individual operation.


Default settings for G7.1 and G12.1

Two different default settings are available in the **.machine** file.


- Choose whether the default output mode will be the G7.1/ G12.1 cycle or longhand output.
- Choose whether the X-axis output will be in diameter or radius values.

Follow these steps:

1. Open the Fanuc TT **.machine** file in the Code Expert.
2. Double-click the **Consumer** layer.




3. Select **Category: Control Definition**.
4. Go to the **Modes** section.
5. For each cycle, choose the default output mode. If you do not select the checkbox, you will get longhand output.
6. Save the **.machine** file when you are done.




Programming G7.1/G12.1 for each operation

Follow this general workflow for programming these cycles for each operation.


1. The cycles are keyed to specific setup types and are automatically enabled when you select **C-axis Face** or **Axis Substitution** on the **Setup** page for milling operations.
2. For either type of operation, the **Toolplane** is automatically selected. These planes were created for you when you completed the **Job Setup** process. Each plane automatically sets the proper tool orientation for your part.



3. After you load the part in the Sync Manager, set the maximum polar feedrate. This is a machine group option applies to the entire part. Click the small triangle next to the group name and enter the desired value.



4. For each operation, choose whether or not to output the G7.1/G12.1, or longhand output. Click the little triangle next to the operation and select the cycle option if desired, or leave it unchecked for longhand output.
5. Press **[Ctrl+S]** to save the new setting back to your part file.



Balanced turning operations

Information about programming balanced turning (pinch turn) operations.

Balanced cut mode on your Generic Fanuc TT machine (G68 mode) typically corresponds to Mastercam's pinch turn operation.


Numbering syncs for pinch turn operations

Mastercam automatically generates and numbers the proper wait codes when you generate a pinch turn operation.

However, when you create your own syncs in the Sync Manager between other operations, these will be numbered after the ones created for the pinch turn operation. This means that after creating your own syncs, choose the **Renumber** command from the ribbon bar.



This will renumber all of your syncs consecutively—your own plus the ones created by Mastercam.



```

31 G96 S200 P11
32 M900 (WAIT)
33 M192 (SIMULTANEOUS FEEDRATE ON)
34 G68 (BALANCE CUT MODE ON)
35 G99 G01 Z.1 F.02
36 Z-3.0152
37 G03 X1.9756 Z-3.2282 R.2913
38 G01 Z-4.4947
39 X2.117 Z-4.424
40 G00 Z.2
41 X1.605
42 M901 (WAIT)
43 G01 Z.1
44 Z-2.9501
45 X1.7077 Z-2.9831
46 G03 X1.8103 Z-3.0249 R.2912
47 G01 X1.9517 Z-2.9542
48 G00 Z.2
49 X1.4197
50 M902 (WAIT)
51 G01 Z.1
52 Z-2.8907
  
```



Setting up tools for pinch turn operations

When creating a pinch turn operation, it is important that the settings for the two tools be properly coordinated. Mastercam will not be able to create the operation if they conflict. Follow these guidelines.


Insert direction—The insert directions for the two tools need to be complementary. For example, if the upper-turret tool is insert-down, then the lower-turret tool needs to be insert-up.

You can tell the insert direction from the picture in the tool window. An orange insert means insert-down; a yellow insert means insert-up.




Spindle direction—The spindle direction for the two tools must be the same.

Tool holder—If the above two conditions are met and the toolpath is still not being created properly, you might need to select a different tool holder. Right-click the picture of the tool, and select **Edit tool**. Then click the **Draw tool** button.


If the upper-turret tool is insert-down...




...the lower-turret tool must be insert-up.



Mastercam displays the tool and holder profile as currently defined. For example, the tool shown here is insert-up with a left-hand holder, but is clearly not defined correctly for work on the left spindle. If you wanted to use this tool in a pinch-turn operation, and it needs to be insert-up to complement the upper-turret roughing tool, you need to select a right-hand holder for it.




To do this, go to the **Holders** tab in the **Define Tool** dialog box. Most of the holders are listed in left-right pairs as shown in the picture. Select the one that you need.



Click the **Draw tool** button again. You should see the tool oriented for the other spindle as shown here.

Once the **Draw tool** picture is correct, Mastercam should be able to create the pinch turn operation properly.



Using coolant


Use Sync Manager options to select pre-configured coolant strategies.

Your Fanuc TT **.machine** file supports the following coolant options:

- Flood coolant (M08)
- Thru-spindle coolant for the milling spindle (M108)
- Bed shower coolant (M07)


If you are familiar with other Mastercam products, you are used to selecting coolant options inside Mastercam as part of the toolpath parameters. In Mill-Turn, coolant selection is done in the Sync Manager; the **Coolant** button is no longer present inside Mastercam.

For each operation, click the small triangle next to the operation name and select the desired coolant option. Each strategy will automatically turn off the coolant before the retract move. Use the **Off** option only when you want to force the coolant off. It is not necessary to use this option to routinely turn off coolant for each operation.



Bed shower coolant (M07)



Bed shower coolant (M07) is controlled separately from the other coolant options. It is typically turned on at the beginning of the machining job. Click the small triangle next to the machine group name to turn it on. It is automatically turned off at the end of the stream.



Setting the default coolant option

You can select a default coolant strategy and save it in the **.machine** file.

1. Open the Fanuc TT **.machine** file in the Code Expert.
2. Double-click the **Consumer** layer.
3. Select **Category: Output Settings**.
4. Go to the **Coolant** section.
5. Set the desired default strategy.
6. Save the **.machine** file.



Output expanded Mcode comments

You can choose to enable or disable extra comments when MCodes are output.


Your **.machine** file includes an option that lets you include expanded comments when certain Mcodes are output:

```
T06006 ( OD ROUGH LEFT - 80 DEG. )
G00 G28 W0.
M161 (LEFT SPINDLE LOW GEAR)
G97 S417 M04 P21
G00 Z-.075
X1.8325
G50 S5000 P21
G96 S200 P21
```

```
T06006 ( OD ROUGH LEFT - 80 DEG. )
G00 G28 W0.
M161
G97 S417 M04 P21
G00 Z-.075
X1.8325
G50 S5000 P21
G96 S200 P21
```

You can disable these extra comments if you wish. Follow these steps:

1. Open the **.machine** file in the Code Expert.
2. Double-click the **Consumer** layer.



3. Select **Category: Output Settings**.
4. Go to the **NC Output** section.
5. Set the **Output comment for some M codes** option as desired.
6. Press **Ctrl+S** before posting to save your setting.

