

How to access RPi Remotely.

1. Use an Ecs computer
2. Open command prompt
3. Type: ssh [pi@10.140.101.184](#)
4. It will ask for a password type: pi (it will not show up but u have typed it.
5. You now have remote access