

# **Freescale MQX RTOS Example Guide**

## **Nill\_lite example**

This document explains the nill\_lite example, what to expect from the example and a brief introduction to the API used.

## **The example**

The application example creates just one task.  
The task does nothing and is blocked.

## **Running example**

The user only needs to do compilation of MQX libraries, ksdk library and the example without any further step.

If the platform supports floating point, you have to disable floating point in <MQX\_folder>\rtos\mqx\config\mcu\<board>\mqx\_sdk\_config.h:

```
#define MQXCFG_ENABLE_FP                0
```

And rebuild MQX library.

To run the example the corresponding IDE, debugger and compiler are needed.