



Haynes
shows you how

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

4 Fuel expansion tank - removal and installation

Warning:

Refer to the **Warning** in Section 1 before proceeding.

1 Loosen the right-rear wheel lug nuts, raise the right-hand rear side of the vehicle and support it securely on jackstands. Remove the right-rear wheel.

2 Remove the plastic nuts/screws/expansion rivets and remove the liner in the right-rear wheel well (see [Chapter 12](#)).

3 Remove the retaining nut, disconnect the lower hose, and pull the bottom of the tank forward (see illustration) .

4.3 Remove the expansion tank retaining nut



4 Note their installed positions, then loosen the clamps and disconnect the remaining two breather hoses from the tank. Remove the tank.

5 Installation is a reversal of removal.