



Haynes
shows you how

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

26 Tie-rods - replacement

1 Remove the steering gear boots (see [Section 24](#)).

2 Disconnect the tie-rod ends from the steering knuckles (see [Section 25](#)).

3 Move the rack in as far as possible, then loosen and remove the large inner tie-rod nut from the end of the steering gear. Remove the tie-rod and inner tie-rod end.

4 Position the new inner tie-rod end/tie-rod on the rack, start the threads and tighten the retaining nut to the specified torque. **Note:** *The tie-rods should only be replaced as a pair.*

5 Install the steering boots (see [Section 24](#)).

© 2024 Haynes Manuals, Inc. Contact us