

**Haynes**
shows you how

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

11 Throttle linkage - lubrication

- 1 Periodically, lubricate the accelerator and throttle linkage with a general purpose oil.
- 2 Lubricate all joints and bearings in the linkage.
- 3 Lubricate the throttle plate shaft with multipurpose grease.

© 2024 Haynes Manuals, Inc. Contact us