



Haynes
shows you how

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

4 Fluid seals - replacement

Torque converter seal

6-speed models only

- 1 Remove the transmission and the torque converter (see [Section 5](#)).
- 2 Using a hooked tool, pry the old oil seal from the transmission bellhousing. Alternatively, drill a small hole, then screw a self-tapping screw into the seal and use pliers to pull out the seal.
- 3 Lubricate the lip of the new seal with clean transmission fluid, then carefully drive it into place using a large socket or tube.
- 4 Remove the old O-ring seal from the input shaft and slide a new one into place. Apply a smear of petroleum jelly to the new O-ring.
- 5 Install the torque converter and transmission (see [Section 5](#)).

Output flange oil seal

- 6 Replacement of the oil seal involves partial disassembly of the transmission, which is a complex operation. Oil seal replacement should be entrusted to a BMW dealer or specialist.

© 2024 Haynes Manuals, Inc. Contact us