

**Haynes**
shows you how

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual


17 Oil pressure and level switches - removal and installation

Oil pressure/temperature switch

1 The oil pressure switch is located on the left-hand side of the engine block behind the oil filter housing.

2 Disconnect the wiring plug, and unscrew the switch from the engine block (see illustration) . Be prepared for oil spillage.

17.2 The oil pressure switch is located behind the oil filter housing



3 Installation is the reversal of removal. Use a new sealing washer and tighten the switch to the specified torque. Check the engine oil level and add new oil if necessary.

Oil condition/level switch

4 Drain the engine oil (see [Chapter 1](#)).

5 Remove the fasteners and the engine splash shield.

6 Disconnect the wiring plug, remove the three retaining nuts and remove the switch from the base of the oil pan.

7 Ensure that the oil pan mating surface is clean.

8 Install the switch with a new seal and apply a little thread-locking compound. Tighten the retaining nuts to the specified torque.

9 Install the engine splash shield, and refill the engine oil (see [Chapter 1](#)).

© 2024 Haynes Manuals, Inc. Contact us