

**Haynes**
*shows you how***BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual**

3 Clutch release bearing and lever - removal, inspection and installation

Warning:

Dust created by clutch wear and deposited on the clutch components may contain asbestos, which is a health hazard. DO NOT blow it out with compressed air or inhale any of it. DO NOT use gasoline (or petroleum-based solvents) to clean off the dust. Brake system cleaner should be used to flush the dust into a suitable receptacle. After the clutch components are wiped clean with rags, dispose of the contaminated rags and cleaner in a sealed, marked container.

Release bearing

Removal

- 1 Remove the transmission (see [Chapter 7A](#)).
- 2 Pull the bearing forwards, and slide it from the guide sleeve in the transmission bellhousing (see illustration) .

3.2 Removing the clutch release bearing



Inspection

- 3 Spin the release bearing, and check it for excessive roughness. Hold the outer race and attempt to move it laterally against the inner race. If any excessive movement or roughness is evident, replace the bearing. If a new

clutch has been installed, it is wise to replace the release bearing as a matter of course.

Installation

4 Clean and then lightly grease the release bearing contact surfaces on the release lever. **Do not** apply grease to the guide sleeve.

5 Slide the bearing into position on the guide sleeve, ensuring that the bearing engages correctly with the release lever.

6 Install the transmission (see [Chapter 7A](#)).

Release lever

Removal

7 Remove the release bearing, as described previously in this Section.

8 Slide the release lever sideways to release it from the retaining spring clip and pivot, then pull the lever forwards from the guide sleeve (see illustrations) .

3.8a Slide the clutch release lever sideways to release the spring clip . . .



3.8b . . . then slide the lever from the guide sleeve



Inspection

9 Inspect the release bearing, pivot and release cylinder pushrod contact faces on the release lever for wear. Replace the lever if excessive wear is evident.


10 Check the condition of the release lever retaining spring clip, and replace if necessary. It is advisable to replace the clip as a matter of course.

Installation

11 Clean and then lightly grease the release bearing contact surfaces on the release lever. Do not apply grease to the guide sleeve.

12 Slide the release lever into position over the guide sleeve, then push the end of the lever over the pivot, ensuring that the retaining spring clip engages correctly over the end of the release lever (see illustration) .

3.12 Ensure that the retaining spring clip (arrow) engages correctly



13 Install the release bearing as described previously in this Section.