



Haynes
shows you how

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

17 Transfer case lubricant level check (every 15,000 miles or 12 months)

- 1 Raise the vehicle and support it securely on jackstands at both ends, to keep the vehicle level.
- 2 Using a ratchet or breaker bar, unscrew the check/fill plug from the transfer case.
- 3 Use your little finger to reach inside the housing to feel the lubricant level. The level should be at or near the bottom of the plug hole. If it isn't, add the recommended lubricant through the plug hole with a syringe or squeeze bottle.
- 4 Install and tighten the plug. Check for leaks after the first few miles of driving.

© 2024 Haynes Manuals, Inc. Contact us