



14 Horns - removal and installation

Removal

- 1 The horns are located behind the left and/or right end(s) of the front bumper.

3-Series models

2 To gain access to the horn(s) from below, apply the parking brake then jack up the front of the vehicle and support it on axle stands. Remove the retaining screws and remove the access cover from the left-hand underside of the bumper. Unclip and remove the brake disc cooling duct.

3 To gain access to the horns from above, remove the left-hand headlight (see [Section 7](#)) (see illustration) .

14.3 Horns viewed from above with the left-hand headlight unit removed (3-Series models)



4 Remove the retaining nut/bolt and remove the horn, disconnecting its wiring connectors as they become accessible.

Z3 models

5 Remove the engine splash shield filler panel (see illustration 6.15a in [Chapter 11](#)) .

6 Unplug the electrical connector and remove the retaining nut (see illustration) .

14.6 To detach a horn from a Z3 model, unplug the electrical connector and remove this nut (arrow)



Installation

7 Installation is the reverse of removal.

© 2024 Haynes Manuals, Inc. Contact us