

**Haynes**
shows you how

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

15 Hinge and lock lubrication

Lubricate the hinges of the hood, doors and tailgate with a light general-purpose oil. Similarly, lubricate all latches, locks and lock strikers. At the same time, check the security and operation of all the locks, adjusting them if necessary (see [Chapter 11](#)).

Lightly lubricate the hood release mechanism and cable with a suitable grease.

© 2024 Haynes Manuals, Inc. Contact us