



Haynes
shows you how

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

4 Resetting the service interval display

June 2000 and earlier models

Note:

The following requires use of a special BMW service tool and adapter. If an aftermarket tool is being used, refer to the instructions supplied by its manufacturer.

- 1 Turn the ignition off, unscrew the cap, then plug BMW service interval resetting tool 62 1 110 into the engine compartment diagnostic socket. The socket is round with a protective cap and located near the jump start terminals in the right-rear part of the engine compartment.
- 2 Ensure that all electrical items are switched off then turn on the ignition switch. **Note:** *Do not start the engine.*
- 3 To reset an Oil Service, press and hold the yellow button; the green light will illuminate. After about 3 seconds the yellow light will illuminate for about 12 seconds, and then go out.
- 4 To reset an Inspection Service, press and hold the red Inspection button; the green (function check) light will illuminate. After about 3 seconds the red lamp should also light, remain on for about 12 seconds, and then go out. Release the Inspection button and the green (function check) light will go out.
- 5 If the clock (annual service) symbol was illuminated at the same time as the oil service or inspection indicator, wait 20 seconds then repeat the operation in paragraph 4.
- 6 Turn off the ignition switch and disconnect the resetting tool and adapter from the diagnostic connector.
- 7 Turn the ignition switch on and check that the Service Interval Display has been reset.

July 2000 and later models

Note:

No special tool is necessary to reset the service interval display on these models.

- 8 Press and hold the trip odometer reset button and then turn the ignition key to the accessory position.

9 After about 5 seconds the display will change, release the button once and then press and hold again for about 5 more seconds.

10 When the display begins to flash, release the button and press it once again briefly. After a few seconds, the display will change to END SIA.

11 The vehicle must be driven another 75 miles if any further resetting is needed.

12 You can interrupt the procedure by simply turning the ignition key off and start over if necessary.

© 2024 Haynes Manuals, Inc. Contact us