



Haynes
shows you how

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

24 Air filter element replacement

Four-cylinder engine

- 1 The air cleaner assembly is located at the front left-hand corner of the engine compartment.
- 2 Release the four securing clips, and lift off the air cleaner cover (see illustration) .

24.2 Releasing an air cleaner cover securing clip - four-cylinder engine



- 3 Lift out the filter element (see illustration) .

24.3 Lifting out the air filter element - four-cylinder engine



4 Wipe out the air cleaner housing and the cover.

5 Lay the new filter element in position, then install the cover and secure with the clips.

Six-cylinder engine

6 The air cleaner assembly is located at the front left-hand corner of the engine compartment.

7 Depress the securing clips, and slide the filter element tray up from the housing.

8 Lift out the filter element (see illustration) .

24.8 Lifting out the air cleaner element - six-cylinder engine



9 Wipe out the air cleaner housing and the tray.

10 Lay the new filter element in position, then slide the tray into the housing until it locks in position.

© 2024 Haynes Manuals, Inc. Contact us