

Wire colours

Bl	Blue	Rs	Pink
Br	Brown	Rt	Red
Ge	Yellow	Sw	Black
Gr	Gray	Vi	Violet
Gn	Green	Ws	White
Or	Orange	Tr	Transparent

Key to items

- 1 Battery
2 Ignition switch
3 B+ distribution box
4 Front power distribution box
9 Data link connector
14 Check control module
57 Driver's door jamb switch
90 Instrument cluster
n = seat belt ind.
o = ABS ind.
p = brake warning indicator

- 90 Instrument cluster continued
q = transmission malfunction ind.
r = control unit
s = fuel gauge
t = fuel consumption meter
u = speedometer
v = tachometer
w = temperature gauge
95 LH front pad sensor
96 RH rear pad sensor
97 Oil temperature sensor

- 98 Key-in switch
99 Driver's seat belt switch
100 Engine coolant temp. sensor
101 Multi-function clock or on-board display
102 On-board computer temp. sensor
103 Chime module
104 Vehicle speed sensor
105 Fuel level sensor
106 Fuel tank sensor II

H31910

Typical warning lights and indicators continued (2 of 2)

