

Typical passenger comp. fusebox 18

(models 03/2007 to 09/2007)

Fuse	Rating	Circuit protected
F1	10A	Roll over protection control unit
F2	5A	Instrument cluster, on board diagnostics (OBDII)
F3	20A	Heated passenger seat
F4	5A	Car access system
F5	-	Not used
F6	15A	Transmission control unit
F7	20A	Auxiliary heater control unit
F8	20A	Audio amplifier
F9	10A	Cruise control
F10	15A	Trailer control unit
F11	10A	Audio system
F12	20A	Convertible roof/sunroof, roof function control unit
F13	5A	iDrive controller, tyre pressure control
F14	-	Not used
F15	5A	Automatic air conditioner sensor
F16	15A	Horn
F17	5A	Telephone
F18	5A	Antenna (convertible), interior rear view mirror (not convertible), shift selector lighting
F19	7.5A	Alarm
F20	5A	Dynamic stability control, transfer case control unit
F21	7.5A	Driver's door switch cluster, electric mirrors
F22	10A	Longitudinal dynamics management
F23	10A	Digital tuner, satellite radio
F24	5A	DC converter, fan cut-out relay
F25	10A	Front seat belt positioner control units
F26	10A	Telephone
F27	5A	Driver's door switch cluster, telephone
F28	5A	Roof function control centre, park distance control
F29	5A	Front seat heating control units
F30	20A	12v sockets, front cigar lighter
F31	20A	Car communication control unit/audio system control unit
F32	30A	Driver's seat control unit
F33	5A	Comfort access control unit, front door outer handles control unit
F34	5A	CD changer, antenna
F35	30A	Dynamic stability control
F36	30A	Footwell control unit
F37	10A	Driver's seat control unit
F38	30A	Transfer case control unit
F39	30A	Wipers
F40	7.5A	Roof function control unit
F41	30A	Footwell control unit
F42	40A	Footwell control unit
F43	-	Not used
F44	30A	Trailer control unit
F45	40A	Active steering system
F46	30A	Heated rear window
F47	20A	Trailer socket

Fuse	Rating	Circuit protected
F48	20A	Rear wash/wipe control unit
F49	30A	Passenger seat heater
F50	10A	Engine control unit
F51	40A	Car access system
F52	20A	Driver's heated seat
F53	20A	Passenger's heated seat
F54	30A	Trailer control unit
F55	-	Not used
F56	15A	Central locking
F57	15A	Central locking
F58	5A	Instrument cluster
F59	5A	Steering column switch cluster
F60	5A	Central information display
F61	10A	Luggage compartment lights, central info. display, glove box light
F62	30A	Electric windows
F63	30A	Electric windows
F64	30A	Electric windows, diagnostic socket (OBDII)
F65	10A	Selector lever illumination, longitudinal dynamics management
F66	50A	Diesel fuel heater
F67	40A	Blower control
F68	40A	Footwell control unit
F69	50/60A	Engine cooling fan
F70	40A	Secondary air injection pump
F71	20A	Trailer socket
F72	-	Not used
F73	-	Not used
F74	10A	Engine control unit, exhaust flap, fuel tank leakage diagnostic unit, nitrogen oxide sensor
F75	10A	EAC sensor, engine fusebox fan, engine control unit, secondary air pump relay
F76	30A	Crankshaft sensor, fuel tank vent valve, mass air flow sensor, oil condition sensor, variable intake manifold sensor, volume control valve
F77	30A	Fuel injectors, ignition coils
F78	30A	Camshaft sensors, thermostat, coolant pump, engine control unit, VANOS valves, waste gate valves
F79	30A	Crankcase breather heater, oxygen sensor heater
F80	40A	Electric coolant pump (non turbo)
F81	30A	Trailer control unit
F82	-	Not used
F83	40A	Footwell control unit
F84	-	Not used
F85	-	Not used
F86	-	Not used
F87	-	Not used
F88	20A	Fuel pump

