

9. DC/DC Converter

A: SPECIFICATION

Refer to “HYBRID ELECTRIC VEHICLE” for specification. <Ref. to HEV-2, SPECIFICATION, General Description.>

B: REMOVAL

Refer to “HYBRID ELECTRIC VEHICLE” for removal procedure. <Ref. to HEV-38, REMOVAL, DC/DC Converter.>

C: INSTALLATION

Refer to “HYBRID ELECTRIC VEHICLE” for the installation procedure. <Ref. to HEV-41, INSTALLATION, DC/DC Converter.>

ENGINE (DIAGNOSTICS)

EN(H4DO HEV)(diag)

	Page
1. Basic Diagnostic Procedure	2
2. Check List for Interview	4
3. General Description	6
4. Electrical Component Location	9
5. Control Module I/O Signal	19
6. Engine Condition Data	29
7. Data Link Connector	30
8. General Scan Tool	31
9. Subaru Select Monitor	36
10. Read Diagnostic Trouble Code (DTC)	51
11. Inspection Mode	52
12. Drive Cycle	55
13. Clear Memory Mode	66
14. System Operation Check Mode	67
15. Malfunction Indicator Light	68
16. Diagnostics for Engine Starting Failure	70
17. List of Diagnostic Trouble Code (DTC)	92
18. Diagnostic Procedure with Diagnostic Trouble Code (DTC)	102
19. General Diagnostic Table	398