


## 5. Control Module I/O Signal

### A: ELECTRICAL SPECIFICATION

#### 1. ENGINE CONTROL MODULE (ECM)



EN-05288

Description		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW ON (engine OFF)	Engine ON (idling)	
Crankshaft position sensor	Signal (+)	B136	16	5	0 or 5	Waveform
	Signal (–)	B136	27	5	0	—
Front oxygen (A/F) sensor	Signal (+)	B136	19	2.8 — 3.2	2.8 — 3.2	—
	Signal (–)	B136	18	2.4 — 2.7	2.4 — 2.7	—
	Shield	B136	30	0	0	—
Rear oxygen sensor	Signal	B136	21	0	0 — 0.9	—
	Shield	B136	30	0	0	—
Front oxygen (A/F) sensor heater signal		B136	5	Battery voltage	0 or battery voltage	Waveform
Rear oxygen sensor heater signal		B134	6	Battery voltage	0 or battery voltage	Waveform
Engine coolant temperature sensor	Signal	B134	30	1.0 — 1.4	1.0 — 1.6	—
Air flow sensor	Signal	B137	22	—	0.3 — 4.5	—
	Shield	B137	28	0	0	—
	Ground	B137	29	0	0	—
Intake air temperature sensor signal		B137	12	0.3 — 4.6	0.3 — 4.6	—
Engine oil temperature sensor signal		B134	20	1.0 — 1.4	1.0 — 1.6	—
Starter switch		B137	17	Waveform	Waveform	Waveform
Accessory cut request		B135	32	Waveform	Waveform	Cranking: waveform
Starter switch 2		B137	14	Waveform	Waveform	Cranking: waveform
Starter cut relay		B135	34	Waveform	Waveform	Cranking: waveform
Ignition switch		B137	27	Battery voltage	Battery voltage	—

# Control Module I/O Signal

## ENGINE (DIAGNOSTICS)

Description		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW ON (engine OFF)	Engine ON (idling)	
Neutral position switch		B137	16	ON: 0 OFF: Battery voltage	ON: 0 OFF: Battery voltage	—
Delivery mode switch		B137	13	Battery voltage	Battery voltage	When fuse is installed: 0
Knock sensor	Signal	B136	28	2.5	2.5	—
	Shield	B136	29	0	0	—
Back-up power supply		B137	2	Battery voltage	Battery voltage	—
Control module power supply		B136	6	Battery voltage	Battery voltage	—
		B137	1	Battery voltage	Battery voltage	—
Sensor power supply		B134	19	5	5	—
		B135	22	5	5	—
Ignition control	#1	B134	21	0	0 or 5	Waveform
	#2	B134	10	0	0 or 5	Waveform
	#3	B134	31	0	0 or 5	Waveform
	#4	B134	8	0	0 or 5	Waveform
Fuel injector	#1	B134	12	Battery voltage	0 or battery voltage	Waveform
	#2	B134	22	Battery voltage	0 or battery voltage	Waveform
	#3	B134	32	Battery voltage	0 or battery voltage	Waveform
	#4	B134	13	Battery voltage	0 or battery voltage	Waveform
Fuel pump relay control		B135	19	Battery voltage	ON: 0.5 or less OFF: Battery voltage	—
A/C relay control		B135	35	ON: 0.5 or less OFF: Battery voltage	ON: 0.5 or less OFF: Battery voltage	—
Pressure switch		B137	8	ON: 0 OFF: Battery voltage	ON: 0 OFF: Battery voltage	—
Main fan relay control		B135	12	ON: 0.5 or less OFF: Battery voltage	ON: 0.5 or less OFF: Battery voltage	—
Sub fan relay control		B135	11	ON: 0.5 or less OFF: Battery voltage	ON: 0.5 or less OFF: Battery voltage	—
Engine speed output		B135	15	—	0 or battery voltage	Waveform
Purge control solenoid valve		B134	11	Battery voltage	Battery voltage	In operation: Waveform
EGR control valve	Signal 1	B136	11	Battery voltage	0 or battery voltage	—
	Signal 2	B136	13	Battery voltage	0 or battery voltage	—
	Signal 3	B136	31	Battery voltage	0 or battery voltage	—
	Signal 4	B136	32	Battery voltage	0 or battery voltage	—
Manifold absolute pressure sensor signal		B136	20	3.4 — 3.8	1.0 — 1.6	—
Electronic throttle control	Main	B134	18	Approx. 0.7	Approx. 0.6 — 0.7	Fully closed: Approx. 0.6 Fully open: Approx. 4.0
	Sub	B134	28	Approx. 1.6	Approx. 1.5 — 1.6	Fully closed: Approx. 1.5 Fully open: Approx. 4.2
Electronic throttle control motor (+)		B134	2	Duty waveform	Duty waveform	Drive frequency: 500 Hz
Electronic throttle control motor (–)		B134	1	Duty waveform	Duty waveform	Drive frequency: 500 Hz

# Control Module I/O Signal

ENGINE (DIAGNOSTICS)

Description		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW ON (engine OFF)	Engine ON (idling)	
Electronic throttle control motor power supply		B135	7	Battery voltage	Battery voltage	—
Electronic throttle control motor relay		B135	17	0	0	—
Intake oil control solenoid (LH)		B134	16	Battery voltage	0 or battery voltage	Waveform
Intake oil control solenoid (RH)		B134	17	Battery voltage	0 or battery voltage	Waveform
Exhaust oil control solenoid (LH)		B134	5	Battery voltage	0 or battery voltage	Waveform
Exhaust oil control solenoid (RH)		B134	7	Battery voltage	0 or battery voltage	Waveform
Intake camshaft position sensor (LH)		B136	15	5	0 or 5	Waveform
Intake camshaft position sensor (RH)		B136	26	5	0 or 5	Waveform
Exhaust camshaft position sensor (LH)		B136	25	5	0 or 5	Waveform
Exhaust camshaft position sensor (RH)		B136	14	5	0 or 5	Waveform
Camshaft position sensor ground		B136	34	0	0	—
Accelerator pedal position sensor	Main sensor signal	B135	23	Fully closed: 0.4 — 1.0 Fully opened: 2.4 — 3.7	Fully closed: 0.4 — 1.0 Fully opened: 2.4 — 3.7	—
	Main power supply	B135	21	5	5	—
	Ground (main sensor)	B135	29	0	0	—
	Sub signal sensor	B135	31	Fully closed: 0.3 — 1.1 Fully opened: 2.3 — 3.8	Fully closed: 0.3 — 1.1 Fully opened: 2.3 — 3.8	—
Starter relay		B135	26	Waveform	Waveform	Waveform
Brake switch 1 (brake switch)		B137	7	When brake pedal is depressed: 0 When brake pedal is released: Battery voltage	When brake pedal is depressed: 0 When brake pedal is released: Battery voltage	—
Brake switch 2 (stop light switch)		B137	3	When brake pedal is depressed: Battery voltage When brake pedal is released: 0	When brake pedal is depressed: Battery voltage When brake pedal is released: 0	—
Cruise control command switch		B137	30	When operating nothing: 3.5 — 4.5 When operating RES/ACC: 2.5 — 3.5 When operating SET/COAST: 0.5 — 1.5 When operating CANCEL: 0 — 0.5	When operating nothing: 3.5 — 4.5 When operating RES/ACC: 2.5 — 3.5 When operating SET/COAST: 0.5 — 1.5 When operating CANCEL: 0 — 0.5	—
Cruise control main switch		B137	23	ON: 0 OFF: 5	ON: 0 OFF: 5	—

## Control Module I/O Signal

### ENGINE (DIAGNOSTICS)


Description		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW ON (engine OFF)	Engine ON (idling)	
CAN commu- nication (MAIN-CAN)	(Hi)	B137	19	—	—	—
	(Lo)	B137	18	—	—	—
CAN commu- nication (PU-CAN)	(Hi)	B137	10	—	—	—
	(Lo)	B137	21	—	—	—
Self-shutoff control		B135	13	0	0	—
Battery temperature sensor		B137	24	1.1 — 2.4	1.1 — 2.4	When battery temper- ature is 20 — 50°C (68 — 122°F)
Oil level switch		B136	24	0	0	Oil level LOW: Bat- tery voltage
Tumble generator valve opening angle switch signal (LH)		B136	9	0	Fully closed: 0.5 or less Fully opened: 4.5 or more	While operating: Waveform
Tumble generator valve actuator (LH open)		B134	23	0	0	While operating: Waveform
Tumble generator valve actuator (LH closed)		B134	24	0	0	While operating: Waveform
Tumble generator valve opening angle switch signal (RH)		B136	23	0	Fully closed: 0.5 or less Fully opened: 4.5 or more	While operating: Waveform
Tumble generator valve actuator (RH open)		B134	25	0	0	While operating: Waveform
Tumble generator valve actuator (RH closed)		B134	14	0	0	While operating: Waveform
Immobilizer communication		B135	25	—	—	—
ELCM	Switching valve	B135	1	Battery voltage	Battery voltage	Operating: 0
	Pressure sensor	B135	20	1 — 4	1 — 4	—
	Vacuum pump	B135	8	Battery voltage	Battery voltage	Operating: 0
Ground	Sensor	B134	29	0	0	—
		B135	30	0	0	—
	Engine 1	B134	4	0	0	—
	Engine 2	B134	3	0	0	—
	Engine 3	B136	1	0	0	—
	Engine 4	B136	2	0	0	—
	Engine 5	B136	3	0	0	—
Body		B137	4	0	0	—

#### NOTE:

- Measurement should be performed after warming up the engine.
- Place the select lever in “P” range or “N” range.
- Turn the A/C to OFF.
- Turn all the accessory switches to OFF.
- Waveforms vary depending on a measurement environment and vehicle condition.

## Input/output name:

- Crankshaft position sensor
- Intake camshaft position sensor RH
- Intake camshaft position sensor LH
- Exhaust camshaft position sensor RH
- Exhaust camshaft position sensor LH
- At idling



EN-10986

(A) Magnified waveform of crankshaft position sensor and camshaft position sensor


## Control Module I/O Signal

### ENGINE (DIAGNOSTICS)


#### NOTE:

- For measuring the waveforms of the crankshaft position sensor, use of oscilloscope function of DST-i or an ordinary oscilloscope is recommended.
- If the oscilloscope function of the Subaru Select Monitor is used, the waveform of the crankshaft position sensor may be shown as in diagram (B).

This is not a malfunction of the Subaru Select Monitor or crankshaft position sensor, because the unit of output from the crankshaft position sensor is smaller than the minimal measurement unit of the Subaru Select Monitor.




EN-11068



EN-11626

# Control Module I/O Signal

## ENGINE (DIAGNOSTICS)




EN-10729



# Control Module I/O Signal


ENGINE (DIAGNOSTICS)



EN-11628

# Control Module I/O Signal

ENGINE (DIAGNOSTICS)



EN-10601