

11.Drain Filter

A: REMOVAL

The drain filter is installed to the leak check valve assembly. Refer to “Leak Check Valve Assembly” for removal procedure. <Ref. to EC(H4DO(HEV))-39, REMOVAL, Leak Check Valve Assembly.>

B: INSTALLATION

The drain filter is installed to the leak check valve assembly. Refer to “Leak Check Valve Assembly” for installation procedure. <Ref. to EC(H4DO(HEV))-42, INSTALLATION, Leak Check Valve Assembly.>

C: INSPECTION

- 1) Check that the drain filter and drain bracket have no deformation, crack, or other damage.
- 2) Check that the drain tube has no cracks, damage or loose part.
- 3) Check that no foreign substances are clogged in the drain filter.