

4. Control Module I/O Signal

A: ELECTRICAL SPECIFICATION

1. ENGINE CONTROL MODULE (ECM)

For details on the input/output signals for the engine control module, refer to ENGINE (DIAGNOSTICS). <Ref. to EN(H4DO HEV)(diag)-19, ELECTRICAL SPECIFICATION, Control Module I/O Signal.>

2. HYBRID POWERTRAIN CONTROL MODULE (HPCM)

For details on the input/output signals of the hybrid powertrain control module, refer to HEV (DIAGNOSTICS). <Ref. to HEV(diag)-10, HYBRID POWERTRAIN CONTROL MODULE (HPCM), ELECTRICAL SPECIFICATION, Control Module I/O Signal.>

B: WIRING DIAGRAM

Refer to “Cruise Control System” in the wiring diagram. <Ref. to WI(HEV)-82, WIRING DIAGRAM, Cruise Control System.>