



oder in der Garage aufbewahren, um den natürlichen Alterungsprozess der Materialien zu verlangsamen.

Wickey-Spielgeräte sind ausschließlich für die private Nutzung vorgesehen, da bei öffentlichen Spielgeräten weitere Sicherheitsauflagen erforderlich sind. Ersatzteile oder Verschleißteile können Sie jederzeit über unseren Shop [www.wickey.de](http://www.wickey.de) bestellen.

Wir wünschen Ihnen und Ihren Kindern viel Vergnügen mit unseren Spielgeräten. Bei Fragen stehen wir Ihnen selbstverständlich gerne zur Verfügung.

Ihr Wickey-Team

## EN

### General safety information

Congratulations on the purchase of your Wickey climbing frame. The purchased product is expandable at any time, so years of fun are guaranteed. Our systems meet the latest safety requirements: the used materials comply with the **European standards, according to EN 71 parts 1 and 8 for private use**. All woods are pressure impregnated and thus protected from the elements. Our playground equipment is examined with the utmost care to ensure the necessary safety.

- ▶ Please use only original Wickey components and add-on parts.
- ▶ For domestic use only!
- ▶ Suitable for children between 3 and 14 years old.
- ▶ Maximum load capacity: **100 kg**.
- ▶ For outdoor use only!

### Safety instructions for assembly:

- ▶ The product may only be assembled by adults.
- ▶ Make sure that no children are present during the installation of

the play equipment.

- ▶ The climbing frame may only be used after the complete inspection of all attachments.
- ▶ Read the installation instructions carefully and keep these instructions for future adjustments or extensions
- ▶ Wear suitable protective clothing, such as safety glasses, and gloves, during the assembly.
- ▶ Do not step onto the platform until the playground equipment is completely assembled.
- ▶ In order to ensure the stability of the climbing frame, you should use ground anchors and fix them in concrete.
- ▶ Make sure that the ground anchors disappear into the ground completely, to prevent tripping hazards.

### Safety distances

- ▶ The distance between the swing seat and the floor should be at least **35 cm**.
- ▶ The distance between the individual swing seats and other swinging products should be at least **45 cm**.
- ▶ The distance to the frame should be at least **30 cm**.

### Surroundings and underground

- ▶ Make sure that the surface is not too hard in terms of shock absorption. Loosen it, if necessary, or equip the ground with fall protection mats, which are also available in our shop.
- ▶ All hard floors such as concrete surfaces, asphalt, etc. are unsuitable as there is a high risk of injury for your children.
- ▶ Also check the immediate surroundings of the climbing frame (a radius of at least 2 meters) for hazards such as branches, clothes lines or other obstacles.

### Inappropriate use

Improper use or the attachment of inappropriate or foreign materials such as heavy chains, poles or ropes release the manufacturer from his responsibility. The same applies to incorrect assembly. Do not deviate from the assembly instructions and do not change the design and implementation.

### Supervision

Keep in mind that adult supervision is mandatory and essential while children play on these devices. Children under 3 years of age are not allowed to use the playground equipment.

### Maintenance

At the beginning of each season and every two weeks during the season, check the strength of the screws and hooks. Note, however, that over-tightened screws can cause cracks in the wood. Also check the fastening material, fittings and swing hooks for any signs of wear or rust. Also check the anchors and replace them in case of defects. In addition, all moving metal parts must be lubricated on a regular basis. Also check all the screw covers and sharp edges and replace them or grind them off if necessary. Check the wooden parts for splinters and cracks, which can naturally occur during the drying process. Remove any splinters that may have developed during this process. Swing seats, chains, ropes and other accessories must be checked for signs of wear. Defective parts must be replaced in accordance with the manufacturer's instructions. Lack of inspection can cause the climbing frame to overturn or can have other dangerous effects.



### Wood treatment

Since all wooden parts are pre-treated (pressure impregnated) there is no need for further treatment



against weathering or decay. Under no circumstances should you paint the wood or use a paint that could result in a slippery/smooth surface.

### Maintenance of plastics

For cleaning the plastic parts, we recommend tap water with detergent. In wintertime, you should store the plastic parts in the house or garage to slow down the natural aging process of the materials.

Wickey's play equipment is intended for private use only, as additional safety requirements are required for public play equipment. Spare parts can be ordered via our webshop: [www.wickey.com](http://www.wickey.com)

We wish you and your children a lot of fun with your Wickey product. If you have any questions, please do not hesitate to contact us.

Your Wickey Team

**NL**

### Algemene veiligheidsvoorschriften

Van harte gefeliciteerd met de koop van een Wickey speelsysteem. De gekochte producten zijn ten allen tijde uit te breiden, zo is jarenlange speelvreugde gegarandeerd. Onze systemen voldoen aan de actuele veiligheidsvoorschriften en de gebruikte materialen voldoen aan de Europese normen EN 71 deel 1 en deel 8 voor privégebruik. Het hout is geïmpregneerd en zo voor weersinvloeden veiliggesteld. Deze speeltoestellen zijn met grote zorg getest, om de nodige veiligheid te garanderen.

- ▶ Gebruik enkel originele Wickey bouwonderdelen en uitbreidingsonderdelen.
- ▶ Alleen voor privégebruik.
- ▶ Geschikt voor kinderen tussen 3 en 14 jaar.

- ▶ Maximale draaglast: 100 kg.
- ▶ Alleen voor buitengebruik.

### Veiligheidsvoorschriften bij de opbouw

- ▶ Bouw het product op enkel met volwassenen.
- ▶ Zorg ervoor dat gedurende het opbouwen van het speeltoestel geen kinderen aanwezig zijn.
- ▶ Gebruik het speelterrein pas na volledige montage van het speeltoestel en controle van alle onderdelen en verbindingen.
- ▶ Lees de montagehandleiding zorgvuldig door en bewaar deze handleiding voor latere aanpassingen of uitbreidingen.
- ▶ Draag bij de montage passende beschermende kleding, evenals veiligheidsbril en handschoenen.
- ▶ Betreed het platform niet, zolang het speeltoestel niet compleet opgebouwd is.
- ▶ Om de stabiliteit van de speeltoren te garanderen, moet u beslist verankeringen toepassen en deze in beton gieten.
- ▶ Let u er op dat de ankers correct bevestigd worden, zodat deze geen struikelplek kunnen zijn.

### Veilige afstanden

- ▶ De schommel moet minimaal 35 cm afstand tot de ondergrond hebben.
- ▶ De afstand tot de enkele schommel en de andere schommelende onderdelen moet minimaal 45 cm bedragen.
- ▶ De afstand tot aan het toestel moet minimaal 30 cm bedragen.

### Omgeving en ondergrond

- ▶ Verzeker u ervan dat de ondergrond in verband met het dempen van een val niet te hard is. Zorg ervoor dat de ondergrond schokabsorberend is. Gebruik hiervoor bijvoorbeeld rubberen veiligheidstegels, deze zijn tevens in onze shop verkrijgbaar.
- ▶ Gebruik beslist geen harde

ondergrond zoals beton, asfalt etc. Hierdoor kunnen uw kinderen ernstige verwondingen oplopen.

- ▶ Controleer de directe omgeving van het toestel ook op gevaren zoals, takken, waslijnen of rondslingerende voorwerpen.

### Foutief gebruik

Foutief gebruik of het aanbrengen van niet geschikte of ongebruikelijke materialen zoals zware kettingen, stangen of touwen ontslaat de producent van elke verantwoordelijkheid. Hetzelfde geldt voor foutieve montage. Wijk niet af van de montagehandleiding en verander niets aan het design of de uitvoering.

### Toezicht

Wees u ervan bewust dat toezicht van volwassenen verplicht en noodzakelijk is, wanneer de kinderen op deze toestellen spelen. Kinderen onder 3 jaar mogen deze speeltoestellen helaas nog niet gebruiken.

### Inspectie

Controleer elke twee weken of de schroeven en haken nog vast zitten. Houd er rekening mee dat te vastgedraaide schroeven scheuren in het hout kunnen veroorzaken. Controleer eveneens het bevestigingsmateriaal, beslag en schommelhaken op eventueel verslijt of roest, evenals de bevestiging van de verankering. Vervang de onderdelen bij gebreken. Controleer de houten onderdelen op splinters en scheuren, die door weersomstandigheden van nature kunnen ontstaan bij het drogen. Verwijder deze indien aanwezig.

### Onderhoud van het hout

Elk speeltoestel is gemaakt van geïmpregneerd hout en is op die manier voldoende beschermd tegen weer invloeden en rotting. U mag het hout in geen geval voorzien van lak