

During the sugar making process, the cotton candy produced is particularly frizzy and the sugar strands are relatively thick and shapeless

Type

Issue

Solution

Stove cover gap is most likely clogged. Replace or clean the burner cover.

Created by

J Jason Lopez