

# There was sugar on the paper stick during crafting, but the paper stick fell into furnace or was bent.

Type

Issue

Solution

The roller of the utility knife was not cleaned, it got stuck because of sugar and could not move. Clean the utility knife with a dampened cloth.

Created by

 Jason Lopez