



Mr Pop

User's Manual

Version Number 20230914



Important Notice

- * Please read the manual firstly before the machine is used.
- * Please keep this manual well so that the user could read it at any time.
- * Product will be improved constantly, and the manufacturer reserves the right to change the manual without notification.

Matters to Attention

Notice

- ◆ DO NOT place the machine in a place that is uneven, tilted or easy to be shaken.
- ◆ Check the wires condition regularly once a week and check the machine comprehensively every month.
- ◆ Please prepare the small fire extinguisher to ensure the workplace safety and turn off the power when the staff is off work.
- ◆ Take care of wires and prevent pest from damaging wires.
- ◆ DO NOT place the machine where the sunlight shines directly to avoid to damage the internal parts of the machine.

Warning

- ◆ Machine should be connected to ground wire and its three - hole plug should be inserted into the power socket with the ground wire.
- ◆ There are precision parts in the machine, please do not drop it or make it to physical impact.
- ◆ DO NOT place the machine close to objects with high magnetic fields or strong radio waves.
- ◆ Machine is not waterproof, to avoid fire or electric shock, please don't make any liquid in the machine or expose it to the environment of dripping water or moisture.
- ◆ Machine is not fireproof, please do not place it close to any fire source.

Danger

- ◆ DO NOT touch the power plug with wet hands.
- ◆ DO NOT scratch, cut off or over-bend the power cord.
- ◆ DO NOT place heavy objects on the power cord.
- ◆ DO NOT use power cords with damaged insulation.
- ◆ DO NOT allow non - p rofessionals to inspect or repair the machine at will, turn off the power when the machine is inspected or repaired.

Table of Contents

I. Specifications and Spare Parts	1
1. Parameters.....	1
2. Spare Parts	1
3. Equipment size parameters.....	1
II. How to Play	2
III. Appearance Introduction	2
1. Frond View.....	2
2. Front Inner View	3
3. Back Inner View.....	3
IV. Power On Self Test	4
1. Contents of Power-on Self-test.....	4
2. Error Codes	4
V. Backstage Setting	5
1. Setting Panel.....	5
2. Setting Button Introduction.....	5
3. Candy Shelf Life Setting.....	6
4. Management Setting Menu.....	6
VI. Electrical Diagram	11
VII. Motherboard Diagram	12
VIII. Maintenance	13
IX. Warranty Terms	13

I. Specifications and Spare Parts

1. Parameters

Name: Mr. Pop

Size: D2.68*W2.33*H5.14(ft)

Weight: 65KGS

Power: 50W

(If the specifications are changed according to improvements in performance and design, there will be without prior notice.)

2. Spare Parts





No.	Name	Quantity
1	Key	1
2	Power cord	1
3	Manual	1
4	Turntable belt	1

Check above spare parts firstly before using machine, if any parts are missing, please contact us.

3. Equipment size parameters




II. How to Play

1. Insert Bills 
2. Press the Button to Start 
3. Press the Button to Stop 
4. Get Your Prize 

III. Appearance Introduction

1. Front View




If the lollipops can not be released, it may be caused by lollipops shortage, or lollipop blocked on the turntable. Please remove the stuck lollipops and press Start Button to pay it out.

2. Front Inner View



3. Back Inner View



IV. Power On Self Test

1. Contents of Power-on self-test:

(1) Start button (2) Setting button (3) Prize out sensor

Note: Please don't touch the Start Button or other parts of machine to avoid the machine occurs errors.

2. Error Codes

Error Code	Error part	Error Reason	Troubleshooting
E1	Start Button Fault	1. Damage of start button if it can't up-spring; 2. Damage of button micro switch.	1. Renew button; 2. Renew micro switch.
E2	Setting Button Failure	1. The button cannot bounce; 2. The button is damaged; 3. The connecting wire is short circuited.	1. Replace the setting board; 2. Check whether the wire is short circuited.
E3	Lollipop Shortage, Lollipop Stuck-in, Turntable Motor Damage, Prize-out Sensor Damage.	1. Lollipop shortage; 2. Lollipop is stuck-in; 3. Prize-out sensor damage; 4. Turntable motor damage; 5. Motherboard damage.	1. Replenish lollipop; 2. Remove lollipop; 3. Renew sensor; 4. Renew motor 5. Renew/repair motherboard.
E4	Motherboard Fault	Motherboard memory fault	Renew/repair motherboard.


Start button (reset button) doesn't work

1. Check start button and motherboard plug and the wires from motherboard plug to start button plug
2. Whether there are lollipops stuck in side-way.
3. Whether the prize sensor red light is always on (red light will only be on when the prize is detected). When there is no lollipop stuck-in, but the red light is always on, prize out sensor is damaged.
4. Check if the motor gear fixing screws and belts are loose.
Press start button within 24 seconds, unplug the prize out sensor, then test the turntable motor voltage
If the turntable motor has power voltage, then the motor not work. That motor damaged.
If the turntable motor has no power voltage, then the motherboard damaged.

How to use start button(reset button): When the machine occurs lollipop shortage or lollipop is stuck-in, open the transparent cover and press the red Start Button, the prize turntable will re-rotate and the error code will disappear after the lollipop-out is restored successfully.

V. Backstage Setting

1. Setting Panel



2. Setting button introduction

Button name	Press	Press and hold
Up button	Last setting item	
Down button	Next setting item	
Left button	Reduce	
Right button	Add	
Setting button (confirm button)	Set default data, confirm Note: choose “yes”, and press the setting button can set factory setting	Enter/exit setting
Menu	1 Free play	

3. Candy Shelf-Life Setting

While the machine is off, adjust DIP #1 then turn on machine.

DIP 1=OFF, will not show candy shelf-life

DIP 1=ON, standby screen will show candy shelf-life

Press and hold Settings button: enter or exit setting for candy shelf life

Up & Down button: set number

Left & Right: to change number position



4. Management Setting Menu

Open the front door, press and hold setting button to enter management setting menu.

(1) Credits: 0-10

Setting to 0 will enable unlimited Free plays.



(2) Difficulty Level

0: Win rate not controlled (Random)

The screenshot shows the 'Difficulty Level' menu. A central table displays various difficulty levels from 0 to 13. The table has columns for 'Difficulty level', 'Prize rate', 'Total numbers of ballpays-out per 100 plays', and 'Uncontrollable Rate' (which is further divided into '1' number of times, '2' number of times, '3' number of times, '4' number of times, and '5' number of times). The row for difficulty level 9 is highlighted in pink. Below the table, a text prompt says 'Press and hold the setting button to save and exit setting'. The 'Parameter Setting' button is located at the top center of the menu.

Difficulty level	Prize rate	Total numbers of ballpays-out per 100 plays	Uncontrollable Rate				
			'1' number of times	'2' number of times	'3' number of times	'4' number of times	'5' number of times
0							
1	1.8	180	55	25	9	7	4
2	1.7	170	59	24	8	6	3
3	1.6	160	63	23	7	5	2
4	1.5	150	68	21	6	3	2
5	1.4	140	72	20	5	2	1
6	1.3	130	78	16	4	2	0
7	1.2	120	84	13	2	1	0
8	1.1	110	90	10	0	0	0
9	1.0	100	100	0	0	0	0
10	1.51	151	66	23	6	4	1
11	1.51	151	66	22	9	1	2
12	1.61	161	66	21	2	8	3
13							

Every three times 1 to be 2 and every tenth time to be 3 or 4.

(4) Demo Volume (0-8)

0: No sound (Mute)

The screenshot shows the 'Demo Volume' menu. A central display shows the number '4'. Below the display are two buttons: a minus sign (-) and a plus sign (+). A text prompt at the bottom says 'Press and hold the setting button to save and exit setting'. The 'Parameter Setting' button is located at the top center of the menu.

(3) Game Volume (0-8)

0: No sound (Mute)


The screenshot shows the 'Game Volume' menu. A central display shows the number '7'. Below the display are two buttons: a minus sign (-) and a plus sign (+). A text prompt at the bottom says 'Press and hold the setting button to save and exit setting'. The 'Parameter Setting' button is located at the top center of the menu.

(5) Game Time (10-60 seconds)

The screenshot shows the 'Game Time' menu. A central display shows the number '15'. Below the display are two buttons: a minus sign (-) and a plus sign (+). A text prompt at the bottom says 'Press and hold the setting button to save and exit setting'. The 'Parameter Setting' button is located at the top center of the menu.


(6) Number Light Twinkle

- 0: Twinkle slowly when in standby
Twinkle fast when insert credits
Light off during game time
- 1: Light off when in standby
Twinkle when insert coins
Light on during game time



(7) Factory Setting

Follow the prompts




(8) Version Information


Display the Version of the machine software.



VI. Electrical Diagram



VII. Motherboard Diagram



VIII. Maintenance

1. When there is dirt on the outer of the machine, please wipe it with a soft dry cloth. If the dirt is quite serious, wipe it with a soft cloth with 5-6 times diluted detergent, and then wipe with a dry cloth.
2. Never use alcohol or volatile solvent-based liquids to wipe , which will damage its surface treatment paint. Do not use cloth containing chemical agents to wipe or place it on the machine for a long time.

IX. Warranty Terms

To ensure the consumers could use our products with rest assured and satisfaction, we will reasonably stipulate our after-sale service system in strict accordance with relevant laws and regulations issued by the state.

1. Due to product's particularity, the product won't be refund once sold.
2. For all machines we sold, we will provide all technical support, including how to check account, difficulty adjustment, reset, various troubleshooting.

3. One-year Warranty: All machines are guaranteed within one year for non- human damage after receiving machines (except for the consumable parts);

Life- long Free Maintenance: When the free replacement or free warranty service expires after one year,we will continue providing technical service, for the part that need to be replaced, only charge the part cost and the maintenance fee is free, and the buyer need to responsible for the express cost.

4. Warranty period starts from the date the buyer receives the machine.
5. Warranty doesn't cover one of the following factors:
 - 5.1 All failures and damages caused by man-made, using in abnormal working environment,without following the manual to use, or without following the manual indication environment to use, etc.
 - 5.2 Without our consent and permission, user disassembles, repairs, or modifies the product, etc.
 - 5.3 Damage caused by poor transportation after purchasing the product.
 - 5.4 Damage caused by other irresistible factors (such as flood, lightning stroke, earthquake, abnormal voltage, etc).
 - 5.5 Normal use becomes old, abrasion, rupture or dip-dye etc.
 - 5.6 Product that doesn't belong to ours (such as fake, counterfeit product).