

SETUP GUIDE

MR. POP

After the machine is unboxed...

1. LOCATE KEYS

- The keys are a matching pair that open every compartment of machine.
- Open the lollipop chamber and load up your machine with your Sweet Robo Lollipops.
- Plug in machine.



2. SET YOUR PRICE

- Use your key to open the front panel of the machine.
- Press and hold the "Settings" button until settings menu appears.
- Select "Credits" with controller. (Press "Settings" button to select.) Choose your price.



3. SET YOUR DIFFICULTY

- Press and hold the "Settings" button until settings menu appears.
- Select "Difficulty Level" with controller. (Press "Settings" button to select.) Choose how often customers win.



4. SET VOLUME

- Press and hold the "Settings" button until settings menu appears.
- Select "Game Volume/Demo Volume" with controller. (Press "Settings" button to select.) Choose the volume of your Demo and Game.



5. SHELF LIFE DISPLAY (OPTIONAL)

- If you do not want the Shelf Life to display to customers, flip the "1" on the Dip Switch to the Off position in the back of machine.
- If you want it to display, keep Dip Switch in On position and adjust the date in settings menu.



6. 1 FREE PLAY TO TEST

- Now, you are ready to test Mr. Pop!
- Please open the front compartment of your machine and press the "Menu" button for a free test play.

