

## IRREGULAR WAVE RUNUP ON BEACHES

---

### TABLE OF CONTENTS

Description .....	5-1-1
Input .....	5-1-1
Output .....	5-1-1
Procedure .....	5-1-2
Single Case Mode .....	5-1-2
Multiple Case Mode .....	5-1-3
Example Problem .....	5-1-4
Input .....	5-1-4
Output .....	5-1-4
References and Bibliography .....	5-1-5

## IRREGULAR WAVE RUNUP ON BEACHES

---

### DESCRIPTION

This application provides an approach to calculate runup statistical parameters for wave runup on smooth slope linear beaches. To account for permeable and rough slope natural beaches, the present approach needs to be modified by multiplying the results for the smooth slope linear beaches by a reduction factor. However, there is no guidance for such a reduction due to the sparsity of good field data on wave runup. The approach used in this ACES application is based on existing laboratory data on irregular wave runup (Mase and Iwagaki, 1984; Mase, 1989).

### INPUT

All data input for this application is done on one screen. The following list describes the necessary input parameters with their corresponding units and range of data recognized by this application:

<u>Item</u>	<u>Symbol</u>	<u>Units</u>	<u>Data Range</u>		
Deepwater significant wave height	$H_{so}$	ft, m	0.1	to	100.0
Peak energy wave period	$T_p$	sec	0.1	to	100.0
Cotangent of foreshore slope	$\cot \theta$		0.1	to	100.0

### OUTPUT

Results from this application are displayed on one screen. Those data include the original input values (in final units) and the following parameter:

<u>Item</u>	<u>Symbol</u>	<u>English Units</u>	<u>Metric Units</u>
Runup			
Maximum runup	$R_{max}$	ft	m
Runup exceeded by 2 percent of the runups	$R_2$	ft	m

Average of the highest one-tenth of the runups	$R_{1/10}$	ft	m
Average of the highest one-third of the runups	$R_{1/3}$	ft	m
Average runup	$\bar{R}$	ft	m

## PROCEDURE

The bulleted items in the following lists indicate potentially optional instruction steps. Any application in ACES may be executed in a given session without quitting the program. The bulleted items provide instructions for accessing the application from various menu areas of the ACES program. Ignore bulleted instruction steps that are not applicable.

### Single Case Mode

- Press **(F1)** on the Main Menu to select Single Case Mode.
  - Fill in the highlighted input fields on the General Specifications screen (or leave the default values). Press **(F1)** when all data on this screen are correct.
  - Press **(F5)** on the Functional Area Menu to select Wave Runup, Transmission, and Overtopping.
  - Press **(F1)** on the Wave Runup, Transmission, and Overtopping Application Menu to select Irregular Wave Runup on Beaches.
1. Fill in the highlighted input fields on the Irregular Wave Runup on Beaches screen. Respond to any corrective instructions appearing at the bottom of the screen. Press **(F1)** when all data on this screen are correct.
  2. All input and output data are displayed on the screen in the final system of units.
  3. Press one of the following keys to select the appropriate action:
    - (F1)** Return to Step 1 for a new case.
    - (F3)** Send a summary of this case to the print file or device.
    - (F10)** Exit this application and return to the Wave Runup, Transmission, and Overtopping Menu.

### Multiple Case Mode

- Press **F2** on the Main Menu to select Multi Case Mode.
  - Fill in the highlighted input fields on the General Specifications screen (or leave the default values). Press **F1** when all data on this screen are correct.
  - Press **F5** on the Functional Area Menu to select Wave Runup, Transmission, and Overtopping.
  - Press **F1** on the Wave Runup, Transmission, and Overtopping Application Menu to select Irregular Wave Runup on Beaches.
1. Move the cursor to select a variable on the Irregular Wave Runup on Beaches screen (the selected variable name blinks). The current set of values for the variable is displayed on the right portion of the screen. When all variable sets are correct, go to Step 3.
  2. Enter a set of values for the subject variable by following one of the input methods:
    - a. Press **R** to select random method. Enter up to 20 values constituting a set for this variable (one in each field) on the right side of the screen. The set of 20 values originally displayed (first execution) in these fields contains the "delimiting" value, which "delimits" or "ends" the set. The "delimiting" value is *not* included as a member in the set unless it is the sole member.
    - b. Press **I** to select incremental method. Fill in the fields for minimum, maximum, and increment values for this variable on the right side of the screen. In this method, the members of the set include all values from the minimum to the maximum (both inclusive) at the specified increment.

The units field should also be specified for the variable regardless of input method. All members of a set of values for a subject variable are assigned the specified units. When all data are correct for the subject variable, press **F10** to return to Step 1. Errors are reported at the bottom of the screen and are corrected by pressing **F1** to allow respecification of the data for the subject variable.
  3. Press **F1** to process the cases resulting from the combinations of the sets of data for all variables. The summary of each case will be sent to the print file or device. The screen will display the total number of cases to be

processed as well as report progress. Errors are reported at the bottom of the screen and are corrected by pressing **(F1)** to allow respecification of variable sets.

4. Press one of the following keys to select the appropriate action:

- (F1)** Return to Step 1 to specify new sets.
- (F10)** Exit this application and return to the Wave Runup, Transmission, and Overtopping Menu.

## EXAMPLE PROBLEM

### Input

All data input for this application is done on one screen. The values and corresponding units selected for this first example problem are shown below.

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deepwater significant wave height	$H_{so}$	4.60	ft
Peak energy wave period	$T_p$	9.50	sec
Cotangent of foreshore slope	$\cot \theta$	13.00	

### Output

Results from this application are displayed on one screen. Those data include the original input values and the following parameters:

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Maximum runup	$R_{max}$	8.74	ft
Runup exceeded by 2 percent of the runups	$R_2$	7.11	ft
Average of the highest one-tenth of the runups	$R_{1/10}$	6.50	ft
Average of the highest one-third of the runups	$R_{1/3}$	5.29	ft
Average runup	$\bar{R}$	3.38	ft

## REFERENCES AND BIBLIOGRAPHY

- Hunt, I. A. 1959. "Design of Seawalls and Breakwaters," *Journal of the Waterway, Port, Coastal, and Ocean Engineering Division*, American Society Civil Engineers, Vol. 85, No. 3, pp. 123-152.
- Mase, H. 1989. "Random Wave Runup Height on Gentle Slopes," *Journal of the Waterway, Port, Coastal, and Ocean Engineering Division*, American Society Civil Engineers, Vol. 115, No. 5, pp. 649-661.
- Mase, H., and Iwagaki, Y. 1984. "Runup of Random Waves on Gentle Slopes," *Proceedings of the 19th International Conference on Coastal Engineering*, Houston, TX, American Society Civil Engineers, pp. 593-609.
- Walton, T. L., Jr., and Ahrens, J. P. 1989. "Maximum Periodic Wave Run-Up on Smooth Slopes," *Journal of the Waterway, Port, Coastal, and Ocean Engineering Division*, American Society Civil Engineers, Vol. 115, No. 5, pp. 703-708.
- Walton, T. L., Jr., Ahrens, J. P., Truitt, C. L., and Dean, R. G. 1989. "Criteria for Evaluating Coastal Flood-Protection Structures," Technical Report CERC-89-15, US Army Engineer Waterways Experiment Station, Vicksburg, MS.

## WAVE RUNUP AND OVERTOPPING ON IMPERMEABLE STRUCTURES

---

### TABLE OF CONTENTS

Description .....	5-2-1
Input .....	5-2-1
Output .....	5-2-3
Procedure .....	5-2-3
Single Case Mode .....	5-2-3
Multiple Case Mode .....	5-2-5
Example Problems .....	5-2-7
Example 1 - Monochromatic Wave - Rough Slope Runup (Riprap) .....	5-2-7
Example 2 - Monochromatic Wave - Smooth Slope Runup .....	5-2-8
Example 3 - Monochromatic Wave - Rough Slope Overtopping .....	5-2-9
Example 4 - Monochromatic Wave - Smooth Slope Overtopping .....	5-2-10
Example 5 - Monochromatic Wave - Rough Slope Runup and Overtopping (Riprap) .....	5-2-11
Example 6 - Monochromatic Wave - Smooth Slope Runup and Overtopping .....	5-2-12
Example 7 - Irregular Wave - Rough Slope Runup and Overtopping (Riprap) ..	5-2-13
Example 8 - Irregular Wave - Smooth Slope Runup and Overtopping .....	5-2-14
References and Bibliography .....	5-2-15

## WAVE RUNUP AND OVERTOPPING ON IMPERMEABLE STRUCTURES

### DESCRIPTION

This application provides estimates of wave runup and overtopping on rough and smooth slope structures that are assumed to be impermeable. Run-up heights and overtopping rates are estimated independently or jointly for monochromatic or irregular waves specified at the toe of the structure. The empirical equations suggested by Ahrens and McCartney (1975), Ahrens and Titus (1985), and Ahrens and Burke (1987) are used to predict runup, and Weggel (1976) to predict overtopping. Irregular waves are represented by a significant wave height and are assumed to conform to a Rayleigh distribution (Ahrens, 1977). The overtopping rate is estimated by summing the overtopping contributions from individual runups in the distribution.

### INPUT

The terminology used to define wave runup is shown in Figure 5-2-1.




Figure 5-2-1. Wave Runup and Overtopping

All data input for this application is done on one screen. The following list describes the necessary input parameters with their corresponding units and range of data recognized by this application:



<u>Mandatory Item</u>	<u>Symbol</u>	<u>Units</u>	<u>Data Range</u>		
Incident wave height	$H_i$	ft, m	0.1	to	100.0
Wave period	$T$	sec	1.0	to	1000.0
Cotan of nearshore slope	$\cot \phi$		5.0	to	10000.0
Water depth at structure toe	$d_s$	ft, m	0.1	to	200.0
Cotan of structure slope	$\cot \Theta$		0.0	to	30.0

**NOTE:** For vertical walls, specify 0.0.

Structure height above toe	$h_s$	ft, m	0.0	to	200.0
----------------------------	-------	-------	-----	----	-------

The above input variables are mandatory. In addition, the following input variables are required under the specified circumstances:

<u>Item</u>	<u>Symbol</u>	<u>Source</u>
<u>Rough slope runup</u>		
Empirical coefficient	$a$	See Table A-3 of Appendix A
Empirical coefficient	$b$	for suggested values.

#### Overtopping

Empirical coefficient	$\alpha$	See Figures 7-24 to 7-34 in the
Empirical coefficient	$Q^*_0$	SPM (1984).

<u>Item</u>	<u>Symbol</u>	<u>Units</u>	<u>Data Range</u>		
Onshore wind velocity	$U$	kn, ft/sec mph, m/sec, kph	0.0	to	200.0
Wave runup (if known)	$R$	ft, m	0.0	to	100.0

**NOTE:** For irregular waves, substitute the following:

Incident significant wave height	$(H_s)$	for	$H_i$
Peak wave period	$(T_p)$	for	$T$

## OUTPUT

Results from this application are displayed on one screen. Those data include the original input values (in final units) and the following parameters:

<u>Item</u>	<u>Symbol</u>		<u>English Units</u>	<u>Metric Units</u>
	monochromatic waves	irregular waves		
Deepwater				
Wave height	$H_0$	$H_{s0}$	ft	m
Relative height	$d_s/H_0$	$d_s/H_{s0}$		
Wave steepness	$H_0/gT^2$	$H_{s0}/gT^2$		
Runup	$R$ (if requested)	$R_s$	ft	m
Overtopping rate	$Q$ (if requested)	$Q$	ft <sup>3</sup> /sec-ft	m <sup>3</sup> /sec-m

The deepwater wave parameters are provided as an aid to determining the empirical overtopping coefficients from the referenced figures in the SPM (1984).

## PROCEDURE

The bulleted items in the following lists indicate potentially optional instruction steps. Any application in ACES may be executed in a given session without quitting the program. The bulleted items provide instructions for accessing the application from various menu areas of the ACES program. Ignore bulleted instruction steps that are not applicable.

### Single Case Mode

- ° Press **(F1)** on the Main Menu to select Single Case Mode.
- ° Fill in the highlighted input fields on the General Specifications screen (or leave the default values). Press **(F1)** when all data on this screen are correct.
- ° Press **(F5)** on the Functional Area Menu to select Wave Runup, Transmission, and Overtopping.
- ° Press **(F2)** on the Wave Runup, Transmission, and Overtopping Application Menu to select Wave Runup and Overtopping on Impermeable Structures.
- ° On the Wave Runup and Overtopping on Impermeable Structures Menu, press one of the following:

*Selections for Monochromatic Waves*

- F1** Estimate runup on rough slope structures.
- F2** Estimate runup on smooth slope structures.
- F3** or **F4** Estimate overtopping rate with a known run-up value.
- F5** Estimate both runup and overtopping rate on rough slope structures.
- F6** Estimate both runup and overtopping rate on smooth slope structures.

*Selections for Irregular Waves*

- F7** or **F8** Estimate overtopping rate with a known run-up value.

1. Fill in the highlighted input fields on the Wave Runup and Overtopping on Impermeable Structures screen. Respond to any corrective instructions appearing at the bottom of the screen. Press **F1** when all data on this screen are correct.

**NOTE:** If the selected case involved the computation of rough slope runup, **F10** may be pressed to provide access to the additional following options (choose one):

- F1** Return to the input screen.
- F2** Display a table of suggested rough slope run-up empirical coefficients ( $a$  and  $b$ ). If this option is selected, these coefficients must be entered in the designated fields of the display screen. The data thus given will be transferred back to (and displayed on) the main input screen when **F1** is pressed.
- F10** Exit the application.

2. All input and output data are displayed on the screen in the final system of units.

3. Press one of the following keys to select the appropriate action:

- F1** Return to Step 1 for a new case.
- F3** Send a summary of this case to the print file or device.
- F10** Exit this application and return to the Wave Runup, Transmission, and Overtopping Menu.

### Multiple Case Mode

Run-up values are provided in this operational mode, but overtopping rates are excluded because of possible functional dependencies between incident wave conditions, structure slope, and the empirical overtopping coefficients. Single Case or Batch Modes may be used to process cases providing overtopping rates.

- Press **F2** on the Main Menu to select Multi Case Mode.
- Fill in the highlighted input fields on the General Specifications screen (or leave the default values). Press **F1** when all data on this screen are correct.
- Press **F5** on the Functional Area Menu to select Wave Runup, Transmission, and Overtopping.
- Press **F2** on the Wave Runup, Transmission, and Overtopping Application Menu to select Wave Runup and Overtopping on Impermeable Structures.
- On the Wave Runup and Overtopping on Impermeable Structures Menu, press one of the following:

**F1** Estimate runup on rough slope structures.

**NOTE:** Selection of this option will display the table of suggested rough slope run-up empirical coefficients ( $a$  and  $b$ ). Fill in the highlighted input fields with the values for these items, and press **F1** to resume input on the main input screen, or press **F10** to exit the application.

**F2** Estimate runup on smooth slope structures.

1. Move the cursor to select a variable on the Wave Runup and Overtopping on Impermeable Structures screen (the selected variable name blinks). The current set of values for the variable is displayed on the right portion of the screen. When all variable sets are correct, go to Step 3.
2. Enter a set of values for the subject variable by following one of the input methods:
  - a. Press **R** to select random method. Enter up to 20 values constituting a set for this variable (one in each field) on the right side of the screen. The set of 20 values originally displayed (first execution) in these fields contains the "delimiting" value, which "delimits" or "ends" the set. The "delimiting" value is *not* included as a member in the set unless it is the sole member.

- b. Press **I** to select incremental method. Fill in the fields for minimum, maximum, and increment values for this variable on the right side of the screen. In this method, the members of the set include all values from the minimum to the maximum (both inclusive) at the specified increment.

The units field should also be specified for the variable regardless of input method. All members of a set of values for a subject variable are assigned the specified units. When all data are correct for the subject variable, press **F10** to return to Step 1. Errors are reported at the bottom of the screen and are corrected by pressing **F1** to allow respecification of the data for the subject variable.

3. Press **F1** to process the cases resulting from the combinations of the sets of data for all variables. The summary of each case will be sent to the print file or device. The screen will display the total number of cases to be processed as well as report progress. Errors are reported at the bottom of the screen and are corrected by pressing **F1** to allow respecification of variable sets.
4. Press one of the following keys to select the appropriate action:

- F1** Return to Step 1 to specify new sets.
- F10** Exit this application and return to the Wave Runup, Transmission, and Overtopping Menu.

**EXAMPLE PROBLEMS****Example 1 - Monochromatic Wave - Rough Slope Runup (Riprap)****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	12.50	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	20.00	ft

**Rough slope run-up item**

Empirical coefficient	$a$	0.956	
Empirical coefficient	$b$	0.398	

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deep water			
Wave height	$H_0$	6.386	ft
Relative height	$d_s/H_0$	1.957	
Wave steepness	$H_0/gT^2$	0.002	
Runup	$R$	9.421	ft

**Example 2 - Monochromatic Wave - Smooth Slope Runup****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	12.50	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	20.00	ft

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deep water			
Wave height	$H_0$	6.386	ft
Relative height	$d_s/H_0$	1.957	
Wave steepness	$H_0/gT^2$	0.002	
Runup	$R$	21.366	ft

**Example 3 - Monochromatic Wave - Rough Slope Overtopping****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	12.50	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	20.00	ft

**Overtopping item**

Empirical coefficient (computed)	$\alpha$	0.076463	
Empirical coefficient	$Q^*_0$	0.025	
Onshore wind velocity	$U$	35.000	kn
Wave runup (if known)	$R$	15.000	ft

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deep water			
Wave height	$H_0$	6.386	ft
Relative height	$d_s/H_0$	1.957	
Wave steepness	$H_0/gT^2$	0.001985	
Overtopping rate	$Q$	3.565	ft <sup>3</sup> /sec-ft



**Example 4 - Monochromatic Wave - Smooth Slope Overtopping****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	12.50	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	20.00	ft

**Overtopping item**

Empirical coefficient (computed)	$\alpha$	0.076463	
Empirical coefficient	$Q^*_0$	0.025	
Onshore wind velocity	$U$	35.000	kn
Wave runup (if known)	$R$	20.000	ft

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deep water			
Wave height	$H_0$	6.386	ft
Relative height	$d_s/H_0$	1.957	
Wave steepness	$H_0/gT^2$	0.001985	
Overtopping rate	$Q$	5.368	ft <sup>3</sup> /sec-ft

### Example 5 - Monochromatic Wave - Rough Slope Runup and Overtopping (Riprap)

#### Input

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	12.50	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	20.00	ft

#### Rough slope run-up item

Empirical coefficient	$a$	0.956	
Empirical coefficient	$b$	0.398	

#### Overtopping item

Empirical coefficient (computed)	$\alpha$	0.076463	
Empirical coefficient	$Q^*_0$	0.025	
Onshore wind velocity	$U$	35.000	kn

#### Output

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deep water			
Wave height	$H_0$	6.386	ft
Relative height	$d_s/H_0$	1.957	
Wave steepness	$H_0/gT^2$	0.001985	
Runup	$R$	9.421	ft
Overtopping rate	$Q$	0.829	ft <sup>3</sup> /sec-ft

**Example 6 - Monochromatic Wave - Smooth Slope Runup and Overtopping****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	12.50	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	20.00	ft

**Overtopping item**

Empirical coefficient (computed)	$\alpha$	0.076463	
Empirical coefficient	$Q^*_0$	0.025	
Onshore wind velocity	$U$	35.000	kn

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deep water			
Wave height	$H_0$	6.386	ft
Relative height	$d_s/H_0$	1.957	
Wave steepness	$H_0/gT^2$	0.001985	
Runup	$R$	21.366	ft
Overtopping rate	$Q$	5.771	ft <sup>3</sup> /sec-ft

**Example 7 - Irregular Wave - Rough Slope Runup and Overtopping (Riprap)****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_s$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	12.50	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	20.00	ft

**Rough slope run-up item**

Empirical coefficient	$a$	0.956	
Empirical coefficient	$b$	0.398	

**Overtopping item**

Empirical coefficient (computed)	$\alpha$	0.076463	
Empirical coefficient	$Q^*_0$	0.025	
Onshore wind velocity	$U$	35.000	kn

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deep water			
Wave height	$H_{s0}$	6.386	ft
Relative height	$d_s/H_{s0}$	1.957	
Wave steepness	$H_{s0}/gT^2$	0.001985	
Runup	$R_s$	9.421	ft
Overtopping rate	$Q$	0.287	ft <sup>3</sup> /sec-ft

**Example 8 - Irregular Wave - Smooth Slope Runup and Overtopping****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_s$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	12.50	ft
Cotan of structure slope	$\cot \theta$	3.00	
Structure height above toe	$h_s$	20.00	ft

**Overtopping item**

Empirical coefficient (computed)	$\alpha$	0.076463	
Empirical coefficient	$Q^*_0$	0.025	
Onshore wind velocity	$U$	35.000	kn

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Deep water			
Wave height	$H_{s0}$	6.386	ft
Relative height	$d_s/H_0$	1.957	
Wave steepness	$H_{s0}/gT^2$	0.001985	
Runup	$R_s$	21.366	ft
Overtopping rate	$Q$	2.728	ft <sup>3</sup> /s-ft

## REFERENCES AND BIBLIOGRAPHY

- Ahrens, J. P. 1977. "Prediction of Irregular Wave Overtopping," CERC CETA 77-7, US Army Engineer Waterways Experiment Station, Vicksburg, MS.
- Ahrens, J. P., and Burke, C. E. 1987. Unpublished report of modifications to method cited in above reference.
- Ahrens, J. P., and McCartney B. L. 1975. "Wave Period Effect on the Stability of Riprap," *Proceedings of Civil Engineering in the Oceans/III*, American Society of Civil Engineers, pp. 1019-1034.
- Ahrens, J. P., and Titus, M. F. 1985. "Wave Runup Formulas for Smooth Slopes," *Journal of Waterway, Port, Coastal and Ocean Engineering*, American Society of Civil Engineers, Vol. 111, No. 1, pp. 128-133.
- Battjes, J. A. 1974. "Surf Similarity," *Proceedings of the 14<sup>th</sup> Coastal Engineering Conference*, Copenhagen, Denmark.
- Dean, R. G. 1974. "Evaluation and Development of Water Wave Theories for Engineering Applications," Vols. 1-2, CERC Special Report No. 1, US Army Engineer Waterways Experiment Station, Vicksburg, MS.
- Douglass, S. L. 1986. "Review and Comparison of Methods for Estimating Irregular Wave Overtopping Rates," Technical Report CERC-86-12, US Army Engineer Waterways Experiment Station, Vicksburg, MS, pp. 6-14.
- Goda, Y. 1983. "A Unified Nonlinearity Parameter of Water Waves," *Report of the Port and Harbour Research Institute*, Vol. 22, No. 3, pp. 3-30.
- Saville, T., Jr. 1955. "Laboratory Data on Wave Run-Up and Overtopping on Shore Structures," TM No. 64, US Army Corps of Engineers, Beach Erosion Board, Washington, DC.
- Saville, T., Jr., and Caldwell, J. M. 1953. "Experimental Study of Wave Overtopping on Shore Structures," *Proceedings, Minnesota International Hydraulics Convention*, Minneapolis, MN.
- Seelig, W. N. 1980. "Two-Dimensional Tests of Wave Transmission and Reflection Characteristics of Laboratory Breakwaters," CERC TR 80-1, US Army Engineer Waterways Experiment Station, Vicksburg, MS.
- Shore Protection Manual*. 1984. 4th ed., 2 Vols., US Army Engineer Waterways Experiment Station, Coastal Engineering Research Center, US Government Printing Office, Washington, DC, Chapter 7, pp. 43-58.
- Smith, O. P. 1986. "Cost-Effective Optimization of Rubble-Mound Breakwater Cross Sections," Technical Report CERC-86-2, US Army Engineer Waterways Experiment Station, Vicksburg, MS, pp. 45-53.
- Weggel, J. R. 1972. "Maximum Breaker Height," *Journal of Waterways, Harbors and Coastal Engineering Division*, American Society of Civil Engineers, Vol. 98, No. WW4, pp. 529-548.
- Weggel, J. R. 1976. "Wave Overtopping Equation," *Proceedings of the 15<sup>th</sup> Coastal Engineering Conference*, American Society of Civil Engineers, Honolulu, HI, pp. 2737-2755.

## WAVE TRANSMISSION ON IMPERMEABLE STRUCTURES

---

### TABLE OF CONTENTS

Description .....	5-3-1
Input .....	5-3-1
Output .....	5-3-2
Procedure .....	5-3-3
Single Case Mode .....	5-3-3
Multiple Case Mode .....	5-3-4
Example Problems .....	5-3-6
Example 1 - Sloped Structure - Known Runup - Transmission Only .....	5-3-6
Example 2 - Vertical Wall with Berm (Submerged) - Transmission Only .....	5-3-6
Example 3 - Rough Slope - Runup and Transmission (Riprap) .....	5-3-7
Example 4 - Smooth Slope - Runup and Transmission .....	5-3-7
References and Bibliography .....	5-3-8

## WAVE TRANSMISSION ON IMPERMEABLE STRUCTURES

### DESCRIPTION

This application provides estimates of wave runup and transmission on rough and smooth slope structures. It also addresses wave transmission over impermeable vertical walls and composite structures. In all cases, monochromatic waves are specified at the toe of a structure that is assumed to be impermeable. For sloped structures, a method suggested by Ahrens and Titus (1985) and Ahrens and Burke (1987) is used to predict runup, while the method of Cross and Sollitt (1971) as modified by Seelig (1980) is used to predict overtopping. For vertical wall and composite structures, a method proposed by Goda, Takeda, and Moriya (1967) and Goda (1969) is used to predict wave transmission.

### INPUT

The terminology used to define wave transmission on impermeable structures is shown in Figures 5-3-1 and 5-3-2.




Figure 5-3-1. Wave Runup and Overtopping




Figure 5-3-2. Composite Structure with Vertical Wall



All data input for this application is done on one screen. The following list describes the necessary input parameters with their corresponding units and range of data recognized by this application:

<u>Mandatory item</u>	<u>Symbol</u>	<u>Units</u>	<u>Data Range</u>	
Incident wave height	$H_i$	ft, m	0.1	to 100.0
Wave period	$T$	sec	1.0	to 1000.0
Cotan of nearshore slope	$\cot \phi$		5.0	to 10000.0
Water depth at structure toe	$d_s$	ft, m	0.1	to 200.0
Structure height above toe	$h_s$	ft, m	0.0	to 200.0
Structure crest width	$B$	ft, m	0.0	to 200.0

The above input variables are mandatory. In addition, the following input variables are required under the specified circumstances:

<u>Item</u>	<u>Symbol</u>	<u>Units</u>	<u>Data Range</u>		
<u>Rough and smooth slope</u>					
Cotan of structure slope	$\cot \Theta$		0.0	to	30.0
Runup (if known)	$R$	ft, m	0.0	to	100.0

<u>Item</u>	<u>Symbol</u>	<u>Source</u>
<u>Rough slope runup</u>		
Empirical coefficient	$a$	See Table A-3 of Appendix A for suggested values.
Empirical coefficient	$b$	

<u>Item</u>	<u>Symbol</u>	<u>Units</u>	<u>Data Range</u>		
<u>Vertical wall</u>					
Toe protection or composite breakwater berm height above structure toe (if present)	$h_b$	ft, m	0.0	to	200.0

## OUTPUT

Results from this application are displayed on one screen. Those data include the original input values (in final units) and the following parameters:

<u>Item</u>	<u>Symbol</u>	<u>English Units</u>	<u>Metric Units</u>
Wave runup (if requested)	$R$	ft	m
Transmitted wave height	$H_T$	ft	m

## PROCEDURE

The bulleted items in the following lists indicate potentially optional instruction steps. Any application in ACES may be executed in a given session without quitting the program. The bulleted items provide instructions for accessing the application from various menu areas of the ACES program. Ignore bulleted instruction steps that are not applicable.

### Single Case Mode

- ° Press **(F1)** on the Main Menu to select Single Case Mode.
- ° Fill in the highlighted input fields on the General Specifications screen (or leave the default values). Press **(F1)** when all data on this screen are correct.
- ° Press **(F5)** on the Functional Area Menu to select Wave Runup, Transmission, and Overtopping.
- ° Press **(F3)** on the Wave Runup, Transmission, and Overtopping Application Menu to select Wave Transmission on Impermeable Structures.
- ° On the Wave Transmission on Impermeable Structures Menu, press one of the following:
  - (F1)** Estimate wave transmission over a sloped structure (with a known run-up value).
  - (F2)** Estimate wave transmission over a vertical wall or composite breakwater.
  - (F3)** Estimate both runup and wave transmission on rough slope structures.
  - (F4)** Estimate both runup and wave transmission on smooth slope structures.
- 1. Fill in the highlighted input fields on the Wave Transmission on Impermeable Structures screen. Respond to any corrective instructions appearing at the bottom of the screen. Press **(F1)** when all data on this screen are correct.
 

**NOTE:** If the selected case involved the computation of rough slope runup, **(F10)** may be pressed to provide access to the additional following options (choose one):

  - (F1)** Return to the input screen.

- (F2) Display a table of suggested rough slope run-up empirical coefficients ( $a$  and  $b$ ). If this option is selected, these coefficients must be entered in the designated fields of the display screen. The data thus given will be transferred back to (and displayed on) the main input screen when (F1) is pressed.
    - (F10) Exit the application.
- 2. All input and output data are displayed on the screen in the final system of units.
- 3. Press one of the following keys to select the appropriate action:
  - (F1) Return to Step 1 for a new case.
  - (F3) Send a summary of this case to the print file or device.
  - (F10) Exit this application and return to the Wave Runup, Transmission, and Overtopping Menu.

### Multiple Case Mode

Run-up values and the associated transmitted wave heights over sloped structures are provided in this operational mode. Also, wave transmission over vertical walls and composite structures is handled. Wave transmission with known run-up values on sloped structures is excluded because of possible functional dependencies between given incident wave conditions, structure slope, and run-up values. Single Case or Batch Modes may be used to process cases providing wave transmission with known run-up values.

- ° Press (F2) on the Main Menu to select Multi Case Mode.
- ° Fill in the highlighted input fields on the General Specifications screen (or leave the default values). Press (F1) when all data on this screen are correct.
- ° Press (F5) on the Functional Area Menu to select Wave Runup, Transmission, and Overtopping.
- ° Press (F3) on the Wave Runup, Transmission, and Overtopping Application Menu to select Wave Transmission on Impermeable Structures.
- ° On the Wave Transmission on Impermeable Structures Menu, press one of the following:
  - (F2) Estimate wave transmission over vertical walls or composite structures.
  - (F3) Estimate runup and wave transmission on rough slope structures.

**NOTE:** Selection of this option will display the table of suggested rough slope run-up empirical coefficients ( $a$  and  $b$ ). Fill in the highlighted input fields with the values for these items, and press **(F1)** to resume input on the main input screen, or press **(F10)** to exit the application.

**(F4)** Estimate runup and wave transmission on smooth slope structures.

1. Move the cursor to select a variable on the Wave Transmission on Impermeable Structures screen (the selected variable name blinks). The current set of values for the variable is displayed on the right portion of the screen. When all variable sets are correct, go to Step 3.
2. Enter a set of values for the subject variable by following one of the input methods:
  - a. Press **(R)** to select random method. Enter up to 20 values constituting a set for this variable (one in each field) on the right side of the screen. The set of 20 values originally displayed (first execution) in these fields contains the "delimiting" value, which "delimits" or "ends" the set. The "delimiting" value is *not* included as a member in the set unless it is the sole member.
  - b. Press **(I)** to select incremental method. Fill in the fields for minimum, maximum, and increment values for this variable on the right side of the screen. In this method, the members of the set include all values from the minimum to the maximum (both inclusive) at the specified increment.

The units field should also be specified for the variable regardless of input method. All members of a set of values for a subject variable are assigned the specified units. When all data are correct for the subject variable, press **(F10)** to return to Step 1. Errors are reported at the bottom of the screen and are corrected by pressing **(F1)** to allow respecification of the data for the subject variable.

3. Press **(F1)** to process the cases resulting from the combinations of the sets of data for all variables. The summary of each case will be sent to the print file or device. The screen will display the total number of cases to be processed as well as report progress. Errors are reported at the bottom of the screen and are corrected by pressing **(F1)** to allow respecification of variable sets.
4. Press one of the following keys to select the appropriate action:
  - (F1)** Return to Step 1 to specify new sets.
  - (F10)** Exit this application and return to the Wave Runup, Transmission, and Overtopping Menu.

**EXAMPLE PROBLEMS****Example 1 - Sloped Structure - Known Runup - Transmission Only****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	10.00	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	15.00	ft
Structure crest width	$B$	7.50	ft
Known runup	$R$	15.00	ft

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Transmitted wave height	$H_T$	2.275	ft

**Example 2 - Vertical Wall with Berm (Submerged) - Transmission Only****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	4.50	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	20.00	ft
Structure height above toe	$h_s$	17.50	ft
Structure crest width	$B$	12.00	ft
Structure berm height above toe	$h_b$	6.00	ft

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Transmitted wave height	$H_T$	3.798	ft

**Example 3 - Rough Slope - Runup and Transmission (Riprap)****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	10.00	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	15.00	ft
Structure crest width	$B$	7.50	ft
Empirical coefficient	$a$	0.956	
Empirical coefficient	$b$	0.398	

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Wave runup	$R$	9.421	ft
Transmitted wave height	$H_T$	1.601	ft

**Example 4 - Smooth Slope - Runup and Transmission****Input**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Incident wave height	$H_i$	7.50	ft
Wave period	$T$	10.00	sec
Cotan of nearshore slope	$\cot \phi$	100.00	
Water depth at structure toe	$d_s$	10.00	ft
Cotan of structure slope	$\cot \Theta$	3.00	
Structure height above toe	$h_s$	15.00	ft
Structure crest width	$B$	7.50	ft

**Output**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Wave runup	$R$	22.436	ft
Transmitted wave height	$H_T$	2.652	ft

**REFERENCES AND BIBLIOGRAPHY**

- Ahrens, J. P. 1977. "Prediction of Irregular Wave Overtopping," CERC CETA 77-7, US Army Engineer Waterways Experiment Station, Vicksburg, MS.
- Ahrens, J. P., and Burke, C. E. 1987. Unpublished report of modifications to method cited in above reference.
- Ahrens, J. P., and Titus, M. F. 1985. "Wave Runup Formulas for Smooth Slopes," *Journal of Waterway, Port, Coastal and Ocean Engineering*, American Society of Civil Engineers, Vol. 111, No. 1, pp. 128-133.
- Battjes, J. A. 1974. "Surf Similarity," *Proceedings of the 14th Coastal Engineering Conference*, Copenhagen, Denmark.
- Cross, R., and Sollitt, C. 1971. "Wave Transmission by Overtopping," Technical Note No. 15, Massachusetts Institute of Technology, Ralph M. Parsons Laboratory, Boston.
- Douglass, S. L. 1986. "Review and Comparison of Methods for Estimating Irregular Wave Overtopping Rates," Technical Report CERC-86-12, US Army Engineer Waterways Experiment Station, Vicksburg, MS, pp. 6-14.
- Goda, Y. 1969. "Reanalysis of Laboratory Data on Wave Transmission over Breakwaters," *Report of the Port and Harbour Research Institute*, Vol. 8, No. 3.
- Goda, Y. 1983. "A Unified Nonlinearity Parameter of Water Waves," *Report of the Port and Harbour Research Institute*, Vol. 22, No. 3, pp. 3-30.
- Goda, Y., Takeda, H., and Moriya, Y. 1967. "Laboratory Investigation of Wave Transmission over Breakwaters," *Report of the Port and Harbour Research Institute*, No. 13.
- Saville, T., Jr. 1955. "Laboratory Data on Wave Run-Up and Overtopping on Shore Structures," TM No. 64, US Army Corps of Engineers, Beach Erosion Board, Washington, DC.
- Seelig, W. N. 1976. "A Simplified Method for Determining Vertical Breakwater Crest Elevation Considering Wave Height Transmitted by Overtopping," CERC CDM 76-1, US Army Engineer Waterways Experiment Station, Vicksburg, MS.
- Seelig, W. N. 1980. "Two-Dimensional Tests of Wave Transmission and Reflection Characteristics of Laboratory Breakwaters," CERC TR 80-1, US Army Engineer Waterways Experiment Station, Vicksburg, MS.
- Shore Protection Manual*. 1984. 4th ed., 2 Vols., US Army Engineer Waterways Experiment Station, Coastal Engineering Research Center, US Government Printing Office, Washington, DC, Chapter 7, pp. 61-80.
- Smith, O. P. 1986. "Cost-Effective Optimization of Rubble-Mound Breakwater Cross Sections," Technical Report CERC-86-2, US Army Engineer Waterways Experiment Station, Vicksburg, MS, pp. 45-53.
- Weggel, J. R. 1972. "Maximum Breaker Height," *Journal of Waterways, Harbors and Coastal Engineering Division*, American Society of Civil Engineers, Vol. 98, No. WW4, pp. 529-548.

## WAVE TRANSMISSION THROUGH PERMEABLE STRUCTURES

---

### TABLE OF CONTENTS

Description .....	5-4-1
Input .....	5-4-1
First Screen .....	5-4-1
Second Screen (Breakwater Geometry Input) .....	5-4-2
Output .....	5-4-3
Procedure .....	5-4-3
Single Case Mode .....	5-4-3
Multiple Case Mode .....	5-4-4
Example Problems .....	5-4-6
Example 1 - Breakwater (3 Materials and 3 Layers) .....	5-4-6
Input .....	5-4-6
First Screen .....	5-4-6
Second Screen (Breakwater Geometry Input) .....	5-4-6
Output .....	5-4-7
Example 2 - Breakwater (3 Materials and 4 Layers) .....	5-4-8
Input .....	5-4-8
First Screen .....	5-4-8
Second Screen (Breakwater Geometry Input) .....	5-4-8
Output .....	5-4-9
References and Bibliography .....	5-4-10



## WAVE TRANSMISSION THROUGH PERMEABLE STRUCTURES

---

### DESCRIPTION

Porous rubble-mound structures consisting of quarry stones of various sizes often offer an attractive solution to the problem of protecting a harbor against wave action. It is important to assess the effectiveness of a given breakwater design by predicting the amount of wave energy transmitted by the structure. This application determines wave transmission coefficients and transmitted wave heights for permeable breakwaters with crest elevations at or above the still-water level. This application can be used with breakwaters armored with stone or artificial armor units. The application uses a method developed for predicting wave transmission by overtopping coefficients using the ratio of breakwater freeboard to wave runup (suggested by Cross and Sollitt, 1971). The wave transmission by overtopping prediction method is then combined with the model of wave reflection and wave transmission through permeable structures of Madsen and White (1976). Seelig (1979,1980) had developed a similar version for mainframe processors.

### INPUT

All data input for this application is done on two screens. For each screen the necessary input parameters with their corresponding units and range of data recognized by this application are given below.

#### First Screen

<u>Item</u>	<u>Symbol</u>	<u>Units</u>	<u>Data Range</u>		
Incident wave height	$H_i$	ft, m	0.1	to	100.0
Wave period	$T$	sec	1.0	to	1000.0
Water depth at structure	$d_s$	ft, m	0.1	to	200.0
Number of materials comprising the breakwater	$NM$		1	to	4

Mean diameter of each material	$d_{50}$	ft, m	0.05	to	99.0
--------------------------------	----------	-------	------	----	------

**NOTE:** Determine the mean diameter of a given material using the following relation:

$$d_{50} = \left( \frac{W_{50}}{\gamma} \right)^{\frac{1}{3}} \quad \text{where:} \quad \begin{array}{l} W_{50} = \text{median weight} \\ \gamma = \text{specific weight} \end{array}$$

Porosity of each material	$P$	%	See Table A-2, Appendix A		
---------------------------	-----	---	---------------------------	--	--

### Second Screen (Breakwater Geometry Input)

<u>Item</u>	<u>Symbol</u>	<u>Units</u>	<u>Data Range</u>		
Units		ft, m			
Structure height above toe	$h_s$	ft, m	0.1	to	200.0
Cotangent of structure slope	$\cot \theta$		1.0	to	5.0
Structure crest width	$B$	ft, m	0.1	to	200.0
Number of horizontal layers in the breakwater	$NL$		1	to	4

**NOTE:** Divide the breakwater into horizontal layers. A new layer occurs any time there is a change vertically in any material type. Make the layer next to the seabed *layer number 1* and proceed upward.

Thickness of each horizontal layer	$TH$	ft, m	0.1	to	200.0
Horizontal length of each material in each layer	$LL$	ft, m	0.0	to	200.0

**NOTE:** Determine an *average* horizontal length of each material in each layer. This average length is measured at the *midpoint* of each layer. Remove the outer layer of armor from the seaward face of the breakwater before making length calculations, because the energy dissipation on the front face is determined separately.

## OUTPUT

Results from this application are displayed on one screen. Those data include the original input values (in final units) and the following parameters:

<u>Item</u>	<u>Symbol</u>	<u>English Units</u>	<u>Metric Units</u>
Wave reflection coefficient	$K_R$		
Wave transmission coefficients			
Through	$K_{Tt}$		
Overtopping	$K_{To}$		
Total	$K_T$		
Transmitted wave height	$H_T$	ft	m

## PROCEDURE

The bulleted items in the following lists indicate potentially optional instruction steps. Any application in ACES may be executed in a given session without quitting the program. The bulleted items provide instructions for accessing the application from various menu areas of the ACES program. Ignore bulleted instruction steps that are not applicable.

### Single Case Mode

- Press **(F1)** on the Main Menu to select Single Case Mode.
- Fill in the highlighted input fields on the General Specifications screen (or leave the default values). Press **(F1)** when all data on this screen are correct.
- Press **(F5)** on the Functional Area Menu to select Wave Runup, Transmission, and Overtopping.
- Press **(F4)** on the Wave Runup, Transmission, and Overtopping Menu to select Wave Transmission Through Permeable Structures.

1. Fill in the highlighted input fields on the first screen; then press **F1** to obtain the second screen in this application, and fill in the input fields. Respond to any corrective instructions appearing at the bottom of the screens. Press **F1** when all data on this second screen are correct.
2. All output data and selected input data are displayed on the screen in the final system of units.
3. Press one of the following keys to select the appropriate action:
  - F1** Return to Step 1 for a new case.
  - F3** Send a summary of this case to the print file or device.
  - F10** Exit this application and return to the Wave Runup, Transmission, and Overtopping Menu.

### Multiple Case Mode

- Press **F2** on the Main Menu to select Multi Case Mode.
  - Fill in the highlighted input fields on the General Specifications screen (or leave the default values). Press **F1** when all data on this screen are correct.
  - Press **F5** on the Functional Area Menu to select Wave Runup, Transmission, and Overtopping.
  - Press **F4** on the Wave Runup, Transmission, and Overtopping Menu to select Wave Transmission Through Permeable Structures.
1. Fill in the highlighted input fields on the first screen; then press **F1** to obtain the second screen in this application, and fill in the input fields. Respond to any corrective instructions appearing at the bottom of the screen. Press **F1** when all data on this second screen are correct to obtain the third data input screen.
  2. Move the cursor to select the wave height or wave period variable on this screen (the selected variable name blinks). The current set of values for the variable is displayed on the right portion of the screen. When all variable sets are correct, go to Step 4.

3. Enter a set of values for the subject variable by following one of the input methods:
  - a. Press **[R]** to select random method. Enter up to 20 values constituting a set for this variable (one in each field) on the right side of the screen. The set of 20 values originally displayed (first execution) in these fields contains the "delimiting" value, which "delimits" or "ends" the set. The "delimiting" value is *not* included as a member in the set unless it is the sole member.
  - b. Press **[I]** to select incremental method. Fill in the fields for minimum, maximum, and increment values for this variable on the right side of the screen. In this method, the members of the set include all values from the minimum to the maximum (both inclusive) at the specified increment.

The units field should also be specified for the variable regardless of input method. All members of a set of values for a subject variable are assigned the specified units. When all data are correct for the subject variable, press **[F10]** to return to Step 1. Errors are reported at the bottom of the screen and are corrected by pressing **[F1]** to allow respecification of the data for the subject variable.

4. Press **[F1]** to process the cases resulting from the combinations of the sets of data for all variables. The summary of each case will be sent to the print file or device. The screen will display the total number of cases to be processed as well as report progress. Errors are reported at the bottom of the screen and are corrected by pressing **[F1]** to allow respecification of variable sets.
5. Press one of the following keys to select the appropriate action:

- [F1]** Return to Step 1 to specify new sets.
- [F10]** Exit this application and return to the Wave Runup, Transmission, and Overtopping Menu.

## EXAMPLE PROBLEMS

### Example 1 - Breakwater (3 Materials and 3 Layers)

#### Input

All data input for this application is done on two screens. For each screen the values and corresponding units selected for this first example problem are shown below.

#### First Screen

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Wave Characteristics			
Incident wave height	$H_i$	6.56	ft
Wave period	$T$	20.00	sec
Water depth at structure	$d_s$	15.75	ft
<u>Item</u>	<u>Symbol</u>	<u>Value</u>	
Material Characteristics			
Number of materials comprising the breakwater	$NM$	3	
Units			ft
Mean diameter of material 1-Armor	$d_{50}$	2.39	
Mean diameter of material 2-Underlayer		1.11	
Mean diameter of material 3-Core		0.30	
Porosity of material 1	$P$	37%	
Porosity of material 2		37%	
Porosity of material 3		37%	

#### Second Screen (Breakwater Geometry Input)

See Figure 5-4-1 for the breakwater dimensions used in this first example.

<u>Item</u>	<u>Symbol</u>	<u>Value</u>
Units		ft
Structure height above toe	$h_s$	19.69
Cotangent of structure slope	$\cot \theta$	1.5
Structure crest width	$B$	8.27
Number of horizontal layers in the breakwater	$NL$	3

Thickness of layer 1	$TH_1$	11.65
Thickness of layer 2	$TH_2$	2.56
Thickness of layer 3	$TH_3$	1.54

Note: Sum of the layer thicknesses must = the water depth.

Length of material 1 in layer 1	$LL_{1,1}$	14.76 <sup>(9.84+4.92)</sup>
Length of material 1 in layer 2	$LL_{1,2}$	14.76 <sup>(9.84+4.92)</sup>
Length of material 1 in layer 3	$LL_{1,3}$	17.39
Length of material 2 in layer 1	$LL_{2,1}$	12.46 <sup>(6.23+6.23)</sup>
Length of material 2 in layer 2	$LL_{2,2}$	8.20
Length of material 2 in layer 3	$LL_{2,3}$	0.0
Length of material 3 in layer 1	$LL_{3,1}$	21.00
Length of material 3 in layer 2	$LL_{3,2}$	0.0
Length of material 3 in layer 3	$LL_{3,3}$	0.0




Figure 5-4-1. Sample Problem 1 - Breakwater Geometry

### Output

Item	Symbol	Value	Units
Wave reflection coefficient	$K_R$	0.719	
Wave transmission coefficients			
Through	$K_{Tt}$	0.077	
Overtopping	$K_{To}$	0.227	
Total	$K_T$	0.239	
Transmitted wave height	$H_T$	1.570	ft

**Example 2 - Breakwater (3 Materials and 4 Layers)****Input**

All data input for this application is done on two screens. For each screen the values and corresponding units selected for this second example problem are shown below.

**First Screen**

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Wave Characteristics			
Incident wave height	$H_i$	10	ft
Wave period	$T$	15.00	sec
Water depth at structure	$d_s$	25.00	ft
<u>Item</u>	<u>Symbol</u>	<u>Value</u>	
Material Characteristics			
Number of materials comprising the breakwater	$NM$	3	
Units			ft
Mean diameter of material 1	$d_{50}$	3.61	
Armor-16,000 lb units (170 lb/ft <sup>3</sup> )			
Mean diameter of material 2		2.07	
Underlayer-3,000 lb stone (170 lb/ft <sup>3</sup> )			
Mean diameter of material 3		1.05	
Core-400 lb stone (170 lb/ft <sup>3</sup> )			
Porosity of material 1	$P$	37%	
Porosity of material 2		37%	
Porosity of material 3		37%	

**Second Screen (Breakwater Geometry Input)**

See Figure 5-4-2 for the breakwater dimensions used in this second example.

<u>Item</u>	<u>Symbol</u>	<u>Value</u>
Units		ft
Structure height above toe	$h_s$	38.00
Cotangent of structure slope	$\cot \theta$	1.75
Structure crest width	$B$	18.00
Number of horizontal layers in the breakwater	$NL$	4




Thickness of layer 1	$TH_1$	4.00
Thickness of layer 2	$TH_2$	8.00
Thickness of layer 3	$TH_3$	7.00
Thickness of layer 4	$TH_4$	6.00

**Note:** Sum of the layer thicknesses must = the water depth.

Length of material 1 in layer 1	$LL_{1,1}$	0
Length of material 1 in layer 2	$LL_{1,2}$	0
Length of material 1 in layer 3	$LL_{1,3}$	10
Length of material 1 in layer 4	$LL_{1,4}$	$28_{(10+18)}$
Length of material 2 in layer 1	$LL_{2,1}$	14
Length of material 2 in layer 2	$LL_{2,2}$	36
Length of material 2 in layer 3	$LL_{2,3}$	$46_{(16+30)}$
Length of material 2 in layer 4	$LL_{2,4}$	32
Length of material 3 in layer 1	$LL_{3,1}$	128
Length of material 3 in layer 2	$LL_{3,2}$	75
Length of material 3 in layer 3	$LL_{3,3}$	22
Length of material 3 in layer 4	$LL_{3,4}$	0

**NOTE:** Length of a particular material is measured at the *midpoint* of the layer.



**Figure 5-4-2. Sample Problem 2 - Breakwater Geometry**

## Output

<u>Item</u>	<u>Symbol</u>	<u>Value</u>	<u>Units</u>
Wave reflection coefficient	$K_R$	0.662	
Wave transmission coefficients			
Through	$K_{Tt}$	0.055	
Overtopping	$K_{To}$	0	
Total	$K_T$	0.055	
Transmitted wave height	$H_T$	0.550	ft

## REFERENCES AND BIBLIOGRAPHY

- Ahrens, J. P., and McCartney B. L. 1975. "Wave Period Effect on the Stability of Riprap," *Proceedings of Civil Engineering in the Oceans/III*, American Society of Civil Engineers, pp. 1019-1034.
- Bear, J., et al. 1968. *Physical Principles of Water Percolation and Seepage*, United Nations Educational, Scientific and Cultural Organization.
- Cross, R., and Sollitt, C. 1971. "Wave Transmission by Overtopping," Technical Note No. 15, Ralph M. Parsons Laboratory, Massachusetts Institute of Technology, Boston.
- Madsen, O. S., and White, S. M. 1976. "Reflection and Transmission Characteristics of Porous Rubble-Mound Breakwaters," CERC MR 76-5, US Army Engineer Waterways Experiment Station, Vicksburg, MS.
- Morris, A. H. 1981. "NSWC/DL Library of Mathematics Subroutines," NSWC-TR-81-410, Naval Surface Weapons Center, Dahlgren, VA.
- Seelig, W. N. 1979. "Estimation of Wave Transmission Coefficients for Permeable Breakwaters," CERC CETA 79-6, US Army Engineer Waterways Experiment Station, Vicksburg, MS.
- Seelig, W. N. 1980. "Two-Dimensional Tests of Wave Transmission and Reflection Characteristics of Laboratory Breakwaters," CERC TR 80-1, US Army Engineer Waterways Experiment Station, Vicksburg, MS.