

Ignition Switch (Or Starter Switch)

- 44 Before starting the engine, ensure that the handbrake is applied. For auto transmission vehicles, ensure that the gear lever is at 'P' (Parked) position.
- (a) To start the engine, turn the ignition key in a clockwise direction to the START position.
 - (b) To switch off the engine, turn the ignition key in an anti-clockwise direction to the OFF position.
 - (c) To withdraw the key, turn it further to the LOCK position. (Note that the key can only be removed with the engine off).

LOCK - The steering wheel is locked when the key is not inserted. Insert the key and turn it in a clockwise direction to unlock the steering wheel.

OFF - Engine and accessories are off. The steering wheel is free.

ACC - Electric current flows to accessory fixtures.

ON - Electric current flows to ignition system.

START - Starter motor begins to rotate. Once the engine is started, quickly release the key. It will automatically return to the 'ON' position.

