

Direction Indicator Lever

- 45 The direction indicator switch is used to indicate to other motorists the direction in which you wish to proceed. When the switch is operated, yellow indicator lights situated at each end of the front and rear of the car will flash on and off. When making a turn, shift the lever in the direction in which you wish to turn. When the turn is completed, the lever will automatically return to its original position.



Windscreen Wiper And Washer

- 46 To operate the windscreen wiper, move the lever downwards to any of the wiper speed positions of your choice. The windscreen washer is operated by pulling the lever towards you or pushing the button at the end of the lever.



Horn

- 47 The horn is usually located at the cross bar of the steering wheel. It is used to warn other road users of any impending danger.

