

High Beam Indicator

- 62 This light will come on when the headlight switch is turned to the high beam position.



Door Warning Light

- 63 This light will come on when any of the doors is not properly shut.



Brake Warning Light

- 64 The brake warning light will come on when the ignition key is switched to the ON Position and goes off once the handbrake is released. When it remains on, it means that the brake fluid in the brake fluid reservoir is below the prescribed level.



Oil Pressure Warning Light

- 65 This light will come on when the ignition is switched to the ON position. If the light fails to go off after the engine is started, this indicates that the lubricating oil in the engine is below the prescribed level.



Battery Warning Light

- 66 This light will come on when the ignition key is switched to the ON position. It will go off once the engine is started. If the light fails to go off after the engine is started, it means that the battery charging system is faulty.

