

4. Zone

4.1. setLinkControl

For setting Link Control in each Zone.

Request Parameters

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
control	string	yes	Specifies Link Control setting Values: Values gotten via /system/getFeatures

URI	<BaseURL>/v1/<zone>/setLinkControl?control=<control>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setLinkControl?control=normal

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

4.2. setLinkAudioDelay

For setting Link Audio Delay in each Zone. This setting is invalid when Link Control setting is "Stability Boost".

Request Parameters

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
delay	string	yes	Specifies Link Audio Delay setting Values: Values gotten via /system/getFeatures

URI	<BaseURL>/v1/<zone>/setLinkAudioDelay?delay=<delay>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setLinkAudioDelay?delay=lip_sync

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details