

URI	<BaseURL>/v1/<zone>/controlMenu?menu=<menu>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/controlMenu?menu=top_menu

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0, }
------------------	------------------------------

5.27. setActualVolume

Set the volume of each Zone with the value to display.

It is valid only when " actual_volume " exists in zone – func_list of /system/getFeatures.

Request Parameters

name	type	required	Description
zone	string	yes	Specifies target Zone Values: "main" / "zone2" / "zone3" / "zone4"
mode	string	yes	Specifies mode Values: Actual_volume_mode_list gotten via /system/getFeatures
value	floating point	no	Specifies volume Values: Calculated from minimum value, maximum value, step value of volume gotten via /system/getFeatures

URI	<BaseURL>/v1/<zone>/setActualVolume?mode=<mode>&value=<value>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setActualVolume?mode=db&volume=-23.5

Response Parameters

name	type	Description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

5.28. setAudioSelect

Set the audio input selection.

It is valid only when " audio_select " exists in zone – func_list of /system/getFeatures.

In the value of audio_select_list obtained by /system/getFeatures, it is possible to specify something other than unavailable. If current audio_select (gotten with getStatus) is unavailable, it can not be set.