

	<pre> "track":"Forget-me-not", "albumart_url":"/YamahaRemoteControl/AlbumART/AlbumART.jpg", "albumart_id":18, "usb_devicetype":"msc", "attribute":511 } </pre>
--	--

7.3. setPlayback

For controlling playback status

Request Parameters

name	type	required	description
playback	string	yes	Specifies playback status Values: "play" / "stop" / "pause" / "play_pause" / "previous" / "next" / "fast_reverse_start" / "fast_reverse_end" / "fast_forward_start" / "fast_forward_end"

URI	<BaseURL>/v1/netusb/setPlayback?playback=<playback>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/netusb/setPlayback?playback=stop

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	<pre> { "response_code":0 } </pre>
------------------	--------------------------------------

7.4. setPlayPosition

For setting track play position. This API is available only when input is Server.

Request Parameters

name	type	required	description
position	integer	yes	Specifies play position (sec) Value : no fewer than total_time gotten via getPlayInfo, nor more than 0

URI	<BaseURL>/v1/netusb/setPlayPosition?position=<position>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/netusb/setPlayPosition?position=123

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error