

		/system/getFeatures
- treble	integer	Returns Treble status Value Range: calculated by minimum/maximum/step values gotten via /system/getFeatures
equalizer	object	Returns Equalizer status
- mode	string	Returns Mode type. Available on after API version 1.15 Values: what is gotten via /system/getFeatures
- low	integer	Returns Low status Value Range: calculated by minimum/maximum/step values gotten via /system/getFeatures
- mid	integer	Returns Mid status Value Range: calculated by minimum/maximum/step values gotten via /system/getFeatures
- high	integer	Returns High status Value Range: calculated by minimum/maximum/step values gotten via /system/getFeatures
balance	integer	Returns Speaker L/R Balance status. Negative values are for left side, positive values are for right side balance Value Range: calculated by minimum/maximum/step values gotten via /system/getFeatures
dialogue_level	integer	Returns Dialogue Level status Values: Value range calculated by minimum/maximum/step values gotten via /system/getFeatures
dialogue_lift	integer	Returns Dialogue Lift status Value Range: calculated by minimum/maximum/step values gotten via /system/getFeatures
clear_voice	boolean	Returns Clear Voice status
subwoofer_volume	integer	Returns Subwoofer Volume status Value Range: calculated by minimum/maximum/step values gotten via /system/getFeatures
bass_extension	boolean	Returns Bass Extension status
link_control	string	Returns Link Control setup status Values: what is gotten via /system/getFeatures
link_audio_delay	string	Returns Audio Delay setup status Values: what is gotten via /system/getFeatures
link_audio_quality	string	Returns audio quality setting of distribution Values: what is gotten via /system/getFeatures
disable_flags	integer	Returns flags of functions that are not operable/available currently. Disable status is expressed as OR of bit field shown below, i.e. functions that listed in zone - func_list of /system/getFeatures, and also that have no flags of below are only valid/available/operable b[0] Volume b[1] Mute b[2] Link Audio Delay
contents_display	boolean	Returns display setting of screen Not displayed if contents_display does not exist in the zone - func_list of /system/getFeatures.
actual_volume	object	Returns the display volume setting. Not displayed when there is no volume.