

4.22. setAutoPowerStandby

For setting Auto Power Standby status. Actual operations/reactions of enabling Auto Power Standby depend on each Device

Request Parameters

name	type	required	description
enable	boolean	yes	Specifies Auto Power Standby status

URI	<BaseURL>/v1/system/setAutoPowerStandby?enable=<enable>		
Method	GET		
Example Request	http://{host}/YamahaExtendedControl/v1/system/setAutoPowerStandby?enable=true		

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	<pre>{ "response_code":0 }</pre>	
------------------	------------------------------------	--

4.23. setIrSensor

For setting remote control IR sensor

Request Parameters

name	type	required	description
enable	boolean	yes	Specifies setting of IR sensor

URI	<BaseURL>/v1/system/setIrSensor?enable=<enable>		
Method	GET		
Example Request	http://{host}/YamahaExtendedControl/v1/system/setIrSensor?enable=true		

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	<pre>{ "response_code":0 }</pre>	
------------------	------------------------------------	--