

## 4.12. getNetworkStandby

For retrieving setup of Network Standby

### Request Parameters

URI	<BaseURL>/v1/system/getNetworkStandby
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/getNetworkStandby

### Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to <a href="#">"Response Code List"</a> for details
network_standby	string	Returns setup of Network Standby. "auto" is available only when "network_standby_auto" exists in system - func_list under /system/getFeatures Values: "off" / "on" / "auto"

Example Response	{ "response_code":0, "network_standby":"auto" }
------------------	--

## 4.13. setNetworkStandby

For setting Network Standby

### Request Parameters

name	type	required	description
standby	string	yes	Specifies setup of Network Standby. "auto" is available only when "network_standby_auto" exists in system - func_list under /system/getFeatures Values: "off" / "on" / "auto"

URI	<BaseURL>/v1/system/setNetworkStandby?standby=<standby>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/setNetworkStandby?standby=on

### Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to <a href="#">"Response Code List"</a> for details

Example Response	{ "response_code":0 }
------------------	-----------------------------