

5.16. setDialogueLevel

For setting Dialogue Level in each Zone. Values of specifying range and steps are different.

Request Parameters

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
value	integer	yes	Specifies Dialogue Level value Values: Value range calculated by minimum/maximum/step values gotten via /system/getFeatures

URI	<BaseURL>/v1/<zone>/setDialogueLevel?value=<value>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setDialogueLevel?value=2

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to "Response Code List" for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

5.17. setDialogueLift

For setting Dialogue Lift in each Zone. Values of specifying range and steps are different.

Request Parameters

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
value	integer	yes	Specifies Dialogue Lift value Values: Value range calculated by minimum/maximum/step values gotten via /system/getFeatures

URI	<BaseURL>/v1/<zone>/setDialogueLift?value=<value>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setDialogueLift?value=3

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to "Response Code List" for details