

```

"response_code":0,
"input":"usb",
"menu_layer":3,
"max_line":40,
"index":32,
"playing_index":-1,
"menu_name":"The Beatles",
"list_info":[
  {
    "text":"Please Please Me",
    "subtexts":[
      "The Beatles"
    ],
    "attribute":2,
    "appearance":[
    ]
  },
  ...
  {
    "text":"Let It Be",
    "subtexts":[
      "The Beatles"
    ],
    "attribute":20,
    "appearance":[
    ]
  }
]
}

```

7.10. setListControl

For control a list. Controllable list info is not limited to or independent from current input

Request Parameters

| name | type | required | description |
|---------|--------|----------|--|
| list_id | string | no | Specifies list ID. If nothing specified, "main" is chosen implicitly Values: "main" (common for all Net/USB sources) "auto_complete" (Pandora) "search_artist" (Pandora) "search_track" (Pandora) |
| type | string | yes | Specifies list transition type. "select" is to enter and get into one deeper layer than the current layer where the element specified by the index belongs to. "play" is to start playback current index element, "return" is to go back one upper layer than current. "select" and "play" needs to specify an index at the same time. |