

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

4.16. setBluetoothTxSetting

For setting Bluetooth transmission

Request Parameters

name	type	required	description
enable	boolean	yes	Specifies Bluetooth transmission setting

URI	<BaseURL>/v1/system/setBluetoothTxSetting?enable=<enable>		
Method	GET		
Example Request	http://{host}/YamahaExtendedControl/v1/system/setBluetoothTxSetting?enable=true		

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

4.17. getBluetoothDeviceList

For retrieving Bluetooth (Sink) device list. This API is available only when "bluetooth_tx_setting" is true under /system/getFuncStatus.

This device list information is in the cach. If update device list information, excute /system/updateBluetoothDeviceList.

Request Parameters

URI	<BaseURL>/v1/system/getBluetoothDeviceList		
Method	GET		
Example Request	http://{host}/YamahaExtendedControl/v1/system/getBluetoothDeviceList		

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details
updating	boolean	Returns whether or not device list is being updated. Returns true while