

| | |
|-----------------|--|
| URI | <BaseURL>/v1/<zone>/setEqualizer?mode=<mode>&low=<low>&mid=<mid>&high=<high> |
| Method | GET |
| Example Request | http://{host}/YamahaExtendedControl/v1/main/setEqualizer?mode=manual&low=3&mid=-2&high=5 |

Response Parameters

| name | type | description |
|---------------|---------|--|
| response_code | integer | 0: Successful request / Others: Error Refer to " Response Code List " for details |

| | |
|------------------|-----------------------------|
| Example Response | { "response_code":0 } |
|------------------|-----------------------------|

5.15. setBalance

For setting L/R Balance in each Zone's speaker. Values of specifying range and steps are different.

Request Parameters

| name | type | required | description |
|-------|---------|----------|---|
| zone | string | yes | Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4" |
| value | integer | yes | Specifies L/R Balance value. Negative values are for left side, positive values are for right side balance. Values: Value range calculated by minimum/maximum/step values gotten via /system/getFeatures |

| | |
|-----------------|--|
| URI | <BaseURL>/v1/<zone>/setBalance?value=<value> |
| Method | GET |
| Example Request | http://{host}/YamahaExtendedControl/v1/main/setBalance?value=5 |

Response Parameters

| name | type | description |
|---------------|---------|--|
| response_code | integer | 0: Successful request / Others: Error Refer to " Response Code List " for details |

| | |
|------------------|-----------------------------|
| Example Response | { "response_code":0 } |
|------------------|-----------------------------|